

UM EN RAD-...-IFS

User manual

Radioline - Wireless transmission system for serial interfaces and I/O signals

UM EN RAD-...-IFS, Revision 05

2018-09-21

This user manual is valid for:

Designation	Order No.
Wireless modules:	
RAD-2400-IFS	2901541
RAD-868-IFS	2904909
RAD-2400-IFS-JP	2702863
I/O extension modules:	
RAD-AI4-IFS	2901537
RAD-PT100-4-IFS	2904035
RAD-AO4-IFS	2901538
RAD-DI4-IFS	2901535
RAD-DI8-IFS	2901539
RAD-DOR4-IFS	2901536
RAD-DO8-IFS	2902811
RAD-DAIO6-IFS	2901533

105542_en_05

Table of contents

1	For your safety	7
1.1	Marking of warning notes.....	7
1.2	Qualification of users	7
1.3	Field of application of the product.....	8
1.4	Installation notes.....	10
1.5	Installation in Zone 2.....	11
1.6	Notes for individual I/O extension modules.....	12
1.7	UL notes (RAD-2400-IFS and I/O extension modules only).....	12
1.8	FCC, Industry Canada, IFT Mexico (RAD-2400-IFS only)	13
2	Brief description	15
2.1	Wireless modules	15
2.2	Firmware versions	16
2.3	I/O extension modules	17
2.4	Application examples	18
3	Installation	19
3.1	Wireless module structure	19
3.2	Basic circuit diagram	20
3.3	Mounting and removal	20
3.4	Connecting the cables	22
3.5	Connecting the power supply	23
3.6	Serial interfaces.....	24
3.7	Connecting the antenna	27
4	Configuration and startup	29
4.1	Default settings of the wireless module	29
4.2	Operating mode of the wireless module	31
4.3	Setting the address of the wireless module using the thumbwheel.....	35
4.4	Configuration using the configuration stick	35
4.5	Copying the device settings via a memory stick	37
4.6	Configuration via the PSI-CONF software	38
4.7	Diagnostics on the wireless module	44
4.8	Diagnostics via PSI-CONF software	49
4.9	Starting up I/O extension modules.....	52
4.10	Startup time of the wireless station	54
5	Serial data mode	55
5.1	Frame-based data transmission	57

RAD-...-IFS

5.2	Setting telegram pauses based on the example of Modbus/RTU	58
6	PLC / Modbus/RTU	59
6.1	PLC / Modbus/RTU mode	59
6.2	PLC / Modbus/RTU dual mode.....	62
6.3	Watchdog	65
6.4	Modbus function codes	66
6.5	Module type and error code registers for I/O extension modules.....	67
6.6	Modbus memory map.....	68
6.7	Error codes and formats for analog input and output values	83
6.8	Radioline function blocks.....	84
7	Description of I/O extension modules	87
7.1	RAD-AI4-IFS - analog extension module with four inputs	87
7.2	RAD-PT100-4-IFS - extension module with four temperature inputs	91
7.3	RAD-AO4-IFS - analog extension module with four outputs	98
7.4	RAD-DI4-IFS - digital extension module with four inputs	102
7.5	RAD-DI8-IFS - digital extension module with eight inputs.....	106
7.6	RAD-DOR4-IFS - digital extension module with four outputs.....	111
7.7	RAD-DO8-IFS - digital extension module with eight outputs.....	115
7.8	RAD-DAIO6-IFS - analog/digital extension module with six channels	120
8	Planning wireless systems	125
8.1	Delay time	125
8.2	Pulse transmission	127
8.3	Trusted Wireless 2.0.....	127
8.4	RF bands.....	131
8.5	Planning wireless paths	132
8.6	Practical test.....	132
8.7	Selecting antenna cables and antennas	133
8.8	Installing antennas.....	134
8.9	Level and attenuation of wireless modules and accessories	137
8.10	Free space attenuation.....	139
8.11	Propagation of radio waves	141
8.12	Fresnel zone.....	144
8.13	Range.....	146
8.14	Equivalent isotropically radiated power (EIRP).....	147
8.15	System calculation in free space	148

Table of contents

8.16	Practical examples	149
9	Detecting and removing errors	151
9.1	Loopback test during serial data transmission	157
10	Technical data for the wireless modules	159
A	Technical appendix.....	171
A 1	Typical combinations of antennas and adapter cables	171
A 2	Control box for wireless systems	184
B	Appendixes.....	185
B 1	List of figures	185
B 2	List of tables	189
B 3	Index.....	191

RAD-...-IFS

1 For your safety

Read this user manual carefully and keep it for future reference. The screenshots shown in this user manual may differ from your software version.

1.1 Marking of warning notes



This symbol indicates hazards that could lead to personal injury.

There are three signal words indicating the severity of a potential injury.

DANGER

Indicates a hazard with a high risk level. If this hazardous situation is not avoided, it will result in death or serious injury.

WARNING

Indicates a hazard with a medium risk level. If this hazardous situation is not avoided, it could result in death or serious injury.

CAUTION

Indicates a hazard with a low risk level. If this hazardous situation is not avoided, it could result in minor or moderate injury.



This symbol together with the **NOTE** signal word warns the reader of actions that might cause property damage or a malfunction.



Here you will find additional information or detailed sources of information.

1.2 Qualification of users

The use of products described in this manual is oriented exclusively to electrically skilled persons or persons instructed by them. The users must be familiar with the relevant safety concepts of automation technology as well as applicable standards and other regulations.

1.3 Field of application of the product

1.3.1 Intended use

The devices are designed for use in industrial environments.

The Radioline wireless system is a Class A item of equipment and may cause radio interference in residential areas. In this case, the operator may be required to implement appropriate measures and to pay the costs incurred as a result.

Operation of the wireless system is only permitted if accessories available from Phoenix Contact are used. The use of other accessory components could invalidate the operating license. You can find the approved accessories for this wireless system listed with the product at phoenixcontact.net/products.

1.3.2 RAD-2400-IFS wireless module



For the country registrations, please visit phoenixcontact.net/product/2901541.

Please note that, in combination with antennas, the maximum permissible transmission power may be exceeded. In this case, set the transmission power via the software (see "Transmission power" on page 39).

Install the wireless module at least 1 m away from other devices using the 2.4 GHz frequency band (e.g., WLAN, Bluetooth, microwave ovens). Otherwise, both the link quality and the data transmission speed will be reduced.

1.3.3 RAD-868-IFS wireless module



The RAD-868-IFS wireless module is only approved for use in Europe and South Africa.

1.3.4 RAD-2400-IFS-JP wireless module



The RAD-2400-IFS-JP wireless module is only approved for use in Japan.

The RAD-2400-IFS-JP wireless module does **not** have ATEX approval. It is **not** suitable for use in potentially explosive areas. Only install the wireless module in the safe area.

Japanese Radio Law and Japanese Telecommunications Business Law Compliance

The device is granted pursuant to the Japanese Radio Law (電波法) and the Japanese Telecommunications Business Law (電気通信事業法).

This device should not be modified (otherwise the granted designation number will become invalid).



202-LSE100

Install the wireless module at least 1 m away from other devices using the 2.4 GHz frequency band (e.g., WLAN, Bluetooth, microwave ovens). Otherwise, both the link quality and the data transmission speed will be reduced.

1.3.5 Product changes

Modifications to hardware and firmware of the device are not permitted.

Incorrect operation or modifications to the device can endanger your safety or damage the device. Do not repair the device yourself. If the device is defective, please contact Phoenix Contact.

1.4 Installation notes



WARNING: Risk of electric shock

During operation, certain parts of the devices may carry hazardous voltages. Disregarding this warning may result in serious personal injury and/or damage to equipment.

- Provide a switch/circuit breaker close to the device, which is labeled as the disconnect device for this device or the entire control cabinet.
- Provide overcurrent protection ($I \leq 6 \text{ A}$) in the installation.
- Disconnect the device from all power sources during maintenance work and configuration (for SELV or PELV circuits the device can remain connected).
- The housing of the device provides basic insulation against the neighboring devices for 300 Vrms. If several devices are installed next to each other, this must be taken into consideration and additional insulation may have to be installed. If the neighboring device is equipped with basic insulation, no additional insulation is required.

- **RAD-2400-IFS and RAD-868-IFS only:** Phoenix Contact hereby declares that this wireless system complies with the basic requirements and other relevant regulations specified in Directive 2014/53/EC.
- **RAD-2400-IFS and RAD-868-IFS only:** The category 3 device is suitable for installation in Zone 2 potentially explosive areas. It meets the requirements of EN 60079-0:2012+A11:2013 and EN 60079-15:2010.
- Installation, operation, and maintenance may only be carried out by qualified electricians. Follow the installation instructions as described.
- When installing and operating the device, the applicable regulations and safety directives (including national safety directives), as well as general regulations applicable to the technology, must be observed. The technical data is provided in the packing slip and on the certificates (conformity assessment, additional approvals where applicable).
- Do not open or modify the device. Do not repair the device yourself; replace it with an equivalent device instead. Repairs may only be carried out by the manufacturer. The manufacturer is not liable for damage resulting from noncompliance.
- The IP20 degree of protection (IEC 60529/EN 60529) of the device is intended for use in a clean and dry environment. Do not subject the device to mechanical and/or thermal loads that exceed the specified limits.
- To protect the device against mechanical or electrical damage, install it in suitable housing with an appropriate degree of protection according to IEC 60529.
- The device complies with the EMC regulations for industrial areas (EMC class A). When used in residential areas, the device may cause radio interference.
- Only specified devices from Phoenix Contact may be connected to the 12-pos. S-PORT interface.
- This device is not designed for use in atmospheres with a risk of dust explosions.
- If dust is present, the device must be installed in suitable approved housing, taking the surface temperature of the housing into consideration.

1.5 Installation in Zone 2

**WARNING: Explosion hazard when used in potentially explosive areas**

Make sure that the following notes and instructions are observed.

The RAD-2400-IFS-JP wireless module does **not** have ATEX approval. It is **not** suitable for use in potentially explosive areas. Only install this wireless module in the safe area.

- Observe the specified conditions for use in potentially explosive areas! Install the device in suitable approved housing (with at least IP54 degree of protection) that meets the requirements of EN 60079-15. Also observe the requirements of EN 60079-14.
- Only connect devices to the supply and signal circuits in Zone 2 that are suitable for operation in Ex Zone 2 and for the conditions at the installation location.
- In potentially explosive areas, only snap the device on or off the DIN rail connector and connect/disconnect cables when the power is disconnected.
- The switches of the device that can be accessed may only be actuated when the power supply to the device is disconnected.
- The device has to be stopped and immediately removed from the Ex area if it is damaged, was subjected to an impermissible load, stored incorrectly, or if it malfunctions.
- Ensure that the radiated wireless power is neither bundled (focused) by the antenna itself nor by any inserts in the environment of the antenna, and that it cannot enter neighboring Zones 1 or 0. Please refer to the technical data for the transmission power.
- The HF cable to the antenna must be suitable for the ambient conditions. Install the cable so that it is protected against mechanical damage, corrosion, chemical stress, and negative effects from heat or UV radiation. The same applies to the antenna which is connected to the cable and which functions as a cable termination.
- The antenna must meet the requirements of EN 60079-0 with regard to housing and electrostatic charge. Otherwise install the antenna in housing that meets the requirements of EN 60079-0 and EN 60079-15 and has at least IP54 degree of protection (EN 60529).

Notes for antennas

- Only use antennas approved for the Ex area (see Section “Accessories” on page 159).
- The intrinsically safe antennas support universal communication in various HF areas. The antennas are intended for use in potentially explosive areas that require 1G equipment. Connection is via antenna barriers (Order No. 2702198) with separate approval as intrinsically safe equipment.
- Observe the safety notes in the documentation for the respective antenna.

1.6 Notes for individual I/O extension modules

For RAD-DI4-IFS, RAD-DOR4-IFS, RAD-DAIO6-IFS



WARNING: Risk of electric shock

Use the same phase for digital inputs and outputs. The isolating voltage between the individual channels must not exceed 300 V.

For RAD-AO4-IFS



Use either the current or voltage output at every analog channel.

1.7 UL notes (RAD-2400-IFS and I/O extension modules only)

For RAD-2400-IFS wireless module

INDUSTRIAL CONTROL EQUIPMENT FOR HAZARDOUS LOCATIONS 45FP

- A This equipment is suitable for use in Class I, Zone 2, IIC T4 and Class I, Division 2, Groups A, B, C, D T4A hazardous locations or non-hazardous locations only.
- B WARNING - EXPLOSION HAZARD - DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NON-HAZARDOUS.
- C WARNING - EXPLOSION HAZARD - SUBSTITUTION OF COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS 1, DIVISION 2.
- D These devices are open-type devices that are to be installed in an enclosure suitable for the environment that is only accessible with the use of a tool.
- E WARNING - Exposure to some chemicals may degrade the sealing properties of materials used in relays within this device.
- F WARNING - EXPLOSION HAZARD - S-PORT IS FOR MAINTENANCE AND PROGRAMMING ONLY AND SHOULD ONLY BE USED WHEN THE AREA IS KNOWN TO BE NON-HAZARDOUS.

For the I/O extension modules

INDUSTRIAL CONTROL EQUIPMENT FOR HAZARDOUS LOCATIONS 45FP

- A This equipment is suitable for use in Class I, Zone 2, IIC T4 and Class I, Division 2, Groups A, B, C, D T4A hazardous locations or non-hazardous locations only.
- B WARNING - EXPLOSION HAZARD - DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NON-HAZARDOUS.
- C WARNING - EXPLOSION HAZARD - SUBSTITUTION OF COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS 1, DIVISION 2.
- D These devices are open-type devices that are to be installed in an enclosure suitable for the environment that is only accessible with the use of a tool.
- E WARNING - Exposure to some chemicals may degrade the sealing properties of materials used in relays within this device.

1.8 FCC, Industry Canada, IFT Mexico (RAD-2400-IFS only)

FCC

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

This device may not cause harmful interference. This device must accept any interference received, including interference that may cause undesired operation.

**NOTE: Interference**

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case, the user will be required to correct the interference at his own expense.

Any changes or modifications not explicitly approved by Phoenix Contact could cause the device to cease to comply with FCC rules Part 15, and thus void the user's authority to operate the equipment.

Radio frequency exposure:

The device contains a radio transmitter and receiver. During communication the device receives and transmits radio frequency (RF) electromagnetic fields (microwaves) in the frequency range of 2400 MHz to 2483.5 MHz.

RF Exposure Statement:

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device contains:

FCC ID: YG3RAD2400A

Industry Canada (IC)

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device has been designed to operate with an antenna having a maximum gain of 9 dBi. Having a higher gain is strictly prohibited per regulations of Industry Canada. The required antenna impedance is 50 ohms.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (EIRP) is not more than that permitted for successful communication.

This device contains:

IC certificate: 4720B-RAD2400A

RAD-...-IFS

IFT, Instituto Federal de Telecomunicaciones México

The operation of this equipment is subject to the following two conditions: (1) it is possible that this equipment or device may not cause harmful interference, and (2) this equipment or device must accept any interference including interference that may cause its undesired operation.

This equipment has been designed to operate with antennas listed below and for an antenna's maximum gain of 19 dBi. Use of this equipment with antennas not included in this list or having a higher gain than 19 dBi is prohibited. The required antenna impedance is 50 ohms.

Certificate number: IFT RCPHRA17-1112

- Antennas: see table "2.4 GHz antennas"

2 Brief description

Wireless communication is based on Trusted Wireless 2.0 technology. The wireless modules meet the high requirements for interference-free data transmission through, among other things, the use of the frequency-hopping spread spectrum (FHSS) method and 128-bit data encryption (AES).

Wireless modules

RAD-2400-IFS, RAD-2400-IFS-JP
RAD-868-IFS

Frequency band

License-free 2.4 GHz ISM band
868 MHz ISM band, license-free in Europe

2.1 Wireless modules

In addition to an RS-232 and RS-485 2-wire interface, the wireless modules support the option of directly connecting up to 32 I/O extension modules in the station structure via the DIN rail connector.

Addressing of the wireless modules and I/O mapping of the extension modules is carried out quickly and easily by means of the thumbwheel on the front. The yellow thumbwheel on the wireless module is used to set the RAD ID. The white thumbwheel on the extension modules is used to set the I/O MAP address. Programming knowledge is not required. You can easily start up the wireless network without the need for software.

In addition, the wireless network can be extended with up to 98 RS-485 stations (RAD-RS485-IFS, Order No. 2702184). I/O data can therefore be distributed across various media using the thumbwheel.

The PSI-CONF configuration and diagnostic software for special functions and diagnostic options of the wireless module is available free of charge.

Features

- Flexible network applications:
I/O data, serial data, PLC / Modbus/RTU mode, dual mode
- Adjustable data rates for the wireless interface
- Easy point-to-point or network structures (star, mesh)
- Yellow thumbwheel for unique addressing of wireless modules in the wireless network
- Integrated RS-232 and RS-485 interfaces
- Can be extended with up to 32 I/O modules per station via DIN rail connector (hot-swap capability)
- 128-bit AES data encryption and authentication
- Unique network addressing via plug-in configuration stick (RAD-CONF) for secure, parallel operation of multiple networks with different RF bands
- Data rates and ranges can be configured using the PSI-CONF software
- International approvals
- Installation in Ex Zone 2 (RAD-2400-IFS and RAD-868-IFS only)
- Can be combined with RS-485 stations



The **RAD-RS485-IFS** RS-485 front module is not described in this user manual. For additional information, visit phoenixcontact.com/product/2702184.

2.2 Firmware versions

Make sure that all the wireless modules in a network have the same firmware version. Where possible, always use the latest firmware.




You can download the latest firmware free of charge at phoenixcontact.net/products.

Table 2-1 Firmware versions

Function	As of firmware version...	
	RAD-2400-IFS	RAD-868-IFS
Initial version	1.00	1.00
PLC / Modbus/RTU mode	1.30	1.00
Support for RAD-DI8-IFS and RAD-DO8-IFS I/O extension modules	1.40	1.00
Support for RAD-PT100-4-IFS	1.50	1.00
Support for ETSI EN 300328: V1.8.1	1.60	-
Support for RAD-RS485-IFS RS-485 front module	1.70	1.70
PLC / Modbus/RTU dual mode	1.80	1.80

2.3 I/O extension modules

Various I/O extension modules are available for setting up the wireless system quickly and easily. You can therefore adapt the number and type of signals to the respective application.



Features

- White thumbwheel for easy and tool-free assignment of device pairs (I/O mapping)
- Modular structure via DIN rail connector (hot-swap capability)
- Depending on the module: channel-to-channel electrical isolation
- Depending on the module: analog inputs or outputs (0/4 mA ... 20 mA / 16-bit resolution / <0.1% accuracy)
- Depending on the module: digital wide-range inputs or outputs (0 V ... 250 V AC/DC)
- DIP switches for HOLD/RESET behavior of outputs
- Loop power function for passive sensors











For a detailed description of the available I/O extension modules, refer to the pages listed below:

Table 2-2 Overview of I/O extension modules

Module type		Designation	Order No.	From page
Analog	4 analog inputs	RAD-AI4-IFS	2901537	87
	4 Pt 100 inputs	RAD-PT100-4-IFS	2904035	91
	4 analog outputs	RAD-AO4-IFS	2901538	98
Digital	4 digital inputs	RAD-DI4-IFS	2901535	102
	8 digital inputs or 2 pulse inputs	RAD-DI8-IFS	2901539	106
	4 digital relay outputs	RAD-DOR4-IFS	2901536	111
	8 digital transistor outputs	RAD-DO8-IFS	2902811	106
Analog/digital	1 analog input/output, 2 digital wide-range inputs/outputs	RAD-DAIO6-IFS	2901533	121

2.4 Application examples

The Radioline system offers a wide range of application options.

Application overview for the Radioline system	I/O to I/O	Serial to Serial	I/O to Serial	
	I/O data mode	Serial data mode	PLC/Modbus RTU mode	PLC/Modbus RTU Dual mode
Communication between wireless stations		* 		
Combined communication between wireless- and RS-485 stations				
Communication between RS-485 stations				
Explanation  Modbus Master  Modbus Slave  Radioline wireless module  Radioline wireless station with I/Os  Radioline RS-485 station with I/Os * In addition to Modbus, more serial protocols are supported				

3 Installation

3.1 Wireless module structure




Figure 3-1 Wireless module structure

Item	Terminal block	Designation
1		RSMA antenna connection (socket)
2	2.1/2.2	RSSI test output (0 V ... 3 V DC) for evaluation of the wireless signal strength
3	1.1/1.2	Device supply (+24 V DC, GND)
4		S-PORT (12-pos. programming interface)
5		Yellow thumbwheel for setting the RAD ID
6		SET button
7		Connection option for DIN rail connector
8		DIN rail
9		Metal foot catch for DIN rail fixing
10	4.1/4.2	Connection terminal blocks for RS-485 interface
11	5.1/5.2/5.3	Connection terminal blocks for RS-232 interface
12	6.1/6.2/6.3	Relay output with floating changeover contact (RF link relay)
13		Status LED (RX/TX) for RS-232/485 serial interface
14		LED bar graph for displaying the wireless signal strength
15		ERR status LED, red (communication error)
16		DAT status LED, green (bus communication)
17		PWR status LED, green (supply voltage)

3.2 Basic circuit diagram




Figure 3-2 Basic circuit diagram for the wireless module

3.3 Mounting and removal

You can connect up to 32 different I/O extension modules to each wireless module via the DIN rail connector. Data is transmitted and power is supplied to the I/O extension modules via the bus foot.

When using the device in a connection station, use the supplied 17.5 mm DIN rail connector. Only use the DIN rail connector in conjunction with 24 V DC devices.



- Mount the wireless module to the left and the I/O extension modules **only to the right** of the wireless module.
- The individual extension modules can be arranged in any order.
- **2.4 GHz wireless modules only:** install the wireless module at least 1 m away from other devices using the 2.4 GHz frequency band (e.g., WLAN, Bluetooth, microwave ovens). Otherwise, both the link quality and the data transmission speed will be reduced.



Figure 3-3 Radioline connection station with up to 32 I/O extension modules




Figure 3-4 Mounting and removal

Mounting a connection station with DIN rail connectors:

- To form a connection station, connect the DIN rail connectors together.
- Push the connected DIN rail connectors onto the DIN rail.
- Place the device onto the DIN rail from above (see Figure 3-4, D). Make sure that the device and DIN rail connector are aligned correctly.
- Holding the device by the housing cover, carefully push the device towards the mounting surface so that the device bus connector is securely fixed onto the DIN rail connector.
- Once the snap-on foot snaps onto the DIN rail, check that it is fixed securely. The device is only mechanically secured via the DIN rail.
- Connect the desired number of I/O extension modules to the wireless module via the DIN rail connector.
- In order to meet the requirements for the protection class, install the device in suitable housing.
- During startup, check that the device is operating, wired, and marked correctly.
- A connection between two DIN rail connectors can be established using MINI COMBICON connectors:
 - MC 1,5/5-ST-3,81 (socket, 1803604);
 - IMC 1,5/5-ST-3,81 (pin, 1857919)



Device replacement is also possible during operation when outside the Ex area.

Removal

- Use a suitable screwdriver to release the locking mechanism on the snap-on foot of the device (see Figure 3-4, E).
- Hold onto the device by the housing cover and carefully tilt it upwards.
- Carefully lift the device off the DIN rail connector and the DIN rail.

3.4 Connecting the cables




Figure 3-5 Connecting cables



For easy installation, it is also possible to pull the screw terminal block out of the device and to re-insert it after having connected the cables.

- Fit ferrules to the litz wires. Permissible cable cross section: $0.2 \text{ mm}^2 \dots 2.5 \text{ mm}^2$
- Insert the wire with ferrule into the corresponding connection terminal block.
- Use a screwdriver to tighten the screw in the opening above the connection terminal block. Tightening torque: 0.6 Nm .

3.5 Connecting the power supply

Via screw terminal blocks

Connect a DC voltage source (19.2 V ... 30.5 V DC) to the wireless module. The nominal voltage is 24 V DC. Supply voltage to the device via terminal blocks 1.1 (24 V) and 1.2 (0 V). In the case of a connection station, it is sufficient to supply the first device in the group.




Figure 3-6 Connecting the power supply

In order to prevent damage to the wireless module, we recommend installing a surge protective device. Make sure the wiring between the surge protective device and the wireless module is as short as possible. Please also observe the manufacturer's specifications.

With a system power supply via the bus foot

If DIN rail connectors are used, you can use the MINI-SYS-PS 100-240AC/24DC/1.5 system power supply (Order No. 2866983). Connect the system power supply using two DIN rail connectors to the left of the device.




Figure 3-7 Supply via system power supply



- Parallel supply via the screw terminal blocks and with a system power supply via the bus foot is **not** possible.
- For redundant supply, you can connect a second MINI-SYS-PS 100-240AC/24DC/1.5 system power supply.

3.6 Serial interfaces

The wireless modules have one RS-232 interface and one RS-485 2-wire interface. Connect the I/O device to the wireless module via the corresponding interface.



- Activate and configure the RS-232 or RS-485 interface using the PSI-CONF software (from page 38 onwards).
- You can only use one interface per wireless module. Parallel operation of both interfaces is not possible.

3.6.1 Shielding of the RS-485 bus cable

- Connect the overall shielding braid of the RS-485 bus cable correctly via an external shield connection clamp (e.g., SKS 8-SNS35, Order No. 3062786).



NOTE: Damage to the interface

If the shielding has been connected incorrectly, permanent, external disturbing pulses may damage the interface.

Observe the polarity of the RS-485 2-wire cable and make sure that the shielding is connected correctly.

Choose the type of the overall shielding braid according to the expected interference:

- Firstly, connect the shield on one side. This suppresses electrical fields.
- To suppress disturbances caused by alternating magnetic fields, connect the shield on both sides. When doing so, ground loops must be taken into consideration. Galvanic disturbances along the reference potential interfere with the useful signal, and the shielding effect is reduced.
- If several devices are connected to a single bus, the shield must be connected to each device (e.g., by means of clamps).
- Connect the bus shield to a central PE point using short, low-impedance connections with a large surface area (e.g., by means of shield connection clamps).

3.6.2 Terminating the RS-485 bus cable

The wireless modules are operated on a 2-wire bus cable. RS-485 bus connections must be terminated at both ends with a 390/150/390 Ω termination network.

- Depending on the position of the device on the RS-485 bus cable, activate or deactivate the termination network.

Table 3-1 DIP switches 1 and 2: termination network

Device position	Termination network	DIP switch	
		1	2
RS-485 termination device	On	ON	ON
RS-485 device	Off	OFF	OFF




Figure 3-8 DIP switch

3.6.3 RS-485 pin assignment

In RS-485 mode, you can create a network with several I/O devices. Use a twisted pair bus cable to connect the I/O devices. Fit this bus cable with a termination network at the two furthest points.

- Connect the single wires of the data cable to the COMBICON plug-in screw terminal block (Figure 3-1, item 10).
- Make sure the signal assignment is correct.




Figure 3-9 RS-485 interface pin assignment

3.6.4 RS-232 pin assignment

In RS-232 mode, point-to-point connections can be established.



- The RS-232 interface of the wireless module is of DTE type (Data Terminal Equipment). This means that terminal point 5.2 (Tx) is always used to transmit and terminal point 5.1 (Rx) is always used to receive.
- Only connect the wireless module to devices which meet the requirements of EN 60950.

According to the standard, you can connect a type DCE device (Data Communication Equipment) to the RS-232 interface using a 1:1 cable (Figure 3-10). It is also possible to connect a DTE device using a crossed cable (Figure 3-11).




Figure 3-10 RS-232 interface pin assignment (DTE - DCE)




Figure 3-11 RS-232 interface pin assignment (DTE - DTE)

If you are not sure whether the device to be connected is of DTE or DCE type, you can also measure the voltage. Measure the voltage between Tx and GND in the idle state:

- Voltage of approximately -5 V: DTE device
- Voltage of approximately 0 V: DCE device

3.7 Connecting the antenna

The wireless module has an RSMA antenna socket for an external antenna. Various installation examples can be found under “Typical combinations of antennas and adapter cables” on page 171.



- Install the antenna outside the control cabinet or building.
- Please also observe the installation instructions for the antenna as well as Section “For your safety” on page 7.
- For information on the transmission power, refer to “Transmission power” on page 39.




Figure 3-12 Connecting the antenna

RAD-...-IFS

4 Configuration and startup

4.1 Default settings of the wireless module

All wireless modules are configured to the same default settings when delivered or following a reset at a later stage.

Table 4-1 Default settings of the wireless module

Parameter	Setting		
	RAD-2400-IFS	RAD-2400-IFS-JP	RAD-868-IFS
Operating mode	I/O data (wire in/wire out)		
Wireless interface			
Net ID	127		
RF band	4		2
Encryption	Off		
Network structure	Mesh		
Device type	Repeater/slave		
Blacklisting	WLAN channel 6		-
Data rate of the wireless interface	125 kbps		9.6 kbps
Receive preamplifier	Enabled		-
Transmission power	18 dBm	20 dBm	27 dBm



By default upon delivery, the receive preamplifier is activated. The transmission power is set so that the devices can cover the greatest possible distances. Therefore, if the devices are operated directly next to one another the receiver may become overloaded. In this case, remove the antennas, increase the distance between the devices and antennas or reduce the transmission power using the PSI-CONF software.

4.1.1 Resetting to the default settings

The device can be reset to the default settings either manually or using the PSI-CONF software.

Manual reset

- Disconnect the device from the supply voltage.
- Hold down the SET button located on the front of the device and switch the supply voltage on.
- Hold down the SET button until the DAT LED flashes.

Reset via PSI-CONF software

- In the device selection area, select “Wireless, RAD-2400-IFS” or “Wireless, RAD-868-IFS”.
- Select “Local Device”.
- Select “Set device to factory default configuration”.

4.1.2 Firmware update



You can download the latest firmware free of charge at phoenixcontact.net/products.

You can update the firmware using the PSI-CONF software. The device is reset to the default settings after a firmware update.

- In the device selection area, select “Wireless, RAD-2400-IFS” or “Wireless, RAD-868-IFS”.
- Select “Update firmware”.

4.2 Operating mode of the wireless module

The Radioline wireless system offers four different options for signal and data transmission:

Table 4-2 Operating mode

Operating mode	Configuration
I/O data mode	Default setting, configuration only possible via thumbwheel
Serial data mode	Configuration via PSI-CONF software
PLC / Modbus/RTU mode	
PLC / Modbus/RTU dual mode	

If the wireless system is operated in an environment where other networks are also present, e.g., additional Radioline networks, then a configuration stick can be used (see “Configuration using the configuration stick” on page 35). Extended settings of the wireless modules can also be configured using the PSI-CONF software (from page 38 onwards).

4.2.1 I/O data mode




Figure 4-1 I/O data mode

By default upon delivery, all wireless modules are in I/O data mode. For simple I/O-to-I/O applications with extension modules, you can easily set the addresses using the thumbwheel. You can therefore establish a wireless connection to other wireless modules without laborious programming (see “Setting the address of the wireless module using the thumbwheel” on page 35 and “Setting the address of the extension modules via the thumbwheel” on page 53).

RS-485 front module

The **RAD-RS485-IFS** RS-485 front module for I/O extension modules allows Radioline stations to be operated via a 2-wire RS-485 bus system. The front module can be extended with up to 32 I/O extension modules via the DIN rail connector.

You can connect Radioline RS-485 stations to a Radioline master wireless module and thereby extend the wireless network. All devices in the wireless network and in the RS-485 network form one system. All stations are addressed uniquely using the yellow thumbwheel.

The I/O signals can be distributed easily between all the stations, regardless of the medium used.




Figure 4-2 I/O-to-I/O, wireless, and RS-485



The **RAD-RS485-IFS** RS-485 front module is not described in this user manual. For additional information, visit phoenixcontact.com/product/2702184.

4.2.2 Serial data mode




Figure 4-3 Serial data mode

In serial data mode, multiple controllers or serial I/O devices are networked quickly and easily using wireless technology. In this way, serial RS-232 or RS-485 cables can be replaced. You need to configure each wireless module using the PSI-CONF software (from page 38 onwards).

4.2.3 PLC / Modbus/RTU mode




Figure 4-4 PLC / Modbus/RTU mode

You can connect the I/O extension modules to the controller directly via the integrated RS-232 and RS-485 interface by means of wireless communication. In PLC / Modbus/RTU mode, the master wireless module (RAD ID = 01) operates as a Modbus slave. The master wireless module has its own Modbus address.

You can connect extension modules to each wireless module in the network. The I/O data of the extension module is stored in the internal Modbus memory map of the master wireless module. In addition, the diagnostic data from all wireless devices is stored here.

You need to configure each wireless module using the PSI-CONF software (from page 38 onwards).

4.2.4 PLC / Modbus/RTU dual mode




Figure 4-5 PLC / Modbus/RTU dual mode

Dual mode combines PLC / Modbus/RTU mode and serial data mode. You can connect Radioline extension modules to the controller directly via the integrated RS-232 and RS-485 interface by means of wireless communication. You can also connect additional Modbus/RTU slaves in parallel.

You need to configure each wireless module using the PSI-CONF software (from page 38 onwards).

4.3 Setting the address of the wireless module using the thumbwheel

- Start by setting the desired station address with the yellow thumbwheel on the wireless module. There must be one master (RAD ID = 01) and at least one repeater/slave (RAD ID = 02 ... 99) in a network.



- Each address in a network must be unique. If two wireless modules in a network have the same address, the network will not function correctly.
- Setting the address via the thumbwheel has priority over setting the address via the PSI-CONF software.
- After making any change to the module address, press the SET button for one second to apply the setting.

The following settings can be made using the yellow thumbwheel:

Table 4-3 Yellow thumbwheel setting

Thumbwheel	Description	
01	Master address	For networks with repeaters (mesh networks)
02 ... 99	Repeater/slave address	
*1	Master address	For networks without repeaters (star networks)
*2 ... *9	Slave address	
00	Not permitted	
**	Only for 2.4 GHz wireless modules: addressing the wireless modules using the PSI-CONF software (address 1 ... 250)	

4.4 Configuration using the configuration stick

By default upon delivery, all the wireless modules have the same network ID and the same RF band. Using a configuration stick (CONFSTICK), you can configure a unique and secure network without the need for software.

The configuration stick is used as a network key. Its network address (network ID) is unique and cannot be assigned via the PSI-CONF software. Only wireless modules with the same network ID can connect to one another.

You must configure each individual network device. To this end, you only need one configuration stick for all wireless modules in the network. After configuration, you can remove the stick from the wireless module.

In addition, the configuration stick contains a preset frequency band (RF band). An RF band is a group of frequencies made up of individual frequencies from the entire frequency band. Different RF bands use different frequencies.

If you operate several Radioline wireless systems in parallel, you should select different RF bands.



2.4 GHz wireless modules: you can also set different RF bands from 1 ... 8 and network IDs from 1 ... 127 using the PSI-CONF software (see page 39).

868 MHz wireless modules: for additional information on the various RF bands in 868 MHz wireless systems, refer to "RF bands" on page 131.

RAD-...-IFS

Different sticks are available for easy configuration without the need for software.

For 2.4 GHz wireless modules:

- RAD-CONF-RF3 for RF band 3 (Order No. 2902814, yellow)
- RAD-CONF-RF5 for RF band 5 (Order No. 2902815, green)
- RAD-CONF-RF7 for RF band 7 (Order No. 2902816, blue)

For 868 MHz wireless modules:

- RAD-868-CONF-RF1 for RF band 1 (Order No. 2702197, red)



WARNING: Explosion hazard when used in potentially explosive areas

Do **not** insert or remove the configuration stick in a potentially explosive atmosphere.




Figure 4-6 Configuration using the configuration stick

Item	Description
1	RAD-CONF-RF
2	Status LEDs
3	SET button

- Carefully insert the configuration stick with the 12-pos. IFS connector into the S-PORT of the wireless module.
- Press the SET button on the wireless module for one second. Parameter read-in is started. Read-in has been completed when the DAT LED lights up once. The new parameters are activated.
- Remove the configuration stick from the wireless module.
- Repeat this process for **each** individual wireless module in the network.

4.5 Copying the device settings via a memory stick

In order to transfer the configuration of a wireless module to another wireless module, you can save the configuration to a memory stick (RAD-MEMORY, Order No. 2902828, white).



WARNING: Explosion hazard when used in potentially explosive areas

Do **not** insert or remove the memory stick in a potentially explosive atmosphere.



- Pay attention to the firmware version of the wireless modules before using the memory stick. In order to ensure that a wireless module is capable of reading the memory stick, it must have the same or later firmware version than the wireless module of which the configuration file was copied. Wireless modules with an earlier firmware version are not able to read the memory stick.
- If an error is detected while saving or checking the data, the DAT and ERR LEDs flash simultaneously.

Common network parameters

- Operating mode
- Network ID
- RF band
- Data rate of the wireless interface
- Encryption
- Network type

Individual device parameters

- Station name
- RAD ID
- Transmission power
- List of permitted connections
- Receive preamplifier ON/OFF
- Serial interface parameters

4.5.1 Saving parameters from the wireless module to the memory stick

Copying common network parameters and individual device parameters to the memory stick:

- Press and hold down the SET button on the wireless module for at least six seconds.
- The four RSSI bar graph LEDs start a running light from bottom to top.
- Insert the memory stick in the S-PORT of the wireless module. Parameter copying is started automatically.
- Wait until the running light stops. The write process has been completed.
- Remove the memory stick from the wireless module.

4.5.2 Reading the memory stick

Reading common network parameters via the memory stick

- Insert the memory stick in the S-PORT of the wireless module.
- Press and hold down the SET button on the wireless module for at least **one** second. Parameter read-in is started. Read-in has been completed when the DAT LED lights up once. The new parameters are activated.
- Remove the memory stick from the wireless module.

Reading common network parameters and individual device parameters via the memory stick

This function enables all common network parameters and individual device parameters to be read into the wireless module. A full copy of devices can be created, e.g., as a backup copy.

- Insert the memory stick in the S-PORT of the wireless module.
- Press and hold down the SET button on the wireless module for at least **six** seconds. Parameter read-in is started, the DAT LED flashes.
- The read-in process has been completed once the DAT LED stops flashing. The new parameters are activated.
- Remove the memory stick from the wireless module.

4.6 Configuration via the PSI-CONF software

You can make special settings using the PSI-CONF configuration and diagnostic software. The software can be downloaded at phoenixcontact.net/products. A PC with Windows operating system is required in order to use the software. Use the RAD-CABLE-USB cable (Order No. 2903447) for configuration and diagnostics.



WARNING: Explosion hazard when used in potentially explosive areas

The USB cable must **not** be used in potentially explosive areas.



For additional information on the USB cable, please refer to the PACKB.RAD-CABLE-USB packing slip. The latest documentation can be downloaded via the product at phoenixcontact.net/product/2903447.

- Install the software and the USB driver for the RAD-CABLE-USB cable. Follow the software wizard.

4.6.1 Extended configuration, individual settings

After reading an existing network project or creating a new project, the network settings can be modified under “Individual Settings”. Here, the wireless network can be optimized and adapted to your specific requirements. When you move the mouse over the individual network parameters, you will see a short description under “Help”.



If you operate several wireless systems in parallel at a short distance from each other: in order to separate the wireless systems, you should select various RF bands and network IDs. These parameters can be set via the PSI-CONF software or by using a configuration stick (see “Configuration using the configuration stick” on page 35).




Figure 4-7 PSI-CONF software: “Network Settings”

4.6.2 Transmission power

Observe the maximum permissible radiated transmission power at the antenna (EIRP, see Table 4-4 or Table 4-5). If necessary, reduce the device transmission power via the PSI-CONF software.

The transmission power can be calculated as follows:

Device transmission power + Antenna gain - Cable attenuation

4.6.3 Data transmission rate of the wireless interface

The range is an important parameter for industrial wireless applications, especially for outdoor applications. Even in cases where long ranges do not have to be covered, good receiver sensitivity enables transmission in harsh outdoor conditions, e.g., when there is no direct line of sight.

The receiver sensitivity determines the signal amplitude which can just about be received by the wireless module. The lower the data transmission rate of the wireless interface, the higher the receiver sensitivity and therefore the range.



Adjust the data transmission rate of the wireless interface to the respective application using the PSI-CONF software.

Default setting:

- 2.4 GHz wireless modules = 125 kbps
- 868 MHz wireless modules = 9.6 kbps

Table 4-4 Data transmission rate of the wireless interface, 2.4 GHz

Data transmission rate	Typical receiver sensitivity	EIRP (max. radiated power)	Potential distance with line of sight and 12 dB system reserve
250 kbps	-93 dBm	20 dBm (Europe: 19 dBm)	1000 m
125 kbps	-96 dBm	20 dBm (Europe: 18 dBm)	3000 m (Europe: 2000 m)
16 kbps	-106 dBm	20 dBm (Europe: 11 dBm)	5000 m (Europe: 3000 m)

Table 4-5 Data transmission rate of the wireless interface, 868 MHz

Data transmission rate	Typical receiver sensitivity	EIRP (max. radiated power)	Potential distance with line of sight and 12 dB system reserve
120 kbps	-103 dBm	27 dBm	10 km
60 kbps	-104 dBm		15 km
19.2 kbps	-111 dBm		18 km
9.6 kbps	-114 dBm		20 km
1.2 kbps	-122 dBm		25 km

You can cover distances in the kilometer range using the wireless module if the following conditions are met:

- Suitable gain antennas are used
- Line of sight
- Adherence to the Fresnel zone

If you reduce the data transmission rate, obstacles such as walls or trees can be penetrated much better. Please note, however, that the delay time increases when the data rate is reduced.

Configuration and startup




Figure 4-8 PSI-CONF software: “Wizard, Step 3”




Figure 4-9 PSI-CONF software: setting the data transmission rate

4.6.4 Device settings



By default upon delivery, the receive preamplifier is activated. The transmission power is set so that the devices can cover the greatest possible distances:

- RAD-2400-IFS: 18 dBm
- RAD-2400-IFS-JP: 20 dBm
- RAD-868-IFS: 27 dBm

Therefore, if the devices are operated directly next to one another the receiver may become overloaded. In this case, remove the antennas, increase the distance between the devices and antennas or reduce the transmission power using the PSI-CONF software.

You can assign a device name or set the transmission power under “Device Settings”. All device parameters are listed on the “Overview” tab.




Figure 4-10 PSI-CONF software: “Individual Settings, Overview”

Configuration and startup

Depending on the operating mode, you can configure the serial interface under “Individual Settings” on the “Serial Port” tab.

To activate the serial interface, select the “Serial data”, “PLC / Modbus/RTU mode” or dual mode network application under “Network Settings”.



You can only use one interface per wireless module. Parallel operation of both interfaces is not possible.




Figure 4-11 PSI-CONF software: “Individual Settings, Serial Port”

Under “Individual Settings” on the “Allowed Parents” tab, you can define the wireless modules to which a connection may be established. This setting is required, for example, when creating repeater chains. Repeater chains are used to circumvent obstacles or to set up redundant wireless paths by means of several repeaters.



The “Allowed Parents” tab is only available if the “Line/Mesh” network type has been selected.




Figure 4-12 PSI-CONF software: “Individual Settings, Allowed Parents”

4.7 Diagnostics on the wireless module

A total of nine LEDs on the wireless module indicate the operating states.




Figure 4-13 Diagnostic LEDs on the wireless module

PWR LED

The green PWR LED indicates the status of the supply voltage.

Off	No supply voltage
On	Supply voltage OK

DAT LED

The green DAT LED indicates the status of bus communication.

Off	No communication
Flashing	Configuration mode
On	Cyclic data communication

ERR LED

The red ERR LED indicates the error status.

Off	No error
Flashing	
Slow (1.4 Hz)	Wireless module in I/O data mode – Double assignment of I/O MAP address (e.g., two input modules with the same I/O MAP address) – Missing input module – Missing output module – RAD ID changed Wireless module in PLC / Modbus/RTU mode – Double assignment of I/O MAP address (e.g., two input modules with the same I/O MAP address) – RAD ID changed – No Modbus communication
Fast (2.8 Hz)	Wireless connection interrupted
On	Local bus error, e.g., input or output module not read

4.7.1 LED bar graph

The LED bar graph indicates the receive signal strength.

Table 4-6 LED bar graph

Bar graph	LEDs	Receive signal	RSSI voltage
	All LEDs light up	Connection with maximum receive signal	2.5 V ... 3 V
	One yellow and two green LEDs light up	Connection with very good receive signal	2 V ... 2.5 V
	One yellow and one green LED light up	Connection with good receive signal	1.5 V ... 2 V
	One yellow LED lights up	Connection with weak receive signal	1 V ... 1.5 V
	Off	Not connected, configuration mode or overload ¹	0 V

¹ By default upon delivery, the receive preamplifier is activated. The transmission power is set so that the devices can cover the greatest possible distances. Therefore, if the devices are operated directly next to one another the receiver may become overloaded. In this case, remove the antennas, increase the distance between the devices and antennas or reduce transmission power using the PSI-CONF software (from page 38 onwards).

RAD-...-IFS

Table 4-7 2.4 GHz RSSI voltage

	16k	125k	250k	RSSI voltage
LED 3	-70 dBm	-65 dBm	-60 dBm	$\geq 2.5 \text{ V}$
LED 2	-80 dBm	-75 dBm	-70 dBm	$\geq 2.0 \text{ V}$
LED 1	-90 dBm	-85 dBm	-80 dBm	$\geq 1.5 \text{ V}$
LINK LED	LINK	LINK	LINK	$\sim 1.0 \text{ V}$

Table 4-8 868 MHz RSSI voltage

	1.2k	9.6k	19.2k	60k	120k	RSSI voltage
LED 3	-90 dBm	-85 dBm	-80 dBm	-75 dBm	-70 dBm	$\geq 2.5 \text{ V}$
LED 2	-100 dBm	-95 dBm	-90 dBm	-85 dBm	-80 dBm	$\geq 2.0 \text{ V}$
LED 1	-110 dBm	-105 dBm	-100 dBm	-95 dBm	-90 dBm	$\geq 1.5 \text{ V}$
LINK LED	LINK	LINK	LINK	LINK	LINK	$\sim 1.0 \text{ V}$

LED bar graph - running light

The running light from bottom to top indicates:

- Firmware update or
- Wireless module in write mode for the memory stick

TX LED, transmit data

The green TX LED indicates communication on the RS-232/RS-485 interface. The wireless module is transmitting data.

As of firmware version 1.70: in I/O data mode, the TX LED on the master wireless module flashes (RAD ID = 01). This indicates that the master wireless module is continuously sending search requests to RS-485 stations.

RX LED, receive data

The green RX LED indicates communication on the RS-232/RS-485 interface. The wireless module is receiving data.

SET button

You can confirm a station change with the SET button, without performing a power up. Station changes include:

- Changing the RAD ID address of the wireless module
- Changing the I/O MAP address of the extension module
- Adding or removing an I/O extension module
- Using a configuration stick or memory stick

After making any change, press the SET button for at least one second to apply the settings. The DAT LED starts flashing. The read-in process has been completed once the DAT LED stops flashing.

RF link relay

The RF link relay in the wireless module diagnoses the state of the wireless connection. If the device is no longer receiving the data packets correctly, the relay drops out after a while. The relay picks up again automatically when the wireless connection is re-established. The relay has been designed as a changeover contact.



The RF link relay can be used as a fault message contact to indicate the failure of the wireless connection to the controller.

RSSI test socket

A voltage measuring device can be connected to the RSSI test socket (2.1/2.2) to measure the RSSI voltage from 0 V ... 3 V. You can use the table on page 46 to determine the received signal strength based on the measured voltage. However, please note the small voltage fluctuation due to multipath propagation.

The RSSI voltage depends on the data rate set for the wireless interface. The higher the RSSI voltage, the better the wireless connection.

For example, the RSSI voltage may be helpful when positioning and aligning the antenna. The recommended minimum signal strength is 1.5 V DC. This results in a power reserve of around 10 dB, which ensures communication even in unfavorable transmission conditions.

RSSI LED bar graph




Figure 4-14 Bar graph for point-to-point connection

In a point-to-point connection with just two wireless modules, the LED bar graph is active on both the master and the repeater/slave.




Figure 4-15 Bar graph for point-to-multipoint connection

In a wireless network with more than one repeater/slave, only the yellow LED on the master is permanently on. The signal strength in the master direction is displayed at the repeaters/slaves. The signal strength always relates to the directly connected, overlapping wireless module.

If several repeaters/slaves are connected to a master, the master should theoretically indicate the signal strength for several wireless modules. This is not possible for technical reasons, however. This is why only the yellow bar graph LED lights up for the master.

You can read the RSSI values via the serial interface of the master wireless module using Modbus/RTU commands (see Section "RSSI signal and error code registers" on page 82).

4.8 Diagnostics via PSI-CONF software

You can display all current device settings for the station under “Diagnostic” on the “Overview” tab.

- Select the desired station from the device list.




Figure 4-16 PSI-CONF software: “Diagnostic, Overview”



- The entire wireless network can be diagnosed using the master wireless module (RAD ID = 01).
- When operating the network in serial data mode, it may not be possible to diagnose all devices. In this case, stop the serial application in order to perform full diagnostics.
- For information on troubleshooting, please refer to Section “Detecting and removing errors” on page 151.

If an error occurs in the network, an error message is displayed under “Device Status”. If the error is no longer present, the error message is reset.

Possible error messages:

- Missing input module
- Missing output module
- Double assignment of I/O MAP address
- Error on IFS bus
- Wireless connection interrupted
- RAD ID changed
- Configuration stick has not yet been inserted

RAD-...-IFS

The “I/O Status” tab displays the status and the current values of the connected I/O extension modules.




Figure 4-17 PSI-CONF software: “Diagnostic, I/O Status”

The “Serial Port” tab displays the parameters currently set for the RS-232/RS-485 interface.




Figure 4-18 PSI-CONF software: “Diagnostic, Serial Port”

The “Network settings” tab displays the network parameters currently set as well as the settings for the configuration stick, if used.




Figure 4-19 PSI-CONF software: “Diagnostic, Network settings”

4.8.1 Recording parameters

The following parameters can be recorded using the PSI-CONF software:

- Signal strength
 - Network structure
 - Status and current values of the connected extension modules
- Click on “Record” under “Diagnostic”.
 - Select “Network diagnose” or “I/O diagnostics” under “Select the type of data to record”.
 - Under “Recording interval”, you can specify how often the values should be recorded.
 - **For network diagnostics:** activate “Record signal strength” or “Record network structures”.
 - **For I/O diagnostics:** select the desired stations.
 - Select a storage location. Click on “Start Recording”.

Diagnostic data is now written to a CSV file which can be opened with Excel, for example.




Figure 4-20 PSI-CONF software: “Record diagnostic data, Network diagnose”

4.9 Starting up I/O extension modules

4.9.1 Combinations of extension modules

Several corresponding output modules at different stations can be assigned to one digital or analog input module. The inputs are transmitted in parallel to all the outputs. The channels of the input module are mirrored to the channels of the output module.



It is **not** possible to separately assign the individual input channels of an extension module to different output modules.




Figure 4-21 Assignment of digital inputs and digital outputs

The combined RAD-DAIO6-IFS extension modules can only be assigned in pairs, because each module has inputs and outputs. That is why only two modules in the network may have the same I/O MAP address.




Figure 4-22 RAD-DAIO6-IFS assignment: analog/digital inputs and outputs

Table 4-9 Assignment of input modules and output modules

Input module			Output module	
2901537	RAD-AI4-IFS		2901538	RAD-AO4-IFS
2904035	RAD-PT100-4-IFS		2901538	RAD-AO4-IFS
2901535	RAD-DI4-IFS		2901536	RAD-DOR4-IFS
2901539	RAD-DI8-IFS	Static mode	2902811	RAD-DO8-IFS
		Pulse counter mode	-	No output module, can only be used in PLC / Modbus/RTU mode or dual mode
2901533	RAD-DAIO6-IFS		2901533	RAD-DAIO6-IFS

4.9.2 Setting the address of the extension modules via the thumbwheel

For I/O-to-I/O transmission of signals, you must assign a corresponding output module to an input module. Set the I/O MAP address (01 ... 99) using the white thumbwheel on the I/O extension module.

Addressing extension modules

- Use the thumbwheel to set the address.
- Press the SET button on the front of the wireless module to read the active configuration.

The following settings can be made using the white thumbwheel:

Table 4-10 White thumbwheel setting

Thumbwheel	Description
01 ... 99	I/O MAP address
00	Delivery state
** , 1* ... 9*	Setting not permitted
*1 ... *9	Interface system slave address, for use with other interface system master devices (IFS)

The following conditions must be met:

- Addresses 1 ... 99 (maximum) can be assigned for the extension modules in the entire wireless network.

Wireless module in I/O data mode

- The input module **must** be provided with the same I/O MAP address as the assigned output module at another station (I/O mapping). Output modules with the same I/O MAP address may appear several times at different stations in the network.
- The I/O MAP address of an input module may only appear once in the network.
- The channels of the input module are directly assigned to the channels of the output module:

Input module		Output module
Channel 1	→	Channel 1
Channel 2	→	Channel 2
...	→	...



It is **not** possible to individually assign the channels of the input and output modules.




Figure 4-23 Input module and output module with the same address

Wireless module in PLC / Modbus/RTU mode

- Output modules **must not** have the same I/O MAP address as input modules. Exception: output modules with the same I/O MAP address may appear several times at different stations in the network.
- The I/O MAP address of an input module may only appear once in the network.
- The input and output data is saved in a Modbus memory map in the master wireless module. You can read or write the process data via the serial interface of the master wireless module (RAD ID = 01) using the Modbus/RTU command. The process data tables can be found starting at page 68.

4.10 Startup time of the wireless station

Once a wireless station has been started up (power “ON”), it will take the wireless module several seconds until it is ready for operation. Every connected I/O extension module increases the startup time. Accordingly, a complete wireless station with 32 I/O extension modules may take several minutes to start up. Only after this time has elapsed is the wireless station ready for operation.

5 Serial data mode

In serial data mode, multiple controllers or serial I/O devices are networked quickly and easily using wireless technology. In this way, serial RS-232 or RS-485 cables can be replaced.




Figure 5-1 Serial data mode

You can configure the serial interface of the wireless module using the PSI-CONF software. In order to connect the wireless module to the PC, use the RAD-CABLE-USB cable (Order No. 2903447).



WARNING: Explosion hazard when used in potentially explosive areas

The USB cable must **not** be used in potentially explosive areas.



- When operating the network in serial data mode, it may not be possible to diagnose all devices. In this case, stop the serial application in order to perform full diagnostics.
- Using the PSI-CONF software, you can assign different serial settings to the devices under “Individual Settings”.

RAD-...-IFS

- Start the PSI-CONF software.
- Follow the software wizard.
- Once you have performed all the steps in the wizard, you can save the project and transfer it to the wireless modules.




Figure 5-2 PSI-CONF software: “Wizard, Step 3”




Figure 5-3 PSI-CONF software: “Wizard, Step 4”

5.1 Frame-based data transmission

$T_{IdleMin}$ parameter (minimum pause between two frames)

The $T_{IdleMin}$ parameter refers to the minimum pause that must elapse between two frames on the output side (wireless module is transmitting data via the serial interface).




Figure 5-4 Frame-based data transmission: $T_{IdleMin}$ parameter

$T_{FrameEnd}$ parameter

$T_{FrameEnd}$ is the time maintained by the transmitting wireless module between two frames.

If the data received by the wireless module is followed by a certain period of time where no further data is received, the wireless module assumes that the frame has arrived in its entirety. The frame is then transmitted. This period of time is referred to as $T_{FrameEnd}$.

$T_{FrameEnd}$ must be shorter than the minimum interval between two frames ($T_{FrameEnd} < T_{IdleMin}$). $T_{FrameEnd}$ must, however, also be greater than the maximum interval that is permitted between two characters in a frame. Otherwise the frame might be fragmented.




Figure 5-5 Frame-based data transmission: $T_{FrameEnd}$ parameter

5.2 Setting telegram pauses based on the example of Modbus/RTU

A frame is also referred to as a telegram. The length of the transmission pause between the telegrams depends on the set data rate. The beginning and end of a telegram is recognized by means of a time condition. A pause of 3.5 characters means that the telegram is complete and the next character is to be interpreted as the slave address. A telegram must therefore be sent as a continuous stream of data. If there is an interruption of more than 1.5 characters within a telegram, the data will be discarded by the receiver.

If the master is not able to transmit the successive characters quickly enough and communication is aborted, you must increase the minimum pause time (T_{FrameEnd}) between the individual characters of a telegram.

- To adapt data transmission to other protocols, you can adjust the T_{FrameEnd} and T_{IdleMin} parameters accordingly. Set the interface parameters under “Individual Settings”.




Figure 5-6 PSI-CONF software: “Individual Settings”

Individual settings for frame-based data transmission

Table 5-1 Verified parameters for frame-based data transmission

Manufacturer	Product	Protocol	T_{IdleMin} [bit]	T_{FrameEnd} [bit]
-	-	PROFIBUS	11	7
-	-	Modbus/RTU	39	20
Phoenix Contact	EMPro	Modbus/RTU	56	12
Phoenix Contact	SOLAR-CHECK	Modbus/RTU	56	12
Delta	RPI-M20A	Modbus/RTU	3	20

Not all of the I/O devices available on the market are verified. In this case, the parameters must be determined by tests based on the connected I/O device and on the protocol. As precise protocol knowledge is required, it might be useful to ask an expert for support.

6 PLC / Modbus/RTU

6.1 PLC / Modbus/RTU mode

In PLC / Modbus/RTU mode, you can wirelessly connect I/O extension modules directly to a controller (I/O to serial). The wireless module provides an RS-232 or RS-485 interface for this. In PLC / Modbus/RTU mode, the master wireless module operates as a Modbus slave. It has its own Modbus slave address. The entire wireless network therefore behaves like a single Modbus slave.

You can connect I/O extension modules to each wireless device in the network. A wireless network can have a maximum of 99 extension modules. Use the white thumbwheel on the I/O extension module to set the I/O MAP address. For information on addressing extension modules, please refer to page 53 onwards.




Figure 6-1 Configuration example: PLC / Modbus/RTU mode

6.1.1 Configuration via PSI-CONF software

- Start the PSI-CONF software (see page 38).
- Create a new network project.
- Follow the software wizard.




Figure 6-2 PSI-CONF software: “Wizard, Step 3”

- Select “PLC/Modbus RTU mode” and assign a Modbus address.
- Follow the software wizard.



The Modbus address is a unique address in the Modbus network. It is only assigned for the master wireless module (RAD ID = 01). You can assign an address between 1 ... 247.

In order to enable the master wireless module to communicate with a controller via the RS-232 or RS-485 interface, you must set the interface parameters. Please note that the controller settings must match the settings of the wireless module.

Table 6-1 Configuration via PSI-CONF software

Parameter	Possible values	Default setting
Interface type	RS-232, RS-485	RS-232
Data rate	300 bps ... 115200 bps	19200 bps
Parity	None, even, odd	None
Number of stop bits	1; 2	1
Number of data bits	8	8
Modbus address	1 ... 247	1

You can monitor the Modbus connection between the controller and the wireless module via a watchdog.

6.1.2 Application example: monitoring of oil pumps

At each oil pump, sensors acquire various analog and digital signals. The monitoring system (well-pad monitoring system) is divided into two meshed networks. As a result, the delay time in the network is kept to a minimum.

The distributed repeaters/slaves transmit the data to the wireless master in the control center. In the control center, the data is transmitted to a higher-level system via the Modbus/RTU interface. In addition, the data is conditioned and displayed on a monitor.




Figure 6-3 Monitoring of oil pumps

6.2 PLC / Modbus/RTU dual mode



PLC / Modbus/RTU dual mode is available for firmware version 1.80 or later. You can update the firmware free of charge using the PSI-CONF software version 2.50 or later. The firmware and software can be found on the Internet at phoenixcontact.net/products.

Dual mode combines PLC / Modbus/RTU mode and serial data mode. You can connect Radioline extension modules to the controller directly via the integrated RS-232 and RS-485 interface by means of wireless communication. You can also connect additional Modbus/RTU slaves in parallel.

In dual mode, each station in the wireless network acts as an independent Modbus slave. The yellow RAD ID corresponds to the Modbus address. The Modbus address of the master wireless module (RAD ID = 01) can be changed in order to integrate the wireless system into an existing Modbus network with Modbus address 01.

You can connect I/O extension modules to each station in the network. All I/O data from the extension modules is stored locally in the Modbus memory map of the respective station. Concurrently, you can connect additional Modbus slaves to each wireless station via RS-232 or RS-485, and control them via the respective Modbus address. All diagnostic data of the wireless network can be read from the wireless master (RAD ID = 01) of the wireless network via Modbus/RTU.




Figure 6-4 Configuration example: PLC / Modbus/RTU dual mode

- Activate dual mode as shown in the following example: “Configuration via PSI-CONF software” on page 60.
- Set the Modbus ID of each wireless module using the yellow thumbwheel.
- You can connect a maximum of 32 I/O extension modules to a wireless station. Use the white thumbwheel on the I/O extension module to set the I/O MAP address. For information on addressing extension modules, please refer to page 53 onwards.
- A wireless network can have a maximum of 99 I/O extension modules.



The function codes, error codes and registers are the same as those in PLC / Modbus/RTU mode. For addition information, please refer to page 66 onwards.

6.2.1 Configuration via PSI-CONF software

- Start the PSI-CONF software (see page 38).
- Create a new network project.
- Follow the software wizard.



- The Modbus address is a unique address in the Modbus network. In dual mode, the Modbus address is the RAD ID.
- In case Modbus slave address “01” has already been assigned to another Modbus device: The address of the master wireless module can only be changed via the PSI-CONF software. You can assign an address between 1 ... 247.

In order to enable the master wireless module to communicate with a controller via the RS-232 or RS-485 interface, you must set the interface parameters. Please note that the controller settings must match the settings of the wireless module.

Table 6-2 Configuration via PSI-CONF software

Parameter	Possible values	Default setting
Interface type	RS-232, RS-485	RS-232
Data rate	300 bps ... 115200 bps	19200 bps
Parity	None, even, odd	None
Number of stop bits	1; 2	1
Number of data bits	8	8
Modbus address	1 ... 247	1

You can monitor the Modbus connection between the controller and the wireless module via a watchdog.

6.2.2 Application examples

In order to wirelessly connect an existing Modbus/RTU device and additional inputs and outputs to a controller, dual mode is required.

Flow meter

The flow meter is installed in a shaft of the water treatment plant as a Modbus/RTU slave. An additional digital input is required to monitor the cover. A wireless system in dual mode can meet both requirements.




Figure 6-5 Flow meter

Access control with door opener

The card reader device on the door is a Modbus/RTU slave, the door opener is a digital output. Until now, either two Modbus slaves and a wireless system were required or two separate wireless systems for serial transmission and I/O transmission. Dual mode allows for economic implementation with only one wireless system.




Figure 6-6 Access control with door opener

6.3 Watchdog

The Modbus telegram watchdog monitors the connection between the master wireless module and the controller. It is triggered each time a Modbus telegram is received correctly. You can activate the watchdog using the PSI-CONF software.

- Under “Individual Settings”, select the “Network Settings” item. You can set a watchdog time of 200 ms ... 65000 ms here.




Figure 6-7 PSI-CONF software: “Individual Settings, Network Settings”

If the watchdog is triggered, an action will be performed on the I/O output modules. You can set this behavior in the event of an error using the DIP switches on the front.

- OFF = RESET: output value is set to 0
- ON = HOLD: hold the last output value

For more information on setting the DIP switches for the different extension modules, please refer to Section “Description of I/O extension modules” on page 87.

If the watchdog is activated and Modbus communication interrupted, the red ERR LED will flash on all wireless modules in the network. Depending on the DIP switch settings, the output modules issue the corresponding hold or reset value.

6.4 Modbus function codes

In the Modbus protocol, the function codes define which data is to be read or written.

Table 6-3 Supported Modbus function codes

Code number	Function code	Description
fc 03	Read Holding Register	Read OUT process data (address range 40010 ... 40999)
fc 04	Read Input Register	Read IN process data (address range 30010 ... 30999)
fc 16	Write Multiple Registers	Write multiple output registers word by word



- Other function codes exist in the Modbus protocol, but they are not supported.
- Registers 1 ... 123 can be read or written with a command.

6.4.1 Addressing registers



Please note that a distinction is made in the Modbus telegram between the register number and register address:

- The register number starts with 1.
- The register address starts with 0.

Function code 04

You must enter 0000 (hex0000) as the start address in order to read register 30001. Address range 3xxxx is already defined by the function code field.

Function codes 03 and 16

You must enter 0031 (hex001F) as the start address in order to read or write registers 40032 ... 40039. Address range 4xxxx is already defined by the function code field.

6.5 Module type and error code registers for I/O extension modules

Registers 30xx0 and 40xx0 can be used to read the module type and data timeliness of the I/O extension modules.

Table 6-4 Module type and timeliness of data

30xx0, 40xx0 ¹ Module type and timeliness of data															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
							Y ²	Module type							

¹ xx = I/O MAP address set using the white thumbwheel

² Y = timeliness of data, bit 8

The individual I/O extension modules can be clearly distinguished by the module type. The module type ID of the extension module can be read in the Modbus register.

Table 6-5 Module type IDs

Module type	Order No.	Module type ID
Analog inputs		
RAD-AI4-IFS	2901537	20 _{hex}
RAD-PT100-4-IFS	2904035	21 _{hex}
Analog outputs		
RAD-AO4-IFS	2901538	30 _{hex}
Digital inputs		
RAD-DI4-IFS	2901535	01 _{hex}
RAD-DI8-IFS	2901539	02 _{hex} (static mode)
		40 _{hex} (pulse counter mode)
Digital outputs		
RAD-DOR4-IFS	2901536	10 _{hex}
RAD-DO8-IFS	2902811	11 _{hex}
Analog/digital inputs and outputs		
RAD-DAIO6-IFS	2901533	60 _{hex}

“Module type” register value

If the module type in the register is invalid or not available, then the register value is 0.

“Timeliness of data” register value

If the data in the register is not up to date, then the register value is 1. This is the case, for example, if the wireless connection to an input module fails. The IN process data is then retained in the Modbus table, but is no longer updated. In the case of an output module, the “timeliness of data” register value is set to 1 until the OUT process data has been written to the Modbus registers. The read I/O data is only valid and up to date if a valid module type value is returned by the slave and the “timeliness of data” register value is 0.

6.5.1 Assigning I/O extension modules to the register

You can use the white thumbwheel on the I/O extension module to assign an I/O MAP address in the Modbus memory map. Example: if you set the thumbwheel of an input module to I/O MAP address = 01, the register assignment is 30010.

Table 6-6 Setting the white thumbwheel for register 30010 (read)

Read register	I/O MAP address (white thumbwheel)	Consecutive number 0 ... 9
30	01	0

6.6 Modbus memory map

The I/O data from the extension modules is stored in an internal register, the Modbus memory map. The Modbus memory map is located in the master wireless module with RAD ID = 01. The data here can be read or written by a Modbus master.

The following process data tables for the individual extension modules show at what location the I/O data is stored in the Modbus memory map. You can find a complete overview of the Modbus memory map from page 79 onwards.

The RSSI signal register can be found from page 82 onwards.

Table 6-7 RSSI voltage 2.4 GHz

LED 3
LED 2
LED 1
LINK LED



16k	125k	250k	RSSI voltage
-70 dBm	-65 dBm	-60 dBm	≥2.5 V
-80 dBm	-75 dBm	-70 dBm	≥2.0 V
-90 dBm	-85 dBm	-80 dBm	≥1.5 V
LINK	LINK	LINK	~1.0 V

Table 6-8 RSSI voltage, 868 MHz

LED 3
LED 2
LED 1
LINK LED



1.2k	9.6k	19.2k	60k	120k	RSSI voltage
-90 dBm	-85 dBm	-80 dBm	-75 dBm	-70 dBm	≥2.5 V
-100 dBm	-95 dBm	-90 dBm	-85 dBm	-80 dBm	≥2.0 V
-110 dBm	-105 dBm	-100 dBm	-95 dBm	-90 dBm	≥1.5 V
LINK	LINK	LINK	LINK	LINK	~1.0 V

6.6.1 RAD-AI4-IFS process data

I/O module	Module type ID	Register	Address range	Function code
RAD-AI4-IFS	20 _{hex}	06 _{hex}	30xx0 ... 30xx5 ¹	fc 04

¹ xx = I/O MAP address set using the white thumbwheel

Table 6-9 RAD-AI4-IFS module type and timeliness of data

30xx0 ¹ Module type and timeliness of data															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
								Y ²	Module type ³						

¹ xx = I/O MAP address set using the white thumbwheel

² Y = timeliness of data, bit 8

If the data in the register is not up to date, then the register value is 1. This is the case, for example, if the wireless connection or communication with an input module fails. In this case, the IN process data is retained in the Modbus table, but is no longer updated.

³ If the module type in the register is invalid or not available, then the register value is 0.

30xx1	Reserved
-------	----------

30xx2 Analog input 1 (terminal point 2.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
AI1															

30xx3 Analog input 2 (terminal point 3.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
AI2															

30xx4 Analog input 3 (terminal point 4.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
AI3															

30xx5 Analog input 4 (terminal point 5.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
AI4															

30xx6 ... 30xx9	Reserved
-----------------	----------

RAD-....-IFS

6.6.2 RAD-PT100-4-IFS process data

I/O module	Module type ID	Register	Address range	Function code
RAD-PT100-4-IFS	21 _{hex}	06 _{hex}	30xx0 ... 30xx5 ¹	fc 04

¹ xx = I/O MAP address set using the white thumbwheel

Table 6-10 RAD-PT100-4-IFS module type and timeliness of data

30xx0 ¹ Module type and timeliness of data															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
								Y ²	Module type ³						

¹ xx = I/O MAP address set using the white thumbwheel

² Y = timeliness of data, bit 8

If the data in the register is not up to date, then the register value is 1. This is the case, for example, if the wireless connection or communication with an input module fails. In this case, the IN process data is retained in the Modbus table, but is no longer updated.

³ If the module type in the register is invalid or not available, then the register value is 0.

30xx1	Reserved														
-------	----------	--	--	--	--	--	--	--	--	--	--	--	--	--	--

30xx2 Pt100 input 1 (terminal point 2.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
T1															

30xx3 Pt100 input 2 (terminal point 3.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
T2															

30xx4 Pt100 input 3 (terminal point 4.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
T3															

30xx5 Pt100 input 4 (terminal point 5.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
T4															

30xx6 ... 30xx9	Reserved														
-----------------	----------	--	--	--	--	--	--	--	--	--	--	--	--	--	--

6.6.3 RAD-AO4-IFS process data

I/O module	Module type ID	Register	Address range	Function code
RAD-AO4-IFS	30 _{hex}	06 _{hex}	40xx0 ... 40xx5 ¹	fc 03, 16

¹ xx = I/O MAP address set using the white thumbwheel

Table 6-11 RAD-AO4-IFS module type and timeliness of data

40xx0 ¹ Module type and timeliness of data															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
								Y ²	Module type ³						

¹ xx = I/O MAP address set using the white thumbwheel

² Y = timeliness of data, bit 8

If the data in the register is not up to date, then the register value is 1. If the process data has been written to one of the registers, then the register value is 0. The register value then remains 0 for the entire operating time of the device.

³ If the module type in the register is invalid or not available, then the register value is 0.

40xx1	Reserved														
-------	----------	--	--	--	--	--	--	--	--	--	--	--	--	--	--

40xx2 Analog output 1 (terminal point 2.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
AO1															

40xx3 Analog output 2 (terminal point 3.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
AO2															

40xx4 Analog output 3 (terminal point 4.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
AO3															

40xx5 Analog output 4 (terminal point 5.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
AO4															

40xx6 ... 40xx9	Reserved														
-----------------	----------	--	--	--	--	--	--	--	--	--	--	--	--	--	--

RAD-....-IFS

6.6.4 RAD-DI4-IFS process data

I/O module	Module type ID	Register	Address range	Function code
RAD-DI4-IFS	01 _{hex}	02 _{hex}	30xx0 ... 30xx1 ¹	fc 04

¹ xx = I/O MAP address set using the white thumbwheel

Table 6-12 RAD-DI4-IFS module type and timeliness of data

30xx0 ¹ Module type and timeliness of data															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
								Y ²	Module type ³						

¹ xx = I/O MAP address set using the white thumbwheel

² Y = timeliness of data, bit 8

If the data in the register is not up to date, then the register value is 1. This is the case, for example, if the wireless connection or communication with an input module fails. In this case, the IN process data is retained in the Modbus table, but is no longer updated.

³ If the module type in the register is invalid or not available, then the register value is 0.

30xx1 Digital inputs															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
												DI4	DI3	DI2	DI1
Terminal point															
												6.x	5.x	2.x	1.x
30xx2 ... 30xx9								Reserved							

6.6.5 RAD-DI8-IFS process data

I/O module	Module type ID	Register	Address range	Function code
RAD-DI8-IFS	02 _{hex} Static mode	02 _{hex} Static inputs	30xx0 ... 30xx1 ¹	fc 04
	40 _{hex} Pulse counter mode	06 _{hex} Pulse inputs	30xx0 ... 30xx5 ¹	fc 04
	40 _{hex} Pulse counter mode	02 _{hex} Reset counter states	40xx0 ... 40xx1 ¹	fc 03, 16

¹ xx = I/O MAP address set using the white thumbwheel

Table 6-13 RAD-DI8-IFS module type and timeliness of data

30xx0 ¹ Module type and timeliness of data															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
							Y ²	Module type ³							

¹ xx = I/O MAP address set using the white thumbwheel

² Y = timeliness of data, bit 8

If the data in the register is not up to date, then the register value is 1. This is the case, for example, if the wireless connection or communication with an input module fails. In this case, the IN process data is retained in the Modbus table, but is no longer updated.

³ If the module type in the register is invalid or not available, then the register value is 0.

RAD-....-IFS

30xx1 Digital inputs DI1 ... DI8 (static mode)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
								DI8	DI7	DI6	DI5	DI4	DI3	DI2	DI1
Terminal point															
								5.x	5.x	4.x	4.x	3.x	3.x	2.x	2.x

30xx2 DI1: 32-bit pulse input, pulse counter mode (terminal point 2.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Counter state DI1, low word															

30xx3 DI1: 32-bit pulse input, pulse counter mode (terminal point 2.x)															
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
Counter state DI1, high word															

30xx4 DI7: 32-bit pulse input, pulse counter mode (terminal point 5.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Counter state DI7, low word															

30xx5 DI7: 32-bit pulse input, pulse counter mode (terminal point 5.x)															
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
Counter state DI7, high word															

30xx6 ... 30xx9	Reserved
-----------------	----------

40xx1 Reset of counter states DI1/DI7															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
														X ¹	X ²

¹ Bit 1 = 1: counter state DI7 reset to 0

² Bit 0 = 1: counter state DI1 reset to 0

40xx2 ... 40xx9	Reserved
-----------------	----------

6.6.6 RAD-DOR4-IFS process data

I/O module	Module type ID	Register	Address range	Function code
RAD-DOR4-IFS	10 _{hex}	02 _{hex}	40xx0 ... 40xx1 ¹	fc 03, 16

¹ xx = I/O MAP address set using the white thumbwheel

Table 6-14 RAD-DOR4-IFS module type and timeliness of data

30xx0 ¹ Module type and timeliness of data															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
								Y ²	Module type ³						

¹ xx = I/O MAP address set using the white thumbwheel

² Y = timeliness of data, bit 8
If the data in the register is not up to date, then the register value is 1. If the process data has been written to one of the registers, then the register value is 0. The value then remains 0 for the entire operating time of the device.

³ If the module type in the register is invalid or not available, then the register value is 0.

40xx1 Digital outputs															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
												DO 4	DO 3	DO 2	DO 1
Terminal point															
												6.x	5.x	2.x	1.x
40xx2 ... 40xx9								Reserved							

RAD-....-IFS

6.6.7 RAD-DO8-IFS process data

I/O module	Module type ID	Register	Address range	Function code
RAD-DO8-IFS	11 _{hex}	02 _{hex} Outputs	40xx0 ... 40xx1 ¹	fc 03, 16
		02 _{hex} Short circuit detection	30xx0 ... 30xx1 ¹	fc 04

¹ xx = I/O MAP address set using the white thumbwheel

Table 6-15 RAD-DO8-IFS module type and timeliness of data

30xx0, 40xx0 ¹ Module type and timeliness of data															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
							Y ²	Module type ³							

¹ xx = I/O MAP address set using the white thumbwheel

² Y = timeliness of data, bit 8

If the data in the register is not up to date, then the register value is 1. If the process data has been written to one of the registers, bit 8 in 40xx0 is set to 0. The value in register 40xx0 then remains 0 for the entire operating time of the device.

However, in register 30xx0, bit 8 is reset to 1 as soon as the status of short-circuit detection is not up to date. This is the case, for example, if communication with an input module fails. In this case, the IN process data is retained in the Modbus table, but is no longer updated.

³ If the module type in the register is invalid or not available, then the register value is 0.

30xx1 Short-circuit detection at the digital outputs															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Reserved														X ¹	X ²

¹ **Bit 1 = 1:** short circuit detected at one output or several outputs 5 ... 8.

² **Bit 0 = 1:** short circuit detected at one output or several outputs 1 ... 4.

30xx2 ... 30xx9	Reserved														
40xx1	Digital outputs DO1 ... DO8														
Channel (high byte)								Channel (low byte)							
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Reserved								DO 8	DO 7	DO 6	DO 5	DO 4	DO 3	DO 2	DO 1
Terminal point															
								5.x	5.x	4.x	4.x	3.x	3.x	2.x	2.x
40xx2 ... 40xx9	Reserved														

6.6.8 RAD-DAIO6-IFS process data

I/O module	Module type ID	Register	Address range	Function code
RAD-DAIO6-IFS	60 _{hex}	03 _{hex} (inputs)	30xx0 ... 30xx2 ¹	fc 04
		03 _{hex} (outputs)	40xx0 ... 40xx2 ¹	fc 03, 16

¹ xx = I/O MAP address set using the white thumbwheel

Table 6-16 RAD-DAIO6-IFS module type and timeliness of data

30xx0 ¹	Module type and timeliness of data														
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
							Y ²	Module type ³							

¹ xx = I/O MAP address set using the white thumbwheel

² Y = timeliness of data, bit 8

If the data in the register is not up to date, then the register value is 1. If the process data has been written to one of the registers, bit 8 in 40xx0 is set to 0. The value in register 40xx0 then remains 0 for the entire operating time of the device. This is the case, for example, if the wireless connection fails. The IN process data is retained in the Modbus table, but is no longer updated.

³ If the module type in the register is invalid or not available, then the register value is 0.

RAD-....-IFS

30xx1 Digital inputs															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
														DI2	DI1
Terminal point															
														2.x	1.x

30xx2 Analog input (terminal point 3.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
AI1															

30xx3 ... 30xx9	Reserved													
------------------------	-----------------	--	--	--	--	--	--	--	--	--	--	--	--	--

40xx1 Digital outputs															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
														DO 2	DO 1
Terminal point															
														6.x	5.x

40xx2 Analog output (terminal point 4.x)															
15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
AO1															
Terminal point															
															4.x

40xx3 ... 40xx9	Reserved													
------------------------	-----------------	--	--	--	--	--	--	--	--	--	--	--	--	--

6.6.9 Complete overview of the Modbus memory map

I/O input data, address range 30010 ... 30999															
Modbus function code 04															
RAD-DAIO6-IFS															
	IO MAP		High byte 15 ... 8								Low byte 7 ... 0				
30	xx	0	Timeliness of data								Module type ID				
											X	X	X	X	X
30	xx	1	DI												
														2	1
														X	X
30	xx	2	AI1												
			X	X	X	X	X	X	X	X	X	X	X	X	X
30xx3 ... 30xx9 reserved															

I/O output data, address range 40010 ... 40999															
Modbus function code 03, 16															
RAD-DAIO6-IFS															
	IO MAP		High byte 15 ... 8								Low byte 7 ... 0				
40	xx	0	Timeliness of data								Module type ID				
											X	X	X	X	X
40	xx	1	DO												
														2	1
														X	X
40	xx	2	AO1												
			X	X	X	X	X	X	X	X	X	X	X	X	X
40xx3 ... 40xx9 reserved															

RAD-DI4-IFS															
	IO MAP		High byte 15 ... 8								Low byte 7 ... 0				
30	xx	0	Timeliness of data								Module type ID				
											X	X	X	X	X
30	xx	1	DI4 ... DI1												
														X	X
30xx2 ... 30xx9 reserved															

RAD-DOR4-IFS															
	IO MAP		High byte 15 ... 8								Low byte 7 ... 0				
40	xx	0	Timeliness of data								Module type ID				
											X	X	X	X	X
40	xx	1	DO4 ... DO1												
														X	X
40xx2 ... 40xx9 reserved															

RAD-DI8-IFS															
	IO MAP		High byte 15 ... 8								Low byte 7 ... 0				
30	xx	0	Timeliness of data								Module type ID				
											X	X	X	X	X
30	xx	1	DI8 ... DI1												
														X	X
30	xx	2	Counter state DI1 (low word)												
			X	X	X	X	X	X	X	X	X	X	X	X	X
30	xx	3	Counter state DI1 (high word)												
			X	X	X	X	X	X	X	X	X	X	X	X	X
30	xx	4	Counter state DI7 (low word)												
			X	X	X	X	X	X	X	X	X	X	X	X	X
30	xx	5	Counter state DI7 (high word)												
			X	X	X	X	X	X	X	X	X	X	X	X	X
30xx6 ... 30xx9 reserved															

RAD-DI8-IFS															
	IO MAP		High byte 15 ... 8								Low byte 7 ... 0				
40	xx	0	Timeliness of data								Module type ID				
											X	X	X	X	X
40	xx	1	Bit 0 = 1: reset DI1 Bit 1 = 1: reset DI7												
														X	X
40xx2 ... 40xx9 reserved															

RAD-....-IFS

I/O input data, address range 30010 ... 30999																
Modbus function code 04																
RAD-DO8-IFS																
	IO MAP		High byte 15 ... 8								Low byte 7 ... 0					
30	xx	0	Timeliness of data								Module type ID					
										X	X	X	X	X	X	X
30	xx	1	Short-circuit detection													
			Bit 0: DO 1 ... 4, bit 1: 5 ... 8													
															X	X
30xx2 ... 30xx9 reserved																

I/O output data, address range 40010 ... 40999															
Modbus function code 03, 16															
RAD-DO8-IFS															
	IO MAP		High byte 15 ... 8							Low byte 7 ... 0					
40	xx	0	Timeliness of data							Module type ID					
										X	X	X	X	X	X
40	xx	1								DO					
										8	7	6	5	4	3
											X	X	X	X	X
40xx2 ... 40xx9 reserved															

RAD-AI4-IFS																
	IO MAP		High byte 15 ... 8							Low byte 7 ... 0						
30	xx	0	Timeliness of data							Module type ID						
										X	X	X	X	X	X	X
30	xx	1	Reserved													
30	xx	2	AI1													
			X	X	X	X	X	X	X	X	X	X	X	X	X	X
30	xx	3	AI2													
			X	X	X	X	X	X	X	X	X	X	X	X	X	X
30	xx	4	AI3													
			X	X	X	X	X	X	X	X	X	X	X	X	X	X
30	xx	5	AI4													
			X	X	X	X	X	X	X	X	X	X	X	X	X	X
30xx6 ... 30xx9 reserved																

RAD-AO4-IFS															
	IO MAP		High byte 15 ... 8								Low byte 7 ... 0				
40	xx	0	Timeliness of data								Module type ID				
											X	X	X	X	X
40	xx	1	Reserved												
40	xx	2	AO1												
			X	X	X	X	X	X	X	X	X	X	X	X	X
40	xx	3	AO2												
			X	X	X	X	X	X	X	X	X	X	X	X	X
40	xx	4	AO3												
			X	X	X	X	X	X	X	X	X	X	X	X	X
40	xx	5	AO4												
			X	X	X	X	X	X	X	X	X	X	X	X	X
40xx6 ... 40xx9 reserved															

I/O input data, address range 30010 ... 30999																
Modbus function code 04																
RAD-PT100-4-IFS																
	IO MAP		High byte 15 ... 8								Low byte 7 ... 0					
30	xx	0	Timeliness of data								Module type ID					
										X	X	X	X	X	X	X
30	xx	1	Reserved													
30	xx	2	T1													
			X	X	X	X	X	X	X	X	X	X	X	X	X	X
30	xx	3	T2													
			X	X	X	X	X	X	X	X	X	X	X	X	X	X
30	xx	4	T3													
			X	X	X	X	X	X	X	X	X	X	X	X	X	X
30	xx	5	T4													
			X	X	X	X	X	X	X	X	X	X	X	X	X	X
30xx6 ... 30xx9 reserved																

Example for reading temperature T1 (I/O MAP = 02):
function code 04, start address 21 (hex15)

.... . . .
.... . . .

30	99	0														
----	----	---	--	--	--	--	--	--	--	--	--	--	--	--	--	--

I/O output data, address range 40010 ... 40999															
Modbus function code 03, 16															

.... . . .
.... . . .

40	99	0														
----	----	---	--	--	--	--	--	--	--	--	--	--	--	--	--	--

RAD-....-IFS

6.6.10 RSSI signal and error code registers

The RSSI values indicate the received signal strength on the wireless module. You can read the RSSI values via the serial interface of the master wireless module (RAD ID = 01) using Modbus/RTU commands. The RSSI values of all wireless modules in the network are within address range 35001 ... 35250.

Table 6-17 RSSI signal and error code registers

Address range		35001 ... 35250															
Modbus function code		fc 04															
Address	Wireless module	High byte								Low byte, RSSI value							
		15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
35001	RSSI - RAD ID = 1 (master)	Reserved								IFS	X	X	X	X	X	X	X
35002	RSSI - RAD ID = 2	Reserved								X	X	X	X	X	X	X	X
...	...	Reserved								X	X	X	X	X	X	X	X
35250	RSSI - RAD ID = 250	Reserved								X	X	X	X	X	X	X	X

Bit 08 = error on IFS bus

If an error is present on the IFS bus, the register value is 1 (e.g., local bus error, because the input or output module is disconnected from the DIN rail connector). If no error is present on the IFS bus, the register value is 0.

- Bits 9 ... 15 are reserved.
- Values <255 indicate the RSSI value in -dBm.
- Value 255 means that the RSSI value is invalid or the device cannot be reached.

Example for reading the RSSI register of the station with RAD ID = 2:
Function code 04, start address 5001 (hex1389)

6.7 Error codes and formats for analog input and output values

The measured value is represented in bits 0 ... 15. Values greater than 8000_{hex} indicate an error.

RAD-AI4-IFS analog inputs

Table 6-18 Representation of RAD-AI4-IFS analog values

Data word			
hex	dec/error code	0 mA ... 20 mA	4 mA ... 20 mA
0000	0	0 mA	-
1770	6000	4 mA	4 mA
7530	30000	20 mA	20 mA
7F00	32512	21.67 mA	21.67 mA
8001	Overrange	>21.67 mA	>21.67 mA
8002	Open circuit	-	<3.2 mA
8080	Underrange	<0 mA	-

RAD-AO4-IFS analog outputs

Table 6-19 Representation of RAD-AO4-IFS analog values

Data word			
hex	dec/error code	0 mA ... 20 mA	0 V ... 10 V
0000	0	0 mA	0 V
7530	30000	20 mA	10 V
7F00	32512	21.67 mA	10.84 V

RAD-DAIO6-IFS analog inputs and outputs

Table 6-20 Representation of RAD-DAIO6-IFS analog values

Data word				
hex	dec/error code	0 ... 20 mA	4 ... 20 mA	0 V ... 10 V
0000	0	0 mA	-	0 V
1770	6000	4 mA	4 mA	2 V
7530	30000	20 mA	20 mA	10 V
7F00	32512	21.67 mA	21.67 mA	10.84 V
8001	Overrange	>21.67 mA	>21.67 mA	-
8002	Open circuit	-	<3.2 mA	-
8080	Underrange	<0 mA	-	-

RAD-....-IFS

Error codes and formats for Pt100 values

Table 6-21 Representation of RAD-PT100-4-IFS Pt100 values

Data word		RAD-PT100-4-IFS Pt100 input	RAD-AO4-IFS analog output		Possible cause
hex	dec/error code	-50°C ... +250°C	0 mA ... 20 mA	0 V ... 10 V	
0000	0	-50°C	0 mA	0 V	
7530	30000	+250°C	20 mA	10 V	
7F00	32512	+275.12°C	21.67 mA	10.84 V	
8001	Overrange				
8002	Open circuit				Sensor wired incorrectly, measuring cable too long, cable resistance too high
8080	Underrange				

6.8 Radioline function blocks



The function blocks can be found at phoenixcontact.net/products at the corresponding Radioline front module.

In widely spread outdoor plant structures, measured values and operating messages are often transmitted from numerous remote stations to one control room. This includes, for example, seamless logging of the pump performance and flow rates. In the control room, standardized software interfaces are used to transmit the process data to a higher-level system or to display it on a monitor. What might sound simple actually means much programming.

Function blocks can be used to integrate new functions quickly and easily or transform devices into a fully fledged part of your control system.

The Radioline function blocks are suitable for PC Worx, STEP 7 and TIA Portal. Thanks to modern wireless technology, I/O signals from distributed sensors and actuators can easily be integrated in a Phoenix Contact or Siemens controller.



Figure 6-8 Function blocks for Radioline

6.8.1 I/O integration in Phoenix Contact controllers




Figure 6-9 I/O integration in PC Worx

Required components:

- Radioline front module
- Radioline I/O extension modules
- Inline or Axioline controllers
- Inline or Axioline RS-485 communication module
- PC Worx
- PC Worx function blocks
 - PCW_6_RadiolineBasic
 - PCW_6_ComSerial
 - PCW_6_Modbus

TIA Portal STEP 7

BK PB/PN

PROFIBUS

RS-485

TRUSTED WIRELESS™

- Radioline front module
- Radioline I/O extension modules
- Inline or Axioline bus coupler
- Inline or Axioline RS-485 communication module
- S7-3xx, S7-12xx, S7-15xx controllers
- TIA Portal or STEP 7
- STEP 7 function blocks
 - STEP_7_RadiolineBasic
 - STEP_7_comserial
 - STEP_7_Modbus

7 Description of I/O extension modules

7.1 RAD-AI4-IFS - analog extension module with four inputs

The RAD-AI4-IFS analog I/O extension module can process up to four input signals with 0/4 mA ... 20 mA. All inputs are electrically isolated from one another, from the supply voltage, and from the electronics.

A supply voltage of at least 12 V DC is available at connection terminal block PWR₁ for passive sensors (see Figure 7-1, item 1).

7.1.1 Structure




Figure 7-1 RAD-AI4-IFS structure

Item	Terminal block	Designation
1	3.1/3.2/3.3	Analog input 2 for 2, 3, 4-wire measuring transducers
2	2.1/2.2/2.3	Analog input 1 for 2, 3, 4-wire measuring transducers
3		DIP switches for configuring the analog inputs (0 mA ... 20 mA, 4 mA ... 20 mA)
4		White thumbwheel for setting the I/O MAP address
5		Connection option for DIN rail connector
6		DIN rail
7		Metal foot catch for DIN rail fixing
8	4.1/4.2/4.3	Analog input 3 for 2, 3, 4-wire measuring transducers
9	5.1/5.2/5.3	Analog input 4 for 2, 3, 4-wire measuring transducers
10		ERR status LED, red (communication error)
11		DAT status LED, green (bus communication)
12		PWR status LED, green (supply voltage)

7.1.2 Basic circuit diagram




Figure 7-2 Basic circuit diagram for the RAD-AI4-IFS

7.1.3 Setting the DIP switches

You can configure the input signals using the DIP switches on the front (0 mA ... 20 mA or 4 mA ... 20 mA). Any changes to the DIP switch settings will be applied immediately. In PLC / Modbus/RTU mode, the setting of the input signals is evaluated for error diagnostics. When set to 4 mA ... 20 mA, for example, it is possible to detect an open circuit.




Figure 7-3 DIP switches of the RAD-AI4-IFS

Table 7-1 DIP switches of the RAD-AI4-IFS

Setting	Input signal	DIP switch			
		1	2	3	4
Analog IN1	0 mA ... 20 mA	OFF			
	4 mA ... 20 mA	ON			
Analog IN2	0 mA ... 20 mA		OFF		
	4 mA ... 20 mA		ON		
Analog IN3	0 mA ... 20 mA			OFF	
	4 mA ... 20 mA			ON	
Analog IN4	0 mA ... 20 mA				OFF
	4 mA ... 20 mA				ON

7.1.4 Diagnostic LEDs

The RAD-AI4-IFS I/O extension module uses a total of three LEDs to indicate the operating states.




Figure 7-4 Diagnostic LEDs of the RAD-AI4-IFS

PWR LED

The green PWR LED indicates the status of the supply voltage.

Off	No supply voltage
On	Supply voltage OK

DAT LED

The green DAT LED indicates the status of bus communication.

Off	No communication
Flashing	Configuration and addressing mode
On	Cyclic data communication

ERR LED

The red ERR LED indicates the error status.

Off	No error
Flashing	
Slow (1.4 Hz)	I/O MAP address changed
Fast (2.8 Hz)	No bus communication
On	Critical internal error

7.1.5 Setting the I/O MAP address

Use the thumbwheel to set the I/O MAP address. The extension module in the Radioline wireless system is addressed using the I/O MAP address. Addresses 01 ... 99 (maximum) can be assigned for the I/O extension modules in the entire wireless network.

Table 7-2 Setting the I/O MAP address for the RAD-AI4-IFS

Thumbwheel	Description
01 ... 99	I/O MAP address
00	Delivery state
** , 1* ... 9*	Setting not permitted
*1 ... *9	Interface system slave address, for use with other interface system (IFS) master devices

7.1.6 Process data in PLC / Modbus/RTU mode

The process image of the I/O extension module consists of six data words. For additional information, please refer to Section "RAD-AI4-IFS process data" on page 69.

I/O module	Module type ID	Register	Address range	Function code
RAD-AI4-IFS	20 _{hex}	06 _{hex}	30xx0 ... 30xx5	fc 04

7.2 RAD-PT100-4-IFS - extension module with four temperature inputs

The RAD-PT100-4-IFS analog I/O extension module has four Pt100 inputs for temperatures from -50°C ... +250°C. Pt100 inputs T1 ... T4 can be mapped to analog outputs I1/U1 ... I4/U4 of the RAD-AO4-IFS extension module. All inputs are electrically isolated from one another, from the supply voltage, and from the remaining electronics.

Pt100 resistance temperature detectors can be connected to the RAD-PT100-4-IFS I/O extension module. The temperature detectors change their resistance according to the temperature. The RAD-PT100-4-IFS acquires the Pt100 input signals. The inputs signals are mapped to proportional, analog voltage or current signals of the RAD-AO4-IFS output module.

Example: at a temperature of -50°C at the Pt100 input, a current of 0 mA or a voltage of 0 V is issued at the output module. At a temperature of 250°C at the Pt100 input, a current of 20 mA or a voltage of 10 V is issued at the output.

Table 7-3 Pt100 input

Pt100 input	Analog output
-50°C	0 mA or 0 V
+250°C	20 mA or 10 V

7.2.1 Connecting sensors

You can connect 2-wire or 3-wire sensors to the extension module. Take the measuring errors of the different measuring methods into consideration.

2-wire connection technology

2-wire connection technology is the most cost-effective connection technology. The temperature-related voltage is not directly measured at the sensor and is therefore falsified by the two cable resistances R_L . The measuring errors that occur may render the entire measurement useless. Please observe the diagrams in Section “Measuring errors when using 2-wire connection technology” on page 93.

For 2-wire connection technology, an insertion bridge is required between terminal blocks x.2 and x.3.




Figure 7-5 2-wire connection technology

3-wire connection technology

With 3-wire connection technology, the temperature-related voltage is measured several times. Corresponding calculations additionally reduce the effect of the cable resistance on the measurement result. The results are almost as good as those achieved with 4-wire connection technology.

The cable resistances R_L at terminal blocks +I and -I must have the same value. This allows you to subtract the measured cable resistance from the measurement result and to get the Pt100 platinum resistance value.




Figure 7-6 3-wire connection technology

4-wire connection technology

The RAD-PT100-4-IFS does not support 4-wire connection technology.

- If you want to use a 4-wire sensor, only connect three of the four cables.
- The fourth cable should be left unwired. Otherwise there will be a different resistance in the +I and -I cables owing to the parallel connection of two cable resistances.




Figure 7-7 4-wire connection technology

7.2.2 Measuring errors when using 2-wire connection technology




Figure 7-8 Systematic temperature measuring error ΔT depending on cable length l

Curves depending on cable cross section A

- ① $A = 0.25 \text{ mm}^2$
- ② $A = 0.5 \text{ mm}^2$
- ③ $A = 1.0 \text{ mm}^2$
- ④ $A = 1.5 \text{ mm}^2$

(Measuring error valid for: copper cable $\chi = 57 \text{ m}/\Omega\text{mm}^2$, $T_A = 25^\circ\text{C}$, and Pt100 sensor)




Figure 7-9 Systematic temperature measuring error ΔT depending on cable cross section A




Figure 7-10 Systematic temperature measuring error ΔT depending on cable temperature T_A

(Measuring error valid for: copper cable $\chi = 57 \text{ m}/\Omega\text{mm}^2$, $T_A = 25^\circ\text{C}$, and Pt100 sensor)

Make sure that the cable resistance and therefore the measuring error is as low as possible:

- Use sensor cables that are as short as possible.
- Avoid cable cross sections smaller than 0.5 mm^2 .

The temperature has only a small influence on the cable resistance.

You can calculate the cable resistance as follows:

$$R_L = R_{L20} \times \left[1 + 0.0039 \frac{1}{\text{K}} \times (T_A - 20^\circ\text{C}) \right]$$

$$R_L = \frac{l}{\chi \times A} \times \left[1 + 0.0039 \frac{1}{\text{K}} \times (T_A - 20^\circ\text{C}) \right]$$

R_L Cable resistance in Ω

R_{L20} Cable resistance at 20°C in Ω

l Cable length in m

χ Specific resistance of copper in $\text{m}/\Omega\text{mm}^2$

A Cable cross section in mm^2

0.0039 1/K Temperature coefficient for copper (degree of purity of 99.99%)

T_A Ambient temperature (cable temperature) in $^\circ\text{C}$

Since there are two cable resistances in the measuring system, the value must be doubled. Using the average temperature coefficient $\alpha = 0.385 \text{ } \Omega/\text{K}$ for Pt100, the absolute measuring error in Kelvin can be determined for platinum sensors according to DIN.

7.2.3 Structure




Figure 7-11 RAD-PT100-4-IFS structure

Item	Terminal block	Designation
1	3.1/3.2/3.3	Pt100 input 2 for 2 and 3-wire sensors
2	2.1/2.2/2.3	Pt100 input 1 for 2 and 3-wire sensors
3		White thumbwheel for setting the I/O MAP address
4		Connection option for DIN rail connector
5		DIN rail
6		Metal foot catch for DIN rail fixing
7	4.1/4.2/4.3	Pt100 input 3 for 2 and 3-wire sensors
8	5.1/5.2/5.3	Pt100 input 4 for 2 and 3-wire sensors
9		ERR status LED, red (communication error)
10		DAT status LED, green (bus communication)
11		PWR status LED, green (supply voltage)

7.2.4 Basic circuit diagram




Figure 7-12 Basic circuit diagram for the RAD-PT100-4-IFS



For 2-wire connection technology, an insertion bridge is required between terminal blocks x.2 and x.3. In this case, the measuring accuracy is reduced (see “Measuring errors when using 2-wire connection technology” on page 93).

7.2.5 Diagnostic LEDs

The RAD-PT100-4-IFS I/O extension module uses a total of three LEDs to indicate the operating states.



Figure 7-13 Diagnostic LEDs of the RAD-PT100-4-IFS

PWR LED

The green PWR LED indicates the status of the supply voltage.

Off	No supply voltage
On	Supply voltage OK

DAT LED

The green DAT LED indicates the status of bus communication.

Off	No communication
Flashing	Configuration and addressing mode
On	Cyclic data communication

ERR LED

The red ERR LED indicates the error status.

Off	No error
Flashing	
Slow (1.4 Hz)	I/O MAP address changed
Fast (2.8 Hz)	No bus communication
On	Critical internal error

7.2.6 Setting the I/O MAP address

Use the thumbwheel to set the I/O MAP address. The extension module in the Radioline wireless system is addressed using the I/O MAP address. Addresses 01 ... 99 (maximum) can be assigned for the I/O extension modules in the entire wireless network.

Table 7-4 Setting the I/O MAP address for the RAD-PT100-4-IFS

Thumbwheel	Description
01 ... 99	I/O MAP address
00	Delivery state
** , 1* ... 9*	Setting not permitted
*1 ... *9	Interface system slave address, for use with other interface system (IFS) master devices

7.2.7 Process data in PLC / Modbus/RTU mode

The process image of the I/O extension module consists of six data words. For additional information, please refer to Section "RAD-PT100-4-IFS process data" on page 70.

I/O module	Module type ID	Register	Address range	Function code
RAD-PT100-4-IFS	21 _{hex}	06 _{hex}	30xx0 ... 30xx5	fc 04

7.3 RAD-AO4-IFS - analog extension module with four outputs

The RAD-AO4-IFS analog I/O extension module can output up to four input signals with 0/4 mA ... 20 mA. All outputs are electrically isolated from one another, from the supply voltage, and from the electronics.



Use either the current or voltage output at every analog channel.

7.3.1 Structure




Figure 7-14 RAD-AO4-IFS structure

Item	Terminal block	Designation
1	3.1/3.2/3.3	Analog output 2 (either current or voltage)
2	2.1/2.2/2.3	Analog output 1 (either current or voltage)
3		DIP switches for configuring the outputs (current/voltage output)
4		White thumbwheel for setting the I/O MAP address
5		Connection option for DIN rail connector
6		DIN rail
7		Metal foot catch for DIN rail fixing
8	4.1/4.2/4.3	Analog output 3 (either current or voltage)
9	5.1/5.2/5.3	Analog output 4 (either current or voltage)
10		ERR status LED, red (communication error)
11		DAT status LED, green (bus communication)
12		PWR status LED, green (supply voltage)

7.3.2 Basic circuit diagram




Figure 7-15 Basic circuit diagram for the RAD-AO4-IFS

7.3.3 Setting the DIP switches

You can use the DIP switches on the front to set the behavior of the outputs in the event of an error, e.g., interruption of the wireless connection. Any changes to the DIP switch settings will be applied immediately.

- RESET = output value is set to 0
- HOLD = hold the last valid output value




Figure 7-16 DIP switches of the RAD-AO4-IFS

Table 7-5 DIP switches of the RAD-AO4-IFS

Input	Output signal	DIP switch			
		1	2	3	4
Analog OUT1	RESET	OFF			
	HOLD	ON			
Analog OUT2	RESET		OFF		
	HOLD		ON		
Analog OUT3	RESET			OFF	
	HOLD			ON	
Analog OUT4	RESET				OFF
	HOLD				ON

7.3.4 Diagnostic LEDs

The RAD-AO4-IFS I/O extension module uses a total of three LEDs to indicate the operating states.




Figure 7-17 Diagnostic LEDs of the RAD-AO4-IFS

PWR LED

The green PWR LED indicates the status of the supply voltage.

Off	No supply voltage
On	Supply voltage OK

DAT LED

The green DAT LED indicates the status of bus communication.

Off	No communication
Flashing	Configuration and addressing mode
On	Cyclic data communication

ERR LED

The red ERR LED indicates the error status, e.g., if a corresponding input module has not been found.

Off	No error
Flashing	
Slow (1.4 Hz)	I/O MAP address changed
Fast (2.8 Hz)	Wireless module in I/O data mode
	– Missing input module
	– No bus communication
	Wireless module in PLC / Modbus/RTU mode
	– No Modbus communication (safe state of outputs, depending on DIP switch setting)
On	Critical internal error

7.3.5 Setting the I/O MAP address

Use the thumbwheel to set the I/O MAP address. The extension module in the Radioline wireless system is addressed using the I/O MAP address. Addresses 01 ... 99 (maximum) can be assigned for the I/O extension modules in the entire wireless network.

Table 7-6 Setting the I/O MAP address for the RAD-AO4-IFS

Thumbwheel	Description
01 ... 99	I/O MAP address
00	Delivery state
** , 1* ... 9*	Setting not permitted
*1 ... *9	Interface system slave address, for use with other interface system (IFS) master devices

7.3.6 Process data in PLC / Modbus/RTU mode

The process image of the I/O extension module consists of six data words. For additional information, please refer to Section "RAD-AO4-IFS process data" on page 71.

I/O module	Module type ID	Register	Address range	Function code
RAD-AO4-IFS	30 _{hex}	06 _{hex}	40xx0 ... 40xx5	fc 03, 16

7.4 RAD-DI4-IFS - digital extension module with four inputs



WARNING: Risk of electric shock

Use the same phase for digital inputs and outputs. The isolating voltage between the individual channels must not exceed 300 V.

The RAD-DI4-IFS digital I/O extension module can process up to four input signals. The digital inputs process the following voltages:

- 0 V ... 50 V AC/DC at the low voltage input
- 0 V ... 250 V AC/DC at the high voltage input

All inputs are electrically isolated from one another, from the supply voltage, and from the electronics.

7.4.1 Structure




Figure 7-18 RAD-DI4-IFS structure

Item	Terminal block	Designation
1	2.1/2.2/2.3	Digital input as wide-range input
2	1.1/1.2/1.3	Digital input as wide-range input
3		White thumbwheel for setting the I/O MAP address
4		Connection option for DIN rail connector
5		DIN rail
6		Metal foot catch for DIN rail fixing
7	5.1/5.2/5.3	Digital input as wide-range input
8	6.1/6.2/6.3	Digital input as wide-range input
9		Status LEDs for digital inputs DI1 ... DI4
10		ERR status LED, red (communication error)
11		DAT status LED, green (bus communication)
12		PWR status LED, green (supply voltage)

7.4.2 Basic circuit diagram




Figure 7-19 Basic circuit diagram for the RAD-DI4-IFS

7.4.3 Diagnostic LEDs

The RAD-DI4-IFS I/O extension module uses a total of seven LEDs to indicate the operating states.




Figure 7-20 Diagnostic LEDs of the RAD-DI4-IFS

PWR LED

The green PWR LED indicates the status of the supply voltage.

Off	No supply voltage
On	Supply voltage OK

DAT LED

The green DAT LED indicates the status of bus communication.

Off	No communication
Flashing	Configuration and addressing mode
On	Cyclic data communication

ERR LED

The red ERR LED indicates the error status, e.g., if a corresponding output module has not been found.

Off	No error
Flashing	
Slow (1.4 Hz)	I/O MAP address changed
Fast (2.8 Hz)	No bus communication
On	Critical internal error

DI1 ... DI4

The yellow DI1 ... DI4 LEDs indicate the state of the digital inputs.

7.4.4 Setting the I/O MAP address

Use the thumbwheel to set the I/O MAP address. The extension module in the Radioline wireless system is addressed using the I/O MAP address. Addresses 01 ... 99 (maximum) can be assigned for the I/O extension modules in the entire wireless network.

Table 7-7 Setting the I/O MAP address for the RAD-DI4-IFS

Thumbwheel	Description
01 ... 99	I/O MAP address
00	Delivery state
** , 1* ... 9*	Setting not permitted
*1 ... *9	Interface system slave address, for use with other interface system (IFS) master devices

7.4.5 Process data in PLC / Modbus/RTU mode

The process image of the I/O extension module consists of two data words. For additional information, please refer to Section "RAD-DI4-IFS process data" on page 72.

I/O module	Module type ID	Register	Address range	Function code
RAD-DI4-IFS	01 _{hex}	02 _{hex}	30xx0 ... 30xx1	fc 04

7.5 RAD-DI8-IFS - digital extension module with eight inputs

The RAD-DI8-IFS digital I/O extension module processes up to eight digital input signals or two pulse signals. You can use DIP switch 1 to set the operating mode. For more detailed information on setting the DIP switch, please refer to page 107.

The eight digital inputs are arranged in two groups of four inputs each with a common reference potential (GND). The two DC voltage groups are electrically isolated from one another, from the supply voltage, and from the electronics.

7.5.1 Structure




Figure 7-21 RAD-DI8-IFS structure

Item	Terminal block	Designation
1	3.1/3.2/3.3	Digital inputs 3 + 4
2	2.1/2.2/2.3	Digital inputs 1 + 2, DI1: pulse input 1
3		White thumbwheel for setting the I/O MAP address
4		DIP switches for switching between static mode and pulse counter mode for digital inputs
5		Connection option for DIN rail connector
6		DIN rail
7		Metal foot catch for DIN rail fixing
8	4.1/4.2/4.3	Digital inputs 5 + 6
9	5.1/5.2/5.3	Digital inputs 7 + 8, DI7: pulse input 2
10		Status LEDs for digital inputs DI1 ... DI8
11		CNT status LED, green (pulse counter mode)
12		ERR status LED, red (communication error)
13		DAT status LED, green (bus communication)
14		PWR status LED, green (supply voltage)

7.5.2 Basic circuit diagram




Figure 7-22 Basic circuit diagram for the RAD-DI8-IFS

7.5.3 Setting the DIP switches

Select static mode or pulse counter mode using the DIP switches on the front.

- In static mode, inputs DI1 ... DI8 are activated, 0 V ... 30.5 V DC voltage
- In pulse counter mode, pulse inputs DI1 and DI7 are activated, 0 Hz ... 100 Hz pulses



The pulse counter function is only available in PLC / Modbus/RTU mode and in dual mode. Set the operating mode using the PSI-CONF software (from page 35).




Figure 7-23 DIP switches of the RAD-DI8-IFS

Table 7-8 DIP switches of the RAD-DI8-IFS

Input	Output signal	DIP switch			
		1	2	3	4
Digital IN DI1 ... DI8	Static mode	OFF	n.c.	n.c.	n.c.
Counter IN DI1 + DI7	Pulse counter mode	ON	n.c.	n.c.	n.c.

n. c. = not connected, DIP switches 2 ... 4 have no function

- Use DIP switch 1 to select static mode or pulse counter mode.
- Disconnect the device from the supply voltage.
- Switch the supply voltage back on.
- The selected mode is now active.

7.5.4 Functions in pulse counter mode

The counter state can only increase consecutively. When the maximum counter limit of 4294967295 is reached, the counter state is automatically reset to 0.

There are also three ways to reset the counter state manually:

Via power up

- Disconnect the device power supply and then reconnect the voltage.

Via Modbus/RTU register

- Reset the counter states via Modbus/RTU as follows:
 - DI1: bit 0 = 1 (register 40xx1)
 - DI7: bit 1 = 1 (register 40xx1)

By setting the inputs

- Set the corresponding input for at least 0.5 seconds:
 - Set input **DI3** in order to reset counter state **DI1**.
 - Set input **DI5** in order to reset counter state **DI7**.

7.5.5 Diagnostic LEDs

The RAD-DI8-IFS I/O extension module uses a total of twelve LEDs to indicate the operating states.




Figure 7-24 Diagnostic LEDs of the RAD-DI8-IFS

PWR LED

The green PWR LED indicates the status of the supply voltage.

Off	No supply voltage
On	Supply voltage OK

DAT LED

The green DAT LED indicates the status of bus communication.

Off	No communication
Flashing	Configuration and addressing mode
On	Cyclic data communication

ERR LED

The red ERR LED indicates the error status.

Off	No error
Flashing	
Slow (1.4 Hz)	I/O MAP address changed or mode switched using DIP switch 1, but not yet applied
Fast (2.8 Hz)	No bus communication
On	Critical internal error

RAD-...-IFS**CNT LED**

The green CNT LED indicates that pulse counter mode is activated.

Off	No error
Flashing	Mode switched using DIP switch 1, but not yet applied
On	Pulse counter mode of digital inputs DI1 and DI7

DI1 ... DI8

The yellow DI1 ... DI8 LEDs indicate the state of the digital inputs.

In pulse counter mode: the DI1 and DI7 LEDs flash in time with the recorded pulses. The DI3 and DI5 LEDs light up when the counter state is reset.

DI3	ON (0.5 seconds)	Counter state DI1 reset to 0
DI5	ON (0.5 seconds)	Counter state DI7 reset to 0

7.5.6 Setting the I/O MAP address

Use the thumbwheel to set the I/O MAP address. The extension module in the Radioline wireless system is addressed using the I/O MAP address. Addresses 01 ... 99 (maximum) can be assigned for the I/O extension modules in the entire wireless network.

Table 7-9 Setting the I/O MAP address for the RAD-DI8-IFS

Thumbwheel	Description
01 ... 99	I/O MAP address
00	Delivery state
** , 1* ... 9*	Setting not permitted
*1 ... *9	Interface system slave address, for use with other interface system (IFS) master devices

7.5.7 Process data in PLC / Modbus/RTU mode

The process image of the I/O extension module consists of eight data words. For additional information, please refer to Section "RAD-DI8-IFS process data" on page 73.

I/O module	Module type ID	Register	Address range	Function code
RAD-DI8-IFS	02 _{hex} Static mode	02 _{hex} Static inputs	30xx0 ... 30xx1	fc 04
	40 _{hex} Pulse counter mode	06 _{hex} Pulse inputs	30xx0 ... 30xx5	fc 04
	40 _{hex} Pulse counter mode	02 _{hex} Reset of counter states	40xx0 ... 40xx1	fc 03, 16

7.6 RAD-DOR4-IFS - digital extension module with four outputs



WARNING: Risk of electric shock

Use the same phase for digital inputs and outputs. The isolating voltage between the individual channels must not exceed 300 V.

The RAD-DOR4-IFS digital I/O extension module can process up to four input signals that are switched via relay outputs. The digital outputs are designed as floating relay contacts (changeover contacts). All outputs are electrically isolated from one another, from the supply voltage, and from the electronics.

7.6.1 Structure




Figure 7-25 RAD-DOR4-IFS structure

Item	Terminal block	Designation
1	2.1/2.2/2.3	Relay output 2 with floating changeover contact
2	1.1/1.2/1.3	Relay output 1 with floating changeover contact
3		DIP switches for configuring the output behavior of the relay outputs (hold/reset)
4		White thumbwheel for setting the I/O MAP address
5		Connection option for DIN rail connector
6		DIN rail
7		Metal foot catch for DIN rail fixing
8	5.1/5.2/5.3	Relay output 3 with floating changeover contact
9	6.1/6.2/6.3	Relay output 4 with floating changeover contact
10		Status LEDs for relay outputs DO1 ... DO4
11		ERR status LED, red (communication error)
12		DAT status LED, green (bus communication)
13		PWR status LED, green (supply voltage)

7.6.2 Basic circuit diagram




Figure 7-26 Basic circuit diagram for the RAD-DOR4-IFS

7.6.3 Setting the DIP switches

You can use the DIP switches on the front to set the behavior of the outputs in the event of an error, e.g., interruption of the wireless connection. Any changes to the DIP switch settings will be applied immediately.

- RESET = output value is set to 0
- HOLD = hold the last output value




Figure 7-27 DIP switches of the RAD-DOR4-IFS

Table 7-10 DIP switches of the RAD-DOR4-IFS

Setting	Output signal	DIP switch			
		1	2	3	4
Digital OUT1	RESET	OFF			
	HOLD	ON			
Digital OUT2	RESET		OFF		
	HOLD		ON		
Digital OUT3	RESET			OFF	
	HOLD			ON	
Digital OUT4	RESET				OFF
	HOLD				ON

7.6.4 Diagnostic LEDs

The RAD-DOR4-IFS I/O extension module uses a total of seven LEDs to indicate the operating states.




Figure 7-28 Diagnostic LEDs of the RAD-DOR4-IFS

PWR LED

The green PWR LED indicates the status of the supply voltage.

Off	No supply voltage
On	Supply voltage OK

DAT LED

The green DAT LED indicates the status of bus communication.

Off	No communication
Flashing	Configuration and addressing mode
On	Cyclic data communication

RAD-...-IFS**ERR LED**

The red ERR LED indicates the error status, e.g., if a corresponding input module has not been found.

Off	No error
Flashing	
Slow (1.4 Hz)	I/O MAP address changed
Fast (2.8 Hz)	Wireless module in I/O data mode
	– Missing input module
	– No bus communication
	Wireless module in PLC / Modbus/RTU mode
	– No Modbus communication (safe state of outputs, depending on DIP switch setting)
On	Critical internal error

DO1 ... DO4

The yellow DO1 ... DO4 LEDs indicate the state of the digital outputs.

7.6.5 Setting the I/O MAP address

Use the thumbwheel to set the I/O MAP address. The extension module in the Radioline wireless system is addressed using the I/O MAP address. Addresses 01 ... 99 (maximum) can be assigned for the I/O extension modules in the entire wireless network.

Table 7-11 Setting the I/O MAP address for the RAD-DOR4-IFS

Thumbwheel	Description
01 ... 99	I/O MAP address
00	Delivery state
** , 1* ... 9*	Setting not permitted
*1 ... *9	Interface system slave address, for use with other interface system (IFS) master devices

Process data in PLC / Modbus/RTU mode

The process image of the I/O extension module consists of two data words. For additional information on the process data, please refer to Section "RAD-DOR4-IFS process data" on page 75.

I/O module	Module type ID	Register	Address range	Function code
RAD-DOR4-IFS	10 _{hex}	02 _{hex}	40xx0 ... 40xx1	fc 03, 16

7.7 RAD-DO8-IFS - digital extension module with eight outputs

The RAD-DO8-IFS digital I/O extension module processes up to eight digital output signals that are switched via transistor outputs. The eight outputs are arranged in two groups of four outputs each with a common supply. The two output groups are electrically isolated from one another, from the supply voltage, and from the electronics.

Since output groups DO1 ... DO4 and DO5 ... DO8 are electrically isolated, the outputs must be supplied externally (see Figure 7-30).

- Outputs DO1 ... DO4 are supplied via:
 - Terminal block 1.1 (12 V DC ... 30.5 V DC)
 - Terminal blocks 1.2/1.3 (GND)
- Outputs DO5 ... DO8 are supplied via:
 - Terminal block 6.1 (12 V DC ... 30.5 V DC)
 - Terminal blocks 6.2/6.3 (GND)

7.7.1 Structure




Figure 7-29 RAD-DO8-IFS structure

Item	Terminal block	Designation
1	3.1/3.2/3.3	Transistor outputs 3 + 4
2	2.1/2.2/2.3	Transistor outputs 1 + 2
3	1.1/1.2/1.3	Supply voltage for outputs 1 ... 4
4		DIP switches for setting the output behavior of the transistor outputs (hold/reset)
5		White thumbwheel for setting the I/O MAP address
6		Connection option for DIN rail connector
7		DIN rail
8		Metal foot catch for DIN rail fixing
9	4.1/4.2/4.3	Transistor outputs 5 + 6
10	5.1/5.2/5.3	Transistor outputs 7 + 8
11	6.1/6.2/6.3	Supply voltage for outputs 5 ... 8
12		Status LEDs of transistor outputs DO1 ... DO8
13		ERR status LED, red (communication error)
14		DAT status LED, green (bus communication)
15		PWR status LED, green (supply voltage)

7.7.2 Basic circuit diagram




Figure 7-30 Basic circuit diagram for the RAD-DO8-IFS

7.7.3 Setting the DIP switches

You can use the DIP switches on the front to set the behavior of the outputs in the event of an error, e.g., interruption of the wireless connection. Any changes to the DIP switch settings will be applied immediately.

- RESET = output value is set to 0
- HOLD = hold the last output value




Figure 7-31 DIP switches of the RAD-DO8-IFS

RAD-...-IFS

Table 7-12 DIP switches of the RAD-DO8-IFS

Setting	Output signal	DIP switch			
		1	2	3	4
Digital OUT 1 ... 4	RESET	OFF		n. c.	n. c.
Digital OUT 1 ... 4	HOLD	ON		n. c.	n. c.
Digital OUT 5 ... 8	RESET		OFF	n. c.	n. c.
Digital OUT 5 ... 8	HOLD		ON	n. c.	n. c.

n. c. = not connected, DIP switches 3 and 4 have no function

7.7.4 Diagnostic LEDs

The RAD-DO8-IFS I/O extension module uses a total of eleven LEDs to indicate the operating states.




Figure 7-32 Diagnostics LEDs of the RAD-DO8-IFS

PWR LED

The green PWR LED indicates the status of the supply voltage.

Off	No supply voltage
On	Supply voltage OK

DAT LED

The green DAT LED indicates the status of bus communication.

Off	No communication
Flashing	Configuration and addressing mode
On	Cyclic data communication

ERR LED

The red ERR LED indicates the error status, e.g., if a corresponding input module has not been found.

Off No error

Flashing **Wireless module in I/O data mode**

- Missing input module
- No bus communication

Wireless module in PLC / Modbus/RTU mode

- No Modbus communication (safe state of outputs, depending on DIP switch setting)
- Short circuit at one output or several outputs

On Critical internal error

DO1 ... DO8

The yellow DO1 ... DO8 LEDs indicate the state of the digital outputs.

DO1 ... DO4 Flashing Short circuit at one output or several outputs 1 ... 4

DO5 ... DO8 Flashing Short circuit at one output or several outputs 5 ... 8

7.7.5 Setting the I/O MAP address

Use the thumbwheel to set the I/O MAP address. The extension module in the Radioline wireless system is addressed using the I/O MAP address. Addresses 01 ... 99 (maximum) can be assigned for the I/O extension modules in the entire wireless network.

Table 7-13 Setting the I/O MAP address for the RAD-DO8-IFS

Thumbwheel	Description
01 ... 99	I/O MAP address
00	Delivery state
** , 1* ... 9*	Setting not permitted
*1 ... *9	Interface system slave address, for use with other interface system (IFS) master devices

7.7.6 Process data in PLC / Modbus/RTU mode

The process image of the I/O extension module consists of four data words. For additional information, please refer to Section “RAD-DO8-IFS process data” on page 76.

I/O module	Module type ID	Register	Address range	Function code
RAD-DO8-IFS	11 _{hex}	02 _{hex} Outputs	40xx0 ... 40xx1	fc 03, 16
		02 _{hex} Short circuit detection	30xx0 ... 30xx1	fc 04

7.8 RAD-DAIO6-IFS - analog/digital extension module with six channels



WARNING: Risk of electric shock

Use the same phase for digital inputs and outputs. The isolating voltage between the individual channels must not exceed 300 V.

The RAD-DAIO6-IFS analog/digital I/O extension module has a total of six channels. The device can process two digital input and output signals as well as one analog input signal and one analog output signal. All inputs and outputs are electrically isolated from one another, from the supply voltage, and from the electronics.

Two digital inputs

The digital inputs process voltages of 0 V ... 50 V AC/DC at the low voltage input and voltages of 0 V ... 250 V AC/DC at the high voltage input.

Two digital outputs

The digital outputs are designed as floating relay contacts (changeover contacts). The switching capacity is 2 A at 250 V AC/24 V DC.

Analog input

The analog input can process standard signals of 0/4 mA ... 20 mA. A supply voltage of at least 12 V DC is available at connection terminal block PWR₁ for passive sensors.

Analog output

The analog output is designed as an active output. You can select a current signal of 0/4 mA ... 20 mA or a voltage signal of 0 V ... 10 V.



Use either the current or voltage output at the analog output.

7.8.1 Structure




Figure 7-33 RAD-DAIO6-IFS structure

Item	Terminal block	Designation
1	3.1/3.2/3.3	Analog input for 2, 3, 4-wire measuring transducers
2	2.1/2.2/2.3	Digital input as wide-range input
3	1.1/1.2/1.3	Digital input as wide-range input
4		DIP switches for configuring the inputs and outputs
5		White thumbwheel for setting the I/O MAP address
6		Connection option for DIN rail connector
7		DIN rail
8		Metal foot catch for DIN rail fixing
9	4.1/4.2/4.3	Analog output, either current or voltage
10	5.1/5.2/5.3	Relay output with floating changeover contact
11	6.1/6.2/6.3	Relay output with floating changeover contact
12		Status LEDs of digital outputs DO1 ... DO2
13		Status LEDs of digital inputs DI1 ... DI2
14		ERR status LED, red (communication error)
15		DAT status LED, green (bus communication)
16		PWR status LED, green (supply voltage)

7.8.2 Basic circuit diagram




Figure 7-34 Basic circuit diagram for the RAD-DAIO6-IFS

7.8.3 Setting the DIP switches

The DIP switches on the front can be used to configure the input signal ranges. In addition, you can set the behavior of the outputs in the event of an error, e.g., interruption of the wireless connection. Any changes to the DIP switch settings will be applied immediately.

Analog output

- RESET = output value is set to 0
- HOLD = hold the last output value

Digital outputs

- RESET = relay drops out
- HOLD = hold the last valid state




Figure 7-35 DIP switches of the RAD-DAIO6-IFS

Table 7-14 DIP switches of the RAD-DAIO6-IFS

Setting	Output signal	DIP switch			
		1	2	3	4
Analog IN	0 mA ... 20 mA	OFF			
	4 mA ... 20 mA	ON			
Analog OUT	RESET		OFF		
	HOLD		ON		
Digital OUT1	RESET			OFF	
	HOLD			ON	
Digital OUT2	RESET				OFF
	HOLD				ON

7.8.4 Diagnostic LEDs

The RAD-DAIO6-IFS I/O extension module uses a total of seven LEDs to indicate the operating states.




Figure 7-36 Diagnostics LEDs of the RAD-DAIO6-IFS

PWR LED

The green PWR LED indicates the status of the supply voltage.

Off	No supply voltage
On	Supply voltage OK

DAT LED

The green DAT LED indicates the status of bus communication.

Off	No communication
Flashing	Configuration and addressing mode
On	Cyclic data communication

RAD-...-IFS**ERR LED**

The red ERR LED indicates the error status, e.g., if a corresponding output module has not been found.

Off	No error
Flashing	
Slow (1.4 Hz)	I/O MAP address changed
Fast (2.8 Hz)	Wireless module in I/O data mode
	– Missing input module
	– No bus communication
	Wireless module in PLC / Modbus/RTU mode
	– No Modbus communication (safe state of outputs, depending on DIP switch setting)
On	Critical internal error

DI1 / DI2

The yellow DI1 and DI2 LEDs indicate the state of the digital inputs.

DO1 / DO2

The yellow DO1 and DO2 LEDs indicate the state of the digital outputs.

7.8.5 Setting the I/O MAP address

Use the thumbwheel to set the I/O MAP address. The extension module in the Radioline wireless system is addressed using the I/O MAP address. Addresses 01 ... 99 (maximum) can be assigned for the I/O extension modules in the entire wireless network.

Table 7-15 Setting the I/O MAP address for the RAD-DAIO6-IFS

Thumbwheel	Description
01 ... 99	I/O MAP address
00	Delivery state
** , 1* ... 9*	Setting not permitted
*1 ... *9	Interface system slave address, for use with other interface system (IFS) master devices

7.8.6 Process data in PLC / Modbus/RTU mode

The process image of the I/O extension module consists of six data words. For additional information, please refer to Section “RAD-DAIO6-IFS process data” on page 77.

I/O module	Module type ID	Register	Address range	Function code
RAD-DAIO6-IFS	60 _{hex}	03 _{hex} (inputs)	30xx0 ... 30xx2	fc 04
		03 _{hex} (outputs)	40xx0 ... 40xx2	fc 03, 16

8 Planning wireless systems

8.1 Delay time

Delay time is understood to mean:

- **In I/O data mode:** delay until an input signal of the input module is output on the associated output module.
- **In serial data mode:** delay until a serial telegram is output via RS-232/RS-485 on the second wireless module via the serial interface.

Among other things, the delay time depends on the following factors:

- Frequency band used
2.4 GHz or 868 MHz, the higher the frequency, the lower the delay time.
- Utilization of the frequency band
The more wireless networks operating in the same frequency band, the higher the delay time.
- Network structure (e.g., star or mesh network)
The larger the network, the higher the delay time.
- Distance and set data rate of the wireless interface
The lower the data rate via the wireless interface, the higher the delay time.
- Data encryption
If data encryption is activated, the delay time increases.

RAD-...-IFS

The table below shows typical delay times that have been determined under laboratory conditions for frequency bands without any interference. The delay times may be higher or lower in practice. The delay time is roughly doubled with each repeater in the network.

Table 8-1 Typical delay times

Frequency band	Network application	Data rate of the serial interface [kbps]	Data rate of the wireless interface [kbps]	Typical delay time	Telegram length ¹
2.4 GHz	I/O data mode	-	250	150 ms	49 bytes
			125	200 ms	
			16	500 ms	
	Serial data mode	19.2	250	20 ms	
			125	25 ms	
			16	120 ms	
868 MHz	I/O data mode	-	120	300 ms	49 bytes
			60	500 ms	17 bytes
			19.2	1 s	
			9.6	2 s	
			1.2	10 s	
	Serial data mode	19.2	120	60 ms	49 bytes
			60	120 ms	17 bytes
			19.2	200 ms	
			9.6	390 ms	
			1.2	2.8 s	

¹ I/O data mode: the telegram length depends on the number of I/O extension modules.
Serial data mode: the telegram length depends on the protocol used and the terminal devices that are connected to the serial interface.

8.2 Pulse transmission

Due to the delay times in the wireless network (see “Delay time” on page 125), in I/O data mode, the digital inputs and outputs are only suitable for transmitting the state. The pulses should therefore be very slow and transmitted with a fixed duty cycle of 50%.

For fast pulse transmissions, e.g., in the case of flow meters, use the RAD-DI8-IFS I/O extension module in pulse counter mode (see “Setting the DIP switches” on page 107). You can record pulses up to 100 Hz in pulse counter mode.

The pulse counter function is only available in PLC / Modbus/RTU mode or in dual mode. Set the operating mode using the PSI-CONF software (from page 35).

In pulse counter mode, the master wireless module maintains a central 32-bit Modbus register with the counter state of the relevant pulse input. The Modbus register can be read and written by any PLC via Modbus/RTU.

8.3 Trusted Wireless 2.0

Phoenix Contact has developed Trusted Wireless 2.0 technology specifically for industrial applications. Trusted Wireless 2.0 operates in the license-free 2.4 GHz or 868 MHz frequency bands.

Features

- Robust communication thanks to the frequency hopping spread spectrum (FHSS) method
- Automatic and manual mechanisms for coexistence with other systems transmitting in the same frequency band
- Secure data encryption and authentication
- Long range thanks to high receiver sensitivity and variable data transmission rate
- Flexible network structure with automatic connection management
- Distributed network management
- Comprehensive diagnostic options
- Adaptations can be made to the relevant application

Frequency hopping spread spectrum (FHSS) method

Trusted Wireless 2.0 uses the frequency hopping spread spectrum (FHSS) method. In the 2.4 GHz frequency band, a selection of up to 127 channels from the entire spectrum of the frequency band is used. In the 868 MHz frequency band, up to 14 channels are available.

The wireless module “hops” between these channels on the basis of a pseudo-random pattern. This results in more robust and more reliable communication.

RF bands

Trusted Wireless 2.0 can be operated on different RF (radio frequency) bands. This enables the simultaneous use of several Trusted Wireless 2.0 systems.

Coexistence management (for 2.4 GHz only)

Blacklisting means that certain frequencies can be hidden selectively. For example, this method allows you to operate several WLAN systems in parallel with Trusted Wireless 2.0 systems without any performance limitations.

Data encryption and authentication

Trusted Wireless 2.0 is a proprietary technology. The protocol has not been published. Therefore it is better protected against attacks. In addition, two security mechanisms have been implemented with 128-bit AES data encryption and authentication. Data encryption makes sure that intercepted data packets are not “understood”. The authentication process checks the sender’s authenticity. For this, a continuous code is added to the message, which must not be repeated. A message that has been tampered with will be recognized as not valid and discarded.

Range

Distances up to several kilometers can be covered with Trusted Wireless 2.0. You can set the data rate of the wireless interface and adapt it to the relevant application. You can increase the sensitivity of the receiver and therefore the range by reducing the data rate.

The relationship between range and data rate can be illustrated by the energy per bit transmitted. The higher the energy per bit, the greater the achievable range. The energy per bit results from the ratio between transmission power and data rate:

energy per bit = transmission power / data rate

2.4 GHz and 868 MHz wireless systems have different characteristics due to the wavelength. Lower frequencies can overcome obstacles more easily. They also support longer ranges.




Figure 8-1 Penetration of obstacles at different frequencies

The 2.4 GHz and 868 MHz frequency bands are subject to various directives. 20 dBm (100 mW) maximum may be transmitted in the 2.4 GHz frequency band. In the 868 MHz frequency band, the transmission power may reach 27 dBm (500 mW). Due to the higher transmission power in the 868 MHz frequency band, longer ranges can also be achieved.

Duty cycle in the 868 MHz band

The duty cycle or holding period refers to the legally regulated period of use for the 869.4 MHz ... 869.65 MHz frequency band. The aim of this regulation is to ensure the function of all devices operating in this frequency band. The maximum transmission time is 10% of one hour (6 minutes). Usually, the duty cycle is not reached during operation, since only low volumes of data are transmitted.

Network structures

2.4 GHz wireless modules can be used to create network structures with up to 250 devices. Up to 99 devices are possible with 868 MHz wireless modules. In these network structures, each device has a repeater function for forwarding data.

In addition, the Trusted Wireless network is able to self-heal connection aborts (self-healing network). Alternative connection paths are initiated automatically. From a simple point-to-point connection to complex mesh networks, you can flexibly create various structures.




Figure 8-2 Point-to-point connection, star network, self-healing mesh network

Distributed network management

Technologies such as WirelessHART or ZigBee use centralized network management. That means that all messages pass through a central manager, which can lead to a significant volume of wireless network traffic.

Trusted Wireless 2.0 on the other hand uses distributed network management. This involves creating “parent-child zones” in the wireless network where the higher-level wireless module is referred to as the “parent” and the wireless modules connected to it as “children”. All network management takes place within the parent-child zone and therefore does not have to be directed through the central manager. This reduces the message traffic volume and speeds up data exchange.




Figure 8-3 Distributed network management with parent-child zones

8.4 RF bands

2.4 GHz

Data rates and RF bands do not depend on the network topology.




Figure 8-4 RF bands in the 2.4 GHz wireless system

868 MHz

The number of RF bands depends on the network topology and the over-the-air (OTA) data rate.




Figure 8-5 RF bands in the 868 MHz wireless system

8.5 Planning wireless paths

Wireless planning enables you to determine whether the wireless system is suitable for the intended application. The three essential requirements for wireless systems are:

- Range
- Data rate
- Stability

These three factors influence one another.

When planning wireless paths over large distances, you need to consider elevation variations. A topographic map or a GPS device are very helpful in this regard. Using GPS devices, you can indicate variations in elevation and measure distances by means of way-points. You can use the GPS device as a direction indicator when aligning the antennas later on.

Theoretical planning

The following questions should be considered during theoretical planning:

- What signals are to be transmitted?
- What points are the signals to be transmitted between?
- What is the distance between these points?
- Are there any topographic or structural obstacles?
- Are you able to circumvent these obstacles, e.g., by means of a repeater or higher mast?

When evaluating the data, a system calculation can be carried out to determine whether the wireless path is theoretically possible. A calculation example can be found from page 148 onwards.

8.6 Practical test

To check the theoretical results, you should carry out an on-site practical test before purchasing a wireless system. Check the location for master, slave, and repeater/slave modules based on the following criteria in order to achieve the best possible wireless connection:

- Position of the antenna with a line of sight and adequate signal strength
- A primary power source for energy supply is available
- Protection of wireless modules against the effects of weather and extreme ambient conditions
- Adequate access to the antenna, surge protection, interface, and other required cables

These requirements can be quickly assessed in most applications. Positioning the antenna is usually the only difficult task. Of course, a connection path without any obstacles would be perfect. However, small obstacles in the Fresnel zone will not necessarily disturb communication. In general, obstacles in the way on long wireless paths have a greater influence than those on short ones.

8.7 Selecting antenna cables and antennas

When installing a wireless system, it is very important that you use low-loss coaxial cables. Using an unsuitable cable may lead to considerable loss in performance which cannot be compensated by high antenna gain or by high transmission power. For every 3 dB of coaxial cable loss, half the transmission power will be lost before reaching the antenna. The received signal will also be reduced.

Consider the following factors when selecting the cable:

- Cable length to the antenna
- Acceptable signal loss
- Options for routing the cables

Antennas

- Select the antenna according to the wireless system and the required range.

Table 8-2 Application of antennas

Range	Antenna, 2.4 GHz	Antenna, 868 MHz
Short range and direct line of sight without any obstacles	Small omnidirectional antenna	-
Medium range	Large omnidirectional antenna (note the vertical opening angle)	
Long range	Directional antenna (note the small horizontal opening angle)	

In addition, the different antenna types are suitable for the following areas of application:

Omnidirectional antenna

- Numerous devices in different directions, e.g., in mesh networks or networks with repeaters
- Freely mobile applications
- Applications without a line of sight
In reflective environments the signal can be received via an indirect route.

Directional antenna

- Large distances
- Point-to-point connections
- Stationary or linear mobile applications
- Multiple point-to-point paths, decoupling due to directivity and different polarization levels (see Figure 8-7)

8.8 Installing antennas


WARNING: Explosion hazard when used in potentially explosive areas

Observe the installation instructions for the antenna and the Section “For your safety” on page 7.


NOTE: Malfunction

- The wireless module must be located at a distance of at least 3 cm from the installed antenna.
- Observe the installation instructions from the antenna manufacturer to ensure that the directional antennas or omnidirectional antennas will function properly.

The following recommendations apply to all antenna installations:

- Install the antenna in an open area as far away as possible from any obstacles such as buildings, dense deciduous forest or metal objects. Select a location that ensures a free signal path in the direction of the partner antenna.
- If two antennas are located in the same place, the distance between them should be at least 0.6 m in the vertical direction and 1 m in the horizontal direction. In the case of 868 MHz wireless systems, the required minimum distance should be even greater as the transmission power is higher.
- Make sure that you select the correct antenna characteristics at both ends of the wireless path. You can also combine omnidirectional antennas and directional antennas.

Table 8-3 Antenna characteristics

Antenna	Comparable to ...
Omnidirectional antenna	Light bulb
Directional antenna	Flashlight
Powerful directional antenna, e.g., Yagi or parabolic antenna	Laser pointer

- Note the polarization of the antenna. Most systems use a vertically polarized omnidirectional antenna at the master station. The partner antennas must therefore also be polarized vertically. Vertical polarization means that the elements are aligned vertically to the horizon. Crossing polarization between the stations results in signal loss (see Table 8-4).




Figure 8-6 Antenna polarization

- In a highly reflective environment: use antennas with circular polarization. This will avoid polarization losses. You can also combine circularly and vertically polarized antennas.

Table 8-4 Polarization of transmitter/receiver antennas

Polarization	Horizontal	Vertical	Circular clockwise	Circular counter-clockwise
				
Horizontal 	Yes	No	Yes, but 3 dB loss	Yes, but 3 dB loss
Vertical 	No	Yes	Yes, but 3 dB loss	Yes, but 3 dB loss
Circular clockwise 	Yes, but 3 dB loss	Yes, but 3 dB loss	Yes	No
Circular counter-clockwise 	Yes, but 3 dB loss	Yes, but 3 dB loss	No	Yes

- If you operate several wireless paths directly next to one another in parallel, you can alternately align directional antennas horizontally and vertically. The signals of the various wireless paths will therefore be decoupled.




Figure 8-7 Decoupling of wireless paths due to directivity and different polarization levels

8.8.1 Outdoor installation of antennas

Antenna cables and antennas are directly exposed to atmospheric discharge. The antennas and the entire infrastructure should therefore be protected against discharge. Protective devices with Lambda/4 technology are usually used for this. These surge protective devices have a coaxial design. They are suitable for all standard transmission systems. Low attenuation and high bandwidth are simultaneously achieved by means of low-capacitance protective circuits. Thanks to excellent impedance matching, surge protection does not distort the useful signal.

- Use surge protection for installation outdoors.
 - **For RAD-2400-IFS...**: CN-LAMBDA/4-5.9-BB, Order No. 2838490
 - **For RAD-868-IFS**: CN-LAMBDA/4-2.2-BB, Order No. 2800024
- The antenna is grounded via the surge protection device.
- The antenna mast must be grounded in accordance with national regulations.
- In outdoor applications, use RAD-TAPE-SV-19-3 vulcanizing sealing tape (Order No. 2903182) to protect adapters, cable connections, etc.
- Run the antenna cable inside the mast or fasten it to the outside of the mast with UV-resistant cable binders.




Figure 8-8 Outdoor installation of antennas

- 1 Omnidirectional antenna
- 2 Antenna cables
- 3 Antenna mast
- 4 Antenna surge protection
- 5 Control cabinet
- 6 Power supply, wireless module, and I/O extension modules

8.8.2 Aligning directional antennas

- First, align the antennas roughly. Use the following:
 - Topographic map
 - GPS device or compass
 - LED bar graph on the wireless module

In this way, you can find the alignment point even if there is no direct line of sight.

- Having carried out a rough alignment, you can now align the antenna precisely using the RSSI voltage. Measure the RSSI voltage at the RSSI test socket of the wireless module (2.1/2.2) using a multimeter. For additional information on the RSSI voltage, please refer to page 47.
- You always have to align both antennas with each other, because the radio waves need to radiate into the antennas.
- In particular with regard to directional antennas, it is important to ensure that the antenna is properly secured. If the antenna sways in the wind, the transmission or reception beam can move out of its target area (see Figure 8-15).

8.9 Level and attenuation of wireless modules and accessories

Keep the connection between the wireless module and the antenna as short as possible. Every extension or adapter cable (pigtail) will cause higher attenuation.

You can calculate the level and attenuation of the wireless devices and accessories using the table below. The total cable attenuation including connectors is specified in the table.

Table 8-5 Level and attenuation of the wireless devices and accessories

Trusted Wireless	Wireless module	Order No.	Max. transmission power	Connection
2.4 GHz	RAD-2400-IFS	2901541	20 dBm	RSMA (f)
	RAD-2400-IFS-JP	2702863		
868 MHz	RAD-868-IFS	2904909	27 dBm	

Adapter and cable	Connection	Order No.	Attenuation at 2.4 GHz	Attenuation at 868 MHz	Length
Pigtail, adapter					
RAD-PIG-RSMA-N-EX/ATEX, RG316	N(f) - RSMA(m)	2904788	-1.3 dB	-0.6 dB	0.76 m
RAD-PIG-EF316-N-RSMA, EF316	N(f) - RSMA(m)	2701402	-0.9 dB	-0.6 dB	0.5 m
FL LCX PIG-EF142-N-N, EF142	N(m) - N(m)	2700677	-0.5 dB	-0.3 dB	0.5 m
Antenna cable - EF393					
RAD-CAB-EF393-3M	N(m)	2867649	-1.8 dB	-1 dB	3 m
RAD-CAB-EF393-5M	N(m)	2867652	-2.9 dB	-1.6 dB	5 m
RAD-CAB-EF393-10M	N(m)	2867665	-5.6 dB	-2.9 dB	10 m
RAD-CAB-EF393-15M	N(m)	2885634	-8.3 dB	-4.3 dB	15 m

RAD-...-IFS

Adapter and cable [...]	Connection [...]	Order No. [...]	Attenuation at 2.4 GHz	Attenuation at 868 MHz	Length [...]
Antenna cable - LMR195					
RAD-PIG-RSMA/N-0.5	RSMA - N(m)	2903263	-0.5 dB	-0.4 dB	0.5 m
RAD-PIG-RSMA/N-1	RSMA - N(m)	2903264	-0.8 dB	-0.5 dB	1 m
RAD-PIG-RSMA/N-2	RSMA - N(m)	2903265	-1.3 dB	-0.9 dB	2 m
RAD-PIG-RSMA/N-3	RSMA - N(m)	2903266	-2 dB	-1.2 dB	3 m
RAD-PIG-RSMA/N-5	RSMA - N(m)	2702140	-3.3 dB	-2 dB	5 m
Adapter					
RAD-ADP-N/F-N/F	N(f) - N(f)	2867843	-0.3 dB	-0.3 dB	-
RAD-ADP-RSMA/M-RSMA/F-90	RSMA(m) - RSMA(f), angled 90°	2904790	-0.3 dB	-0.3 dB	-
Splitter					
RAD-SPL-2-N/N	3 x N(f)	2702293	-0.3 dB	-0.3 dB	
2.4 GHz surge protection					
CN-LAMBDA/4-5.9-BB	N(f) - N(f)	2838490	<-0.15 dB	<-0.15 dB	-
868 MHz surge protection					
CN-LAMBDA/4-2.2-BB	N(f) - N(f)	2800024	<-0.15 dB	<-0.15 dB	

Antenna	Connection	Order No.	Gain	Remark
2.4 GHz omnidirectional antenna				
RAD-ISM-2400-ANT-OMNI-2-1-RSMA	RSMA(m)	2701362	2.1 dBi	2.1 dBi - 2.1 dB (1.5 m cable, RG316)
RAD-ISM-2400-ANT-VAN-3-0-RSMA	RSMA(m)	2701358	3 dBi	3 dBi - 1.5 dB (1.5 m cable, EF316)
ANT-OMNI-2459-02	N(m)	2701408	2.5 dBi	
RAD-ISM-2459-ANT-FOOD-6-0	N(f)	2692526	6 dBi	-
RAD-ISM-2400-ANT-OMNI-6-0	N(f)	2885919	6 dBi	-
RAD-ISM-2400-ANT-OMNI-9-0	N(f)	2867623	9 dBi	-
868 MHz omnidirectional antenna				
ANT-OMNI-868-01	N(f)	2702136	4 dBi	
RAD-900-ANT-OMNI-2-N	N(f)	2904802	2 dBi	
2.4 GHz directional antenna				
ANT-DIR-2459-01	N(f)	2701186	9 dBi	-
RAD-ISM-2400-ANT-PAR-19-0	N(f)	2867885	19 dBi	-
868 MHz directional antenna				
ANT-DIR-868-01	N(f)	2702137	3.5 dBi	
RAD-ISM-900-ANT-YAGI-6.5-N	N(f)	2867814	8.5 dBi	
RAD-ISM-900-ANT-YAGI-10-N	N(f)	5606614	12 dBi	

8.10 Free space attenuation

When using wireless transmission technology, the signal between the transmitter and receiver is attenuated by the air. The following table lists attenuation values for different distances with a free Fresnel zone.

Table 8-6 Free space attenuation

Distance	Attenuation at 2.4 GHz	Attenuation at 868 MHz
5 m	-54 dB	...
10 m	-60 dB	...
20 m	-66 dB	...
30 m	-69.5 dB	...
50 m	-74 dB	...
100 m	-80 dB	-71.2 dB
110 m	-80.8 dB	...
120 m	-81.6 dB	...
150 m	-83.5 dB	...
200 m	-86 dB	-77.2 dB
250 m	-88 dB	...
300 m	-89.5 dB	-80.7 dB
350 m	-90.9 dB	...
400 m	-92 dB	-83.2 dB
450 m	-93.1 dB	...
500 m	-94 dB	-85.1 dB
550 m	-94.8 dB	...
600 m	-95.6 dB	-86.7 dB
650 m	-96.3 dB	...
700 m	-96.9 dB	-88.1 dB
750 m	-97.5 dB	...
800 m	-98.1 dB	-89.2 dB
850 m	-98.6 dB	...
900 m	-99.1 dB	-90.3 dB
950 m	-99.6 dB	...
1000 m	-100 dB	-91.2 dB
2000 m	-	-97.2 dB
3000 m	-	-100.7 dB
4000 m	-	-103.2 dB
5000 m	-	-105.1 dB
6000 m	-	-106.7 dB
7000 m	-	-108.1 dB
8000 m	-	-109.2 dB

Table 8-6 Free space attenuation

Distance [...]	Attenuation at 2.4 GHz [...]	Attenuation at 868 MHz [...]
9000 m	-	-110.3 dB
10 km	-	-111.2 dB
11 km	-	-112 dB
12 km	-	-112.8 dB
13 km	-	-113.4 dB
14 km	-	-114.1 dB
15 km	-	-114.7 dB
16 km	-	-115.3 dB
17 km	-	-115.8 dB
18 km	-	-116.3 dB
19 km	-	-116.7 dB
20 km	-	-117.2 dB
21 km	-	-117.6 dB
22 km	-	-118.1 dB
23 km	-	-118.5 dB
24 km	-	-118.8 dB
25 km	-	-119.2 dB

General formula: **free space attenuation [dB] = 32.4 + 20 x log(f) + 20 x log(d)**

Formula for 2.4 GHz: **free space attenuation [dB] = 100 + 20 x log(d)**

Formula for 868 MHz: **free space attenuation [dB] = 91.17 + 20 x log(d)**

f = transmission frequency in MHz

d = distance between the antennas in km

The free space attenuation is later included in the system calculation (see Section "Equivalent isotropically radiated power (EIRP)" on page 147).

8.11 Propagation of radio waves

In addition to free space attenuation, there are other factors which influence the wireless path. Dispersion, diffraction, and reflection represent types of interference that occur when the wireless signal encounters obstacles. They result in multipath propagation.

Dispersion

Dispersion of the wireless signal, e.g., at a tree, means that the wireless signal is dispersed in several directions. A bare tree will let signals through almost completely. However, a tree with leaves will scatter the signals considerably. The leaf surfaces disperse the wireless signal in many different directions.




Figure 8-9 Dispersion on a rough surface

Diffraction

Diffraction of the wireless signal, e.g., on edges and obstacles, involves the signal being refracted around the edge. The signal then changes its direction. This is similar to the refraction of light in a crystal.




Figure 8-10 Diffraction on an edge

Reflection

Reflection on a smooth metal surface involves virtually the entire wireless signal being reflected at the same angle. In certain applications, the reflection may have a positive effect, e.g., if there is no line of sight. Reflections mainly occur in buildings.




Figure 8-11 Reflection on a metal surface

Penetration

The type of wall encountered also influences the attenuation of the wireless signal. The following constructions adversely affect the wireless signal, for example:

- Hollow lightweight walls with aluminum-lined insulation
- False ceilings with metal or carbon fiber panels
- Lead glass
- Insulation glass (Thermopen)
- Glass with a metal coating
- Steel objects
- Fire walls
- Elevator shafts and staircases

Each material has a different degree of attenuation. However, the following typical values provide a rough guide.

Table 8-7 Attenuation of different materials

Obstacle	Typical attenuation at 2.4 GHz [dB]	Typical attenuation at 868 MHz [dB]
Wood, plaster, glass, plastic, uncoated, without metal	3 ... 4	1 ... 2
Brick, chip board	3 ... 5	1 ... 3
Brick wall, 16 cm	6 ... 8	2 ... 4
Concrete wall, 16 cm	15 ... 20	9 ... 11
Reinforced concrete wall, 16 cm	20 ... 30	11 ... 20
Forest, 1 m, see 8.16 "Practical examples"	9 ... 14	4 ... 8
Heat-absorbing glass with metal coating	40 ... 50	30 ... 40




Figure 8-12 Reduction of radio waves when penetrating a wall

Also observe the angle between the transmitter and receiver. Depending on the angle, the radio waves have to penetrate more or less material.




Figure 8-13 Angle of the transmitter and receiver

Radio dead spot

Radio dead spots are caused by impenetrable obstacles in the wireless path. A radio dead spot can be compared to the shadow cast by the sun. If the receiver is located in a radio dead spot, no direct radio waves can reach it. It can only receive reflections or diffracted waves.




Figure 8-14 Radio dead spot

Weather influences

Snow, rain or hail only have a small effect on the wireless signal. With rainfall of 50 liters per square meter, i.e., a cloudburst, attenuation of around 0.02 dB/km occurs at a frequency of 2.4 GHz, for example.

Strong wind does not influence the wireless signal, however, it does mean that the antenna must be securely fixed in place. Especially when using directional antennas with a small opening angle, you should make sure that the antenna cannot be moved by the wind. Moving the antenna away from its original position, even by a few centimeters only, may result in a partial loss of the wireless signal on long transmission paths.




Figure 8-15 Wireless path with strong wind

8.12 Fresnel zone

A certain area between the transmitting and receiving antennas on the wireless path is referred to as the Fresnel zone. There should be a line of sight between the antennas, especially when covering large distances. In order to stay within the Fresnel zone, it might be necessary to install the antennas at a height of a few meters. This area should also be free from any other obstacles.

The ideal wireless path with a direct line of sight between transmitter and receiver is not always possible. In real-life applications, obstacles that affect the wireless channel often have to be taken into account. The wireless path can work even if obstacles such as houses and trees are within the Fresnel zone. The decisive factor is the number of obstacles and the area they occupy in the Fresnel zone. In this case, test measurements should be performed.

Inside buildings, e.g., in conventional automation environments, there is a predominance of reflections. They contribute to a good wireless connection even if the Fresnel zone is not free from obstacles.

The following figure shows the Fresnel zone between two antennas. The required mounting height for the antennas depends on the radius of the Fresnel zone.




Figure 8-16 Fresnel zone

Table 8-8 Radius of the Fresnel zone depending on the distance

Wireless path distance (d)	Radius of the Fresnel zone (r) for 2.4 GHz	Radius of the Fresnel zone (r) for 868 MHz
200 m	1.5 m	4.2 m
500 m	4 m	6.6 m
1000 m	5 m	9.3 m
2000 m	8 m	13.1 m
4000 m	11 m	18.6 m
5000 m	-	20.8 m
10 km	-	24.4 m
15 km	-	36 m
20 km	-	41.5 m
25 km	-	46 m

General formula for calculating the diameter of the Fresnel zone:

$$r = 0.5 \times \sqrt{\lambda \times d}$$

r = radius of the Fresnel zone

λ = wavelength (0.125 m for 2.4 GHz, 0.345 m for 868 MHz)

d = distance between the antennas in m

Radius of the Fresnel zone for 2.4 GHz and d = 3000 m:

$$r = 0.5 \times \sqrt{0.125 \times 3000}$$

$$r = 9.68 \text{ m}$$

Result: the radius of the Fresnel zone is 9.68 m at a wavelength of 0.125 m (2.4 GHz) and a distance of 3000 m between the antennas.

8.13 Range

Specifying ranges is very difficult due to the influence of various factors. Based on practical tests, it is possible to provide the following guide values. They may be significantly higher or lower depending on the actual application.

The range depends on the following:

- Set data rate
 - 2.4 GHz: a default setting of 125 kbps
 - 868 MHz: a default setting of 9.6 kbps
- Length of the antenna cable
- Antenna used
- Line of sight
- Adherence to the Fresnel zone

Table 8-9 Ranges for different antennas at 2.4 GHz

Antenna, 2.4 GHz	Data rate of the wireless interface	Range
Inside buildings		
Omnidirectional antenna, 2 dBi	≤250 kbps	50 m ... 100 m
	≤125 kbps	100 m ... 200 m
Outside buildings, with a free line of sight		
Omnidirectional antenna, 2 dBi	≤250 kbps	50 m ... 100 m
	≤125 kbps	100 m ... 200 m
Omnidirectional antenna, 6 dBi	≤125 kbps	≤1500 m (Europe: ≤1000 m)
Panel antenna, 8 dBi or 9 dBi	≤125 kbps	≤3000 m (Europe: ≤2000 m)
	16 kbps	≤5000 m (Europe: ≤3000 m)
Parabolic antenna, 19 dBi	16 kbps	>5000 m (Europe: >3000 m)

Table 8-10 Ranges for different antennas at 868 MHz

Antenna, 868 MHz	Data rate of the wireless interface	Maximum range
Outside buildings, with a free line of sight		
Omnidirectional antenna, 4 dBi	120 kbps	4 km
	60 kbps	5 km
	19.2 kbps	8 km
	9.6 kbps	9 km
	1.2 kbps	11 km

Table 8-10 Ranges for different antennas at 868 MHz

Antenna, 868 MHz [...]	Data rate of the wireless interface	Maximum range [...]
Panel antenna, 4 dBi	120 kbps	5 km
	60 kbps	6 km
	19.2 kbps	9 km
	9.6 kbps	10 km
	1.2 kbps	13 km
Yagi directional antenna, 8 dBi	120 kbps	7 km
	60 kbps	8 km
	19.2 kbps	12 km
	9.6 kbps	15 km
	1.2 kbps	18 km
Yagi directional antenna, 12 dBi	120 kbps	8 km
	60 kbps	10 km
	19.2 kbps	15 km
	9.6 kbps	20 km
	1.2 kbps	25 km

8.14 Equivalent isotropically radiated power (EIRP)

The equivalent isotropically radiated power (EIRP) is a gauge of the radiation power of an antenna. The EIRP value is the sum of the transmission power in dBm and the antenna gain in dBi.

Example at 2.4 GHz:

- Transmission power = 14 dBm
- Antenna gain = 8 dBi
- Cable attenuation (3 m EF 142) = 2.85 dB

- $EIRP = 14 \text{ dBm} + 8 \text{ dBi} - 2.85 \text{ dB} = 19.15 \text{ dBm}$

The EIRP depends on the frequency used. You may not exceed the following maximum EIRP for legal reasons.

- For 2.4 GHz:
 - Maximum of 20 dBm outside Europe
 - Maximum of 19 dBm in Europe, depending on the set transmission rate
- For 868 MHz:
 - Maximum of 27 dBm

- If the maximum EIRP is exceeded, adapt the cable, adapter or transmission power, if necessary.

8.15 System calculation in free space




Figure 8-17 Free space attenuation

- Antenna gain per antenna: 8 dBi
- Transmission power per wireless module: 14 dBm
- Cable attenuation per cable (3 m EF 142): 2.85 dB
- Free space attenuation, 400 m: 92 dB

Example calculation for 2.4 GHz with optimum free space:

- Length of the wireless path: 400 m
- Device transmission power + antenna gain - cable attenuation (EIRP): ≤ 20 dBm

EIRP [dBm] =
 transmitter power [dBm]
 + gain of transmitting antennas [dBi]
 - loss of the transmitter cable [dB]

Incoming power for the receiver [dBm] =
 transmitter power [dBm]
 - loss of the transmitter cable [dB]
 + gain of the transmitting antenna [dBi]
 - free space attenuation [dB]
 + gain of the receiving antenna [dBi]
 - attenuation of the antenna cable at the receiver [dBm]

System reserve =
 receiver sensitivity [dBm]
 - incoming power for the receiver [dBm]

(recommended system reserve > 10 dB)

- EIRP = 19.15 dBm
- Free space attenuation, D_L [dB]:
 $D_L = 32.4 + 20\log(R[\text{km}]) + 20\log(f[\text{MHz}]) = 32.4 + 20\log(0.4 \text{ km}) + 20\log(2400 \text{ MHz})$
 $= -92 \text{ dB}$
- Incoming power at the receiver = -67.7 dBm
- Receiver sensitivity = -96 dB (with a data rate of 125 kbps)
- System reserve = $-96 \text{ dB} - (-67.7 \text{ dB}) = 28.3 \text{ dB}$
 $28.3 \text{ dB} > 10 \text{ dB}$

Conclusion: The loss of -67.7 dB is significantly lower than the receiver sensitivity of -96 dB. The desired wireless connection is therefore possible in mathematical terms.

8.16 Practical examples

It is not possible to provide basic calculation principles for obstacles on the wireless path as the obstacles and applications will vary too much. The practical examples given below are for guidance only. They cannot be directly transferred to other applications.

The bush illustrated below is 2 m wide and has an attenuation of approximately 15 dB at 2.4 GHz. At 868 MHz, the attenuation is around 8 dB.



Figure 8-18 Bush with an attenuation of approximately 15 dB

The forest illustrated below consists of dense undergrowth with a trunk diameter of approximately 5 cm to 20 cm. In our test, the 2.4 GHz wireless signal was transmitted through a 25 m forest. The attenuation was around 40 dB. At 868 MHz, the attenuation is around 22 dB.



Figure 8-19 Forest with an attenuation of around 40 dB

RAD-...-IFS

9 Detecting and removing errors

If your wireless system does not function properly, proceed as follows:

- First, make sure that a good wireless signal is available (1 green bar graph LED or RSSI voltage ≥ 1.5 V).
- Check the status of the individual stations:
 - If the PSI-CONF software is installed, check the device status of all network devices via online diagnostics.
 - If the PSI-CONF software has **not** been installed, check the bar graph LEDs on the front of each device.
- Find the error using the tables from page 152 onwards.



- Avoid contact between the antennas of two wireless modules, otherwise the receiver might become overloaded.
- Ground loops are caused by grounding of the antenna via the antenna fixing unit, grounding of the power supply, or grounding of the serial interface. To avoid ground loops, connect these components to a single ground point.

Strength of the receive signal

You can determine the strength of the receive signal by means of the RSSI voltage. The signal strength is displayed on the LED bar graph on the wireless module.

- In a point-to-point connection, the LED bar graph is active on the master and on the repeater/slave.
- In a wireless network with more than one repeater/slave, only the yellow LED on the master is permanently on. The signal strength in the master direction is indicated on the repeaters/slaves. The signal strength always relates to the directly connected, overlapping wireless module.

The RSSI indicator is a voltage output in the range from 0 V DC ... 3 V DC. The higher the voltage, the better the wireless connection. The measured voltage is directly related to the receive signal in -dB. However, please observe the small voltage fluctuation due to multipath propagation.

The recommended minimum signal strength is 1.5 V DC. This results in a power reserve of around 10 dB, which ensures communication even in unfavorable transmission conditions.

You can measure the RSSI voltage at the RSSI test socket or read it using the PSI-CONF software. When connecting the master wireless module to a PC, you can read the RSSI voltages on the entire wireless network. On a slave or repeater, it is only possible to read the RSSI voltage of the connected wireless module.



For more information on the RSSI voltage, please refer to Table 4-7 and Table 4-8.

RAD-...-IFS

Table 9-1 Detecting and removing errors: wireless module

LED, wireless module	Current state and possible cause	Solution
-	Wireless module cannot be configured using the PSI-CONF software.	• Make sure that the wireless module is supplied with power. • Make sure that you are using the correct cable: – RAD-CABLE-USB (Order No. 2903447), energy supply via the USB port on the PC – IFS-USB-DATACABLE (Order No. 2320500), external power supply • Install the USB driver. The driver is installed automatically during PSI-CONF software installation (see page 38).
PWR off	No power supply, mains probably switched off.	• Switch on the mains, restore the power supply.
DAT off	No communication between wireless module and I/O extension module. Wireless module probably in "serial data" mode.	• Check whether the I/O extension module is properly snapped onto the DIN rail connector and whether it is connected to the wireless module. • Check the operating mode of the wireless module using the PSI-CONF software. The wireless module must be in "I/O data", "PLC / Modbus/RTU" mode or in dual mode (see page 38). • Reset the wireless module to the default settings (I/O data mode), if necessary. To do so, disconnect the device from the supply voltage, hold down the SET button, and switch the supply voltage on again (see page 30).
ERR on	Local bus error The input or output module is disconnected from the DIN rail connector and the bus.	• Check whether the I/O extension module is properly snapped onto the DIN rail connector. • Press the SET button on the front of the wireless module or carry out a power up. The data of the I/O extension modules is read again.
ERR flashing DAT flashing	Writing to the memory stick did not work.	• Repeat the process in order to correctly write to the memory stick.

Detecting and removing errors

Table 9-1 Detecting and removing errors: wireless module

LED, wireless module	Current state and possible cause	Solution
ERR flash- ing fast (2.8 Hz), bar graph does not light up	No wireless connection, even though the wireless modules are not far away from each other	• Make sure that in a network only one wireless module is configured as the master (RAD ID = 01) and all other wireless modules are slaves or repeaters. Reconfigure the wireless network, if necessary. • Check whether the set RAD ID is a permitted address. • Make sure that each RAD ID (yellow thumbwheel) only occurs once in the network. • There may be an overload problem: by default upon delivery, the receive preamplifier is activated. The transmission power is set so that the devices can cover the greatest possible distances. If the devices are operated directly next to one another the receiver may therefore become overloaded. In this case, remove the antennas, increase the distance between the devices and antennas or reduce transmission power using the PSI-CONF software (from page 38 onwards). • Using the PSI-CONF software, check whether the network parameters have the same settings on all wireless modules (operating mode, network ID, RF band, data rate of the wireless interface, encryption, network type, from page 38 onwards). • Reset the wireless module to the default settings (I/O data mode), if necessary. To do so, disconnect the device from the supply voltage, hold down the SET button, and switch the supply voltage on again (see page 30).
	No wireless connection, the wireless modules are far away from each other	• Check whether the antennas are connected and aligned properly. • Make sure that the antenna connections are tight and free from corrosion. • Install the antenna at a higher point. Adhere to the Fresnel zone. • Use a different antenna with higher antenna gain or use shorter cables with lower signal attenuation. • Check whether there is another transmitting antenna in close proximity. Position the antenna further away from all other antennas (at least 1 m in the horizontal direction or 0.6 m in the vertical direction). • Make sure that the power supply is sufficiently high. • Make sure that there is no connection between the core and the shield of the cable in the connected antenna system.

RAD-...-IFS

Table 9-1 Detecting and removing errors: wireless module

LED, wireless module	Current state and possible cause	Solution
LED bar graph, only yellow LED is on	Connection with low receive signal	• Check whether the antennas are connected and aligned properly. • Make sure that the antenna connections are tight and free from corrosion. • Install the antenna at a higher point. Adhere to the Fresnel zone. • Use a different antenna with higher antenna gain or use shorter cables with lower signal attenuation. • Check whether there is another transmitting antenna in close proximity. Position the antenna further away from all other antennas (at least 1 m in the horizontal direction or 0.6 m in the vertical direction). • Make sure that the power supply is sufficiently high. • Make sure that there is no connection between the core and the shield of the cable in the connected antenna system.
	Several repeaters/slaves at the master wireless module	• No action required, normal display for a wireless network with more than one repeater/slave. The signal strength is displayed on the repeaters/slaves. The signal strength always relates to the directly connected, overlapping wireless module.
In I/O data mode		
ERR flashing slowly (1.4 Hz)	Double assignment of the I/O MAP address, two input modules have the same I/O MAP address in a network.	• The I/O MAP address of an input module may only appear once in the network. Use the white thumbwheel to set different I/O MAP addresses.
	Missing input module Example: an output module is not assigned the corresponding input module with the same I/O MAP address.	• Check whether an input module with the same I/O MAP address has been assigned to every output module. • Use the white thumbwheel on the extension module to set the I/O MAP address (01 ... 99). The input module must be provided with the same I/O MAP address as the assigned output module at another station.
	Missing output module Example: an input module is not assigned the corresponding output module with the same I/O MAP address.	• Check whether an output module with the same I/O MAP address has been assigned to every input module. • Use the white thumbwheel on the extension module to set the I/O MAP address (01 ... 99). The output module must be provided with the same I/O MAP address as the assigned input module at another station.
	RAD ID changed Example: the yellow thumbwheel setting has accidentally been modified and the modification has not yet been confirmed via the SET button.	• Check the RAD ID setting on the yellow thumbwheel of the wireless module. • If necessary, set the correct RAD ID and press the SET button.

Detecting and removing errors

Table 9-1 Detecting and removing errors: wireless module

LED, wireless module	Current state and possible cause	Solution
In PLC / Modbus/RTU mode		
ERR flash- ing slowly (1.4 Hz)	Double assignment of I/O MAP address, two input modules have the same I/O MAP address in a network.	The I/O MAP address of an input module may only appear once in the network. Use the white thumbwheel to set different I/O MAP addresses.
	RAD ID changed Example: the yellow thumbwheel setting has accidentally been modified and the modification has not yet been confirmed via the SET button.	- Check the RAD ID setting on the yellow thumbwheel of the wireless module. - If necessary, set the correct RAD ID and press the SET button.
	No Modbus communication (only if watchdog is activated) Example: the communication line between the Modbus/RTU controller and the master wireless module has been interrupted.	- Check the communication line between the Modbus/RTU controller and the master wireless module using RAD ID 01. - Check the wiring of the RS-232/RS-485 connections on the wireless modules. - Check the serial interface settings (baud rate, parity, data bits, and stop bits) for the wireless modules and serial terminal devices. - Check whether the I/O extension module is properly snapped onto the DIN rail connector. - Use the PSI-CONF software to check if the wireless module is in "PLC / Modbus/RTU" mode or in dual mode (see page 38). - Press the SET button on the wireless module or carry out a power up in order to read the station structure.
In "serial data" or "PLC / Modbus/RTU" mode		
RX, TX off	Wireless connection present, but application does not transmit any data.	- Check the wiring of the RS-232/RS-485 connections on the wireless modules. - Check the serial interface settings (baud rate, parity, data bits, and stop bits) for the wireless modules and serial terminal devices (from page 38 onwards).

RAD-...-IFS

Table 9-2 Detecting and removing errors: I/O extension module

LED, I/O module	Current state and possible cause	Solution
PWR off	No power supply, mains probably switched off	Switch on the mains, restore the power supply.
DAT off	No communication between wireless module and I/O extension module. The wireless module is probably in "serial data" mode.	- Check whether the I/O extension module is properly snapped onto the DIN rail connector and whether it is connected to the wireless module. - Check the operating mode of the wireless module using the PSI-CONF software. The wireless module must be in "I/O data", "PLC / Modbus/RTU" mode or in dual mode (see page 38). - Reset the wireless module to the default settings (I/O data mode, see page 30), if necessary.
ERR on	Critical internal error Example: technical defect	Please contact Phoenix Contact technical support.
ERR flashing slowly (1.4 Hz)	I/O MAP address changed Example: the white thumbwheel setting has accidentally been modified and the modification has not yet been confirmed via the SET button.	- Check the I/O MAP address setting on the white thumbwheel of the I/O extension module. - If necessary, set the correct I/O MAP address and press the SET button on the wireless module.
In I/O data mode		
ERR flashing fast (2.8 Hz)	Missing input module Example: an output module is not assigned the corresponding input module with the same I/O MAP address.	- Check whether an input module with the same I/O MAP address has been assigned to every output module. - Use the white thumbwheel on the extension module to set the I/O MAP address (01 ... 99). The input module must be provided with the same I/O MAP address as the assigned output module at another station.
	No bus communication, no wireless connection present	See measures for the wireless module, page 153
In PLC / Modbus/RTU mode		
ERR flashing fast (2.8 Hz)	No Modbus communication (safe state of outputs, depending on DIP switch settings)	- Check the communication line between the Modbus/RTU controller and the master wireless module using RAD ID 01. - Check the wiring of the RS-232/RS-485 connections on the master and the PLC. - Check the serial interface settings (baud rate, parity, data bits, and stop bits) on the master and the PLC (from page 38 onwards). - Check whether the I/O extension module is properly snapped onto the DIN rail connector. - Use the PSI-CONF software to check if the wireless module is in "PLC / Modbus/RTU" mode or in dual mode (see page 38). - Press the SET button on the wireless module or carry out a power up in order to read the station structure.
	No bus communication, no wireless connection present	See measures for the wireless module, page 153

9.1 Loopback test during serial data transmission

With an RS-232 interface, you can use the loopback test to check the data path from the master to the slave and back again. To do this, you need to short circuit two terminal points of the RS-232 interface on the slave wireless module. You can then transmit characters to the master wireless module using a terminal program (e.g., HyperTerminal). The characters are echoed back to the terminal program.



Note for users of Windows 7 or a more recent Windows operating system:

HyperTerminal is no longer available from Windows 7. Instead you can use any other terminal program.

To carry out a loopback test, proceed as follows:

- Close all programs on your PC, including the PSI-CONF software.
- Connect the PC to the master wireless module. Start HyperTerminal via “Start, All Programs, Accessories, Communication, HyperTerminal”. The COM port settings on the PC must correspond to the interface settings on the master wireless module.

RAD-...-IFS

- Connect terminal points 5.1 and 5.2 of the RS-232 interface on the slave module to be tested.




Figure 9-1 Loopback test on an RS-232 interface

- Connect the two wireless modules to the power supply.
- Check the wireless connection via the LED bar graph.
- Enter several characters of your choice. HyperTerminal transmits these characters over the wireless path. The characters are output on the slave side (e.g., at terminal point 5.1, RX cable of the RS-232 interface) and immediately read again using the bridge (e.g., at terminal point 5.2, TX cable of the RS-232 interface). This returns the transmitted characters and they appear twice on the HyperTerminal screen.
 - The screen remains blank if the check was not successful. Monitor the TX and RX LEDs on every wireless module. In this way, you can determine the point up to which data has been transmitted.
 - If the characters only appear once, check the HyperTerminal settings for hidden outgoing characters. The following options must be enabled under “File, Properties, Settings, ASCII Setup”:
 “Echo typed characters locally” and
 “Append line feeds to incoming line ends”




Figure 9-2 Settings in HyperTerminal

10 Technical data for the wireless modules

Description	Type	Order No.	Pcs./Pkt.
Wireless transceiver with RS-232/485 interface, can be extended with I/O modules, RSMA (female) antenna connection, point-to-point, star, and mesh networks			
2.4 GHz, up to 250 stations, up to 5 km, worldwide use	RAD-2400-IFS	2901541	1
868 MHz, up to 99 stations, up to 20 km, use in Europe	RAD-868-IFS	2904909	1
2.4 GHz, up to 250 stations, up to 5 km, use in Japan	RAD-2400-IFS-JP	2702863	1

Accessories

RS-485 front module	Type	Order No.	Pcs./Pkt.
RS-485 multipoint multiplexer, can be extended with I/O modules, can be used as Modbus/RTU bus coupler or can be combined with Radioline wireless system, up to 99 stations, range of up to 1.2 km on in-house copper cables	RAD-RS485-IFS	2702184	1

Extension modules	Type	Order No.	Pcs./Pkt.
I/O extension module, 4 analog current inputs (0/4 mA...20 mA)	RAD-AI4-IFS	2901537	1
I/O extension module, 4 Pt100 inputs (-50°C ... +250°C)	RAD-PT100-4-IFS	2904035	1
I/O extension module, 4 analog current or voltage outputs (0/4 mA ... 20 mA, 0 V ... 10 V)	RAD-AO4-IFS	2901538	1
I/O extension module, 4 digital inputs (0 ... 250 V AC/DC)	RAD-DI4-IFS	2901535	1
I/O extension module, 8 digital inputs (0 ... 30.5 V DC) or 2 pulse inputs up to 100 Hz	RAD-DI8-IFS	2901539	1
I/O extension module, 4 digital relay outputs (5 A, 250 V AC / 24 V DC)	RAD-DOR4-IFS	2901536	1
I/O extension module, 8 digital transistor outputs (30.5 V DC / 200 mA)	RAD-DO8-IFS	2902811	1
I/O extension module, 2 digital inputs and outputs (0 ... 250 V AC/DC) and 1 analog input (0/4 ... 20 mA) and output (0/4 ... 20 mA, 0 ... 10 V)	RAD-DAIO6-IFS	2901533	1

RAD-...-IFS

Mounting and configuration	Type	Order No.	Pcs./Pkt.
DIN rail connector for DIN rail power supply, gold-plated contacts, for DIN rail mounting, 5-pos.	ME 17,5 TBUS 1,5/ 5-ST-3,81 GN	2709561	10
Shield connection clamp for applying the shield on bus-bars	SKS 8-SNS35	3062786	10
Vulcanizing sealing tape for external protection of adapters, cable connections, etc., roll length: 3 m	RAD-TAPE-SV-19-3	2903182	1
Memory stick for saving custom configuration data	RAD-MEMORY	2902828	1
USB data cable for communication between the PC and Radioline devices, energy supply for diagnostics and configuration via the USB port of the PC, cable length: 2 m	RAD-CABLE-USB	2903447	1
Configuration sticks	Type	Order No.	Pcs./Pkt.
Configuration stick for easy and secure network addressing, unique network ID			
2.4 GHz, RF band 3	RAD-CONF-RF3	2902814	1
2.4 GHz, RF band 5	RAD-CONF-RF5	2902815	1
2.4 GHz, RF band 7	RAD-CONF-RF7	2902816	1
868 MHz, RF band 1	RAD-868-CONF-RF1	2702197	1
2.4 GHz antennas	Type	Order No.	Pcs./Pkt.
Omnidirectional antenna, 2.4 GHz, gain: 2 dBi, polarization: linear, opening angle: h/v 360°/75°, degree of protection: IP65, connection: RSMA (male), including 1.5 m connecting cable and mounting bracket for wall mounting	RAD-ISM-2400-ANT-OMNI-2-1-RSMA	2701362	1
Omnidirectional antenna with protection against vandalism, 2.4 GHz, gain: 3 dBi, polarization: linear, opening angle: h/v 360°/85°, degree of protection: IP55, connection: RSMA (male), for control cabinet mounting (wall mounting as an option), including 1.5 m connecting cable	RAD-ISM-2400-ANT-VAN-3-0-RSMA	2701358	1
Omnidirectional antenna, 2.4 GHz, gain: 6 dBi, polarization: linear, opening angle: h/v 360°/30°, degree of protection: IP67, seawater-resistant, connection: N (female), including mounting bracket and mast clips, ATEX and IECEx approval	RAD-ISM-2400-ANT-OMNI-6-0	2885919	1

Technical data for the wireless modules


2.4 GHz antennas	Type	Order No.	Pcs./Pkt.
Omnidirectional antenna, 2.4 GHz, gain: 9 dBi, polarization: linear, opening angle: h/v 360°/15°, degree of protection: IP65, connection: N (female), including mounting bracket and mast clips	RAD-ISM-2400-ANT-OMNI-9-0	2867623	1
Directional antenna, 2.4 GHz/5 GHz, gain: 9 dBi, polarization: linear, opening angle: h/v 75°/55°, degree of protection: IP67, seawater-resistant, connection: N (female), including mounting bracket and mast clips, ATEX and IECEx approval	ANT-DIR-2459-01	2701186	1
Directional antenna, 2.4 GHz, gain: 19 dBi, polarization: linear, opening angle: h/v 17°/11°, degree of protection: IP65, connection: N (female), including mounting bracket and mast clips	RAD-ISM-2400-ANT-PAR-19-0	2867885	1
868 MHz antennas	Type	Order No.	Pcs./Pkt.
Omnidirectional antenna, 868 MHz/900 MHz, gain: 2 dBi, polarization: linear, opening angle: h/v 360°/50°, degree of protection: IP66, connection: N (female), for control cabinet mounting (wall mounting as an option)	RAD-900-ANT-OMNI-2-N	2904802	1
Omnidirectional antenna with protection against vandalism, 868 MHz, gain: 2,5 dBi, polarization: linear vertical, opening angle: h/v 360°/55°, degree of protection: IP67, shock resistance: IK08, connection: N (female), for control cabinet mounting, optional wall mounting	ANT-OMNI-VAN-868-01	1090616	1
Omnidirectional antenna, 868 MHz, gain: 4dBi, polarization: linear, opening angle: h/v 360°/30°, degree of protection: IP67, seawater-resistant, connection: N (female), including mounting bracket and mast clips, ATEX and IECEx approval	ANT-OMNI-868-01	2702136	1
Directional antenna, 868 MHz, gain: 3.5 dBi, polarization: circular, opening angle: h/v 135°/90°, degree of protection: IP67, seawater-resistant, connection: N (female), including mounting bracket and mast clips, ATEX and IECEx approval	ANT-DIR-868-01	2702137	1
Directional antenna, 868 MHz/900 MHz, gain: 8.5 dBi, polarization: linear, opening angle: h/v 100°/62°, degree of protection: IP65, connection: N (female), including mounting bracket and mast clips	RAD-ISM-900-ANT-YAGI-6.5-N	2867814	1
Directional antenna 868 MHz/900 MHz, gain: 12 dBi, polarization: linear, opening angle: h/v 56°/46°, degree of protection: IP65, connection: N (female), including mounting bracket and mast clips	RAD-ISM-900-ANT-YAGI-10-N	5606614	1

RAD-...-IFS

Antenna cables and adapters	Type	Order No.	Pcs./Pkt.
Antenna cable for control cabinet feed-through, outside diameter: 3.2 mm, inner conductor: flexible, attenuation: 0.6/0.9/1.4 dB at 0.9/2.4/5.8 GHz, connection: N (female) -> RSMA (male), cable length: 0.5 m	RAD-PIG-EF316-N-RSMA	2701402	1
Antenna cable, outer diameter: 5 mm, inner conductor: rigid, connection: N (male) -> RSMA (male)			
Length 0.5 m, attenuation: 0.4/0.5/0.6 dB at 0.9/2.4/5.8 GHz	RAD-PIG-RSMA/N-0.5	2903263	1
Length 1 m, attenuation: 0.5/0.8/1.1 dB at 0.9/2.4/5.8 GHz	RAD-PIG-RSMA/N-1	2903264	1
Length 2 m, attenuation: 0.9/1.3/2.0 dB at 0.9/2.4/5.8 GHz	RAD-PIG-RSMA/N-2	2903265	1
Length 3 m, attenuation: 1.2/2.0/3.0 dB at 0.9/2.4/5.8 GHz	RAD-PIG-RSMA/N-3	2903266	1
Length 5 m, attenuation: 2.0/3.3/4.8 dB at 0.9/2.4/5.8 GHz	RAD-PIG-RSMA/N-5	2702140	1
Antenna cable, outside diameter: 5 mm, inner conductor: flexible, attenuation: 0.3/0.5/0.8 dB at 0.9/2.4/5.8 GHz, connection: 2 x N (male), cable length: 0.5 m	FL LCX PIG-EF142-N-N	2700677	1
Attachment plug with LAMBDA/4 technology as surge protection for coaxial signal interfaces connection: socket-socket N connectors			
For RAD-2400-IFS	CN-LAMBDA/4-5.9-BB	2838490	1
For RAD-868-IFS	CN-LAMBDA/4-2.2-BB	2800024	1
Antenna adapter for control cabinet feed-through, frequency range: 0.3 GHz ... 6 GHz, degree of protection: IP65, connection: 2 x N (female)	RAD-ADP-N/F-N/F	2867843	1
Antenna adapter, frequency range: 0.3 GHz ... 6 GHz, connection: RSMA (male) -> RSMA (female), 90° angled	RAD-ADP-RSMA/M-RSMA/F-90	2904790	1
Antenna barrier for control cabinet feed-through, type of protection: Ex i, degree of protection: IP65, barrier installation: Zone 2, antenna installation: Zone 0, 1 or 2, frequency range: 0.3 GHz ... 6 GHz, connection: 2 x N (female), ATEX and IECEx approval	BAR-ANT-N-N-EX	2702198	1
Antenna splitter, frequency range: 0.3 GHz ... 6 GHz, degree of protection: IP65, connection: 3 x N (female), corresponding connecting cable for antenna connection (Order No. 2700677)	RAD-SPL-2-N/N	2702293	1

Technical data for the wireless modules

Antenna cables and adapters	Type	Order No.	Pcs./Pkt.
Antenna cable, outer diameter: 10 mm, inner conductor: flexible, connection: 2 x N (male)			
Length 3 m, attenuation: 1.0/1.8/3.1 dB at 0.9/2.4/5.8 GHz	RAD-CAB-EF393- 3M	2867649	1
Length 5 m, attenuation: 1.6/2.9/5.0 dB at 0.9/2.4/5.8 GHz	RAD-CAB-EF393- 5M	2867652	1
Length 10 m, attenuation: 2.9/5.6/9.9 dB at 0.9/2.4/5.8 GHz	RAD-CAB-EF393-10M	2867665	1
Length 15 m, attenuation: 4.3/8.3/14.8 dB at 0.9/2.4/5.8 GHz	RAD-CAB-EF393-15M	2885634	1
Antenna adapter, frequency range: 0.3 GHz ... 6 GHz, connection: RSMA (male) -> RSMA (female), 90° angled	RAD-ADP-RSMA/M-RSMA/F-90	2904790	1
Energy supply	Type	Order No.	Pcs./Pkt.
Solar system for worldwide use, consisting of a solar panel, prewired control cabinet with charge controller, solar batteries, fuses, surge protection, and mounting material (including mast clips)			
24 V / 100 Wp	RAD-SOL-SET-24-100	2885472	1
24 V / 200 Wp	RAD-SOL-SET-24-200	2917722	1
DIN rail power supply unit, primary-switched, narrow design, output: 24 V DC/1.5 A	MINI-SYS-PS-100-240AC/24DC/1.5	2866983	1
Control box	Type	Order No.	Pcs./Pkt.
Control box for robust setup of wireless systems for industrial applications, IP65, 25 x 18 x 13 cm, polycarbonate material, gray, drilled, including DIN rail, plugs, and screw connections, without devices	FL RUGGED BOX	2701204	1

RAD-...-IFS**Dimensions (nominal sizes in mm)****Dimensions W / H / D**

17.5 mm / 99 mm / 114.5 mm

General data

Overvoltage category	II
Degree of protection	IP20
Pollution degree	2
Housing design	PA 6.6 FR, green
Flammability rating according to UL 94	V0

Power

Supply voltage range	19.2 V DC ... 30.5 V DC
Maximum current consumption	≤65 mA (at 24 V DC, at 25°C, stand-alone) ≤6 A (at 24 V DC, with DIN rail connector at full capacity)
Transient surge protection	Yes

System limits

	RAD-2400-IFS...	RAD-868-IFS
Wireless module		
Number of devices supported	≤250 (addressing via PSI-CONF software) ≤99 (addressing via thumb-wheel)	≤ 99 (per wireless network)
Number of possible extension modules	≤32 (per wireless module)	≤32 (per wireless module)
Wireless network		
I/O data mode	≤99 (I/O extension modules per wireless network, serial interface deactivated)	
Serial data mode	0 (no I/O extension modules can be used)	
PLC / Modbus/RTU mode	≤99 (access to I/O extension modules via Modbus/RTU protocol)	

Technical data for the wireless modules

Wireless interface		RAD-2400-IFS...	RAD-868-IFS
Antenna connection method		RSMA (female)	
Direction		Bidirectional	
Frequency		2.4 GHz	868 MHz
Frequency range		2.4002 GHz ... 2.4785 GHz	869.4 MHz ... 869.65 MHz
Number of channel groups		8	14
Number of channels per group		55	-
Channel distance		1.3 MHz	30 kHz (depending on the network structure and data transmission rate)
Data transmission rate (adjustable)		16 kbps 125 kbps 250 kbps	1.2 kbps 9.6 kbps 19.2 kbps 60 kbps 120 kbps
Receiver sensitivity		-106.00 dBm (16 kbps) -96.00 dBm (125 kbps) -93.00 dBm (250 kbps)	-122 dBm (1.2 kbps) -114 dBm (9.6 kbps) -111 dBm (19.2 kbps) -104 dBm (60 kbps) -103 dBm (120 kbps)
Transmission power		≤20 dBm (outside Europe, can be set via software) ≤19 dBm (Europe, can be set via software, depends on the data rate) ≤18 dBm (default setting)	≤27 dBm (default setting, can be set)
Security		128-bit data encryption	
Operating mode		I/O data (default setting, configuration via thumbwheel) serial data, PLC / Modbus/RTU mode, PLC / Modbus/RTU dual mode (activation and configuration via PSI-CONF software)	
RS-232 interface			
Connection method		COMBICON plug-in screw terminal block	
Connection technology		3-wire	
Data rate		0.3 kbps ... 115.2 kbps	
Transmission length		≤15 m	
RS-485 interface			
Connection method		COMBICON plug-in screw terminal block	
Connection technology		2-wire	
Data rate		0.3 kbps ... 187.5 kbps	
Transmission length		≤1200 m	
Termination resistor (can be switched on via DIP switches)		390 Ω / 150 Ω / 390 Ω	

RAD-...-IFS**Configuration interface**

Connection method	S-PORT (socket)
-------------------	-----------------

RSSI voltage output

Number of outputs	1
Voltage output signal	0 V ... 3 V

RF link relay output

Number of outputs	1
Contact type	Changeover contact
Contact material	PdRu, gold-plated
Maximum switching voltage	30 V AC/DC / 60 V DC
Maximum switching current	500 mA (30 V AC/DC) / 300 mA (60 V DC)
Electrical service life	5 x 10 ⁵ cycles at 0.5 A at 30 VDC

Connection data

Connection method	Screw connection
Conductor cross-section, rigid	0.2 mm ² ... 2.5 mm ²
Conductor cross-section, flexible	0.2 mm ² ... 2.5 mm ²
Conductor cross-section, AWG/kcmil	24 ... 14
Stripping length	7 mm
Tightening torque	0.6 Nm

Status indicator

Status indicator	Green LED (supply voltage, PWR) Green LED (bus communication, DAT) Red LED (peripheral fault, ERR) 3 x green, 1 x yellow LED (LED bar graph for receive quality, RSSI) Green LED (RS-232/RS-485 receive data, RX) Green LED (RS-232/RS-485 transmit data, TX)
------------------	--

Ambient conditions

Ambient temperature (operation)	-40°C ... 70°C (>55°C derating) -40°F ... 158°F (>131°F derating)
Ambient temperature (storage/transport)	-40°C ... 85°C -40°F ... 185°F
Permissible humidity (operation)	20% ... 85%
Permissible humidity (storage/transport)	20% ... 85%
Altitude	2000 m
Vibration (operation)	According to IEC 60068-2-6: 5g, 10 Hz ... 150 Hz
Shock	16g, 11 ms

Technical data for the wireless modules

Approvals	RAD-2400-IFS	RAD-868-IFS	RAD-2400-IFS-JP
CE conformity	RED directive 2014/53/EU		No
ATEX	Ex II 3 G Ex nA nC IIC T4 Gc (IBExU 15 ATEX B008 X)		No
IECEX	Ex nA nC IIC T4 Gc (IECEX IBE 13.0019X)		No
FCC	FCC directive, part 15.247	No	No
ISC	ISC directive RSS 210	No	No
IFT Mexico	IFT RCPHRA17- 1112	No	No
UL, USA/Canada	UL 508 Listed, Class I, Div. 2, Groups A, B, C, D T4A Class I, Zone 2, IIC T4	No	No
Noxious gas test	ISA-S71.04-1985 G3 Harsh Group A		

RAD-...-IFS

Conformity with EMC directive 2014/30/EU (RAD-2400-IFS and RAD-868-IFS)		
Immunity to interference according to EN 61000-6-2		
Electrostatic discharge	EN 61000-4-2	
	Contact discharge	±6 kV (test intensity 3)
	Air discharge	±8 kV (test intensity 3)
	Indirect discharge	±6 kV
	Comment	Criterion B
Electromagnetic HF field	EN 61000-4-3	
	Frequency range	26 MHz ... 3 GHz (test intensity 3)
	Field strength	10 V/m
	Comment	Criterion A
Fast transients (burst)	EN 61000-4-4	
	Input	±2 kV (test intensity 3)
	Signal	±2 kV
	Comment	Criterion B
Surge current loads (surge)	EN 61000-4-5	
	Input	±0.5 kV (symmetrical) ±1 kV (asymmetrical)
	Signal	±1 kV (asymmetrical)
	Comment	Criterion B
Conducted interference	EN 61000-4-5	
	Frequency range	0.15 MHz ... 80 MHz
	Voltage	10 V
	Comment	Criterion A
Noise emission according to EN 61000-6-4 (RAD-2400-IFS and RAD-868-IFS)		
Emitted radio interference according to EN 55011		EN 55016-2-3 Class A, industrial area of application
Criterion A	Normal operating behavior within the specified limits	
Criterion B	Temporary adverse effects on the operating characteristics that the device corrects automatically.	
RED directive 2014/53/EU	RAD-2400-IFS	RAD-868-IFS
EMC - immunity to interference (electromagnetic compatibility of wireless systems)	EN 61000-6-2, generic standard for industrial environments	
Safety - protection of personnel with regard to electrical safety	EN 60950	
Health - limitation of exposure of the population to electromagnetic fields	EN 62311	
Radio - effective use of the frequency spectrum and avoidance of radio interference	EN 300328	EN 300220


Operating conditions for the extended temperature range (+55°C ... 70°C)

No function restrictions for the extended temperature range if you keep a minimum spacing of 17.5 mm between the modules. The minimum spacing is the width of a DIN rail connector.


Otherwise, please observe the following restrictions. Individual operating conditions available on request!

RAD-DAIO6-IFS (2901533):


Do not use the analog loop power output (PWR1).



Only use the analog voltage output (U1).




Do not use more than two of the four possible digital inputs and outputs.




RAD-...-IFS**RAD-DOR4-IFS (2901536):**


Maximum switching current: 1 A per channel

**RAD-AI4-IFS (2901537):**

Make sure that no more than 40 mA in total is drawn from loop power outputs PWR₁ ... PWR₄.

**RAD-AO4-IFS (2901538):**

Only use the analog voltage output (0 V ... 10 V).



A Technical appendix

A 1 Typical combinations of antennas and adapter cables

In this section, you will find typical combinations of wireless modules, antennas, and adapter cables for installation with or without a control cabinet.



- Install the antenna outside the control cabinet or building.
- Observe the installation instructions for the antenna and the Section “For your safety” on page 7.
- For information on the transmission power, please refer to “Transmission power” on page 39.

A 1.1 2.4 GHz antennas

Omnidirectional antenna, 2 dBi




Figure A-1 Omnidirectional antenna, 2 dBi

Item	Product	Description	Connection	Order No.
1	RAD-ISM-2400-ANT-OMNI-2-1-RSMA	Omnidirectional antenna, 2.4 GHz, 2 dBi gain, 1.5 m cable length, linear vertical polarization, h/v 360°/75° opening angle, IP65 protection	RSMA (male)	2701362

RAD-...-IFS

Omnidirectional antenna with protection against vandalism, 3 dBi




Figure A-2 Omnidirectional antenna with protection against vandalism, 3 dBi

Item	Product	Description	Connection	Order No.
1	RAD-ISM-2400-ANT-VAN-3-0-RSMA	Omnidirectional antenna with protection against vandalism, 2.4 GHz, 3 dBi gain, IP55 protection, 1.5 m cable length, h/v 360°/85° opening angle Appropriate mounting material is available for wall mounting.	RSMA (male)	2701358

Typical combinations of antennas and adapter cables

Omnidirectional antenna, 2.5 dBi




Figure A-3 Omnidirectional antenna, 2.5 dBi

Item	Product	Description	Connection	Order No.
1	ANT-OMNI-2459-02	Omnidirectional antenna, 2.4 GHz/5 GHz, 2.5/5 dBi gain, linear vertical polarization, opening angle: h/v 360°/30° for 2.4 GHz, h/v 360°/16° for 5 GHz, IP68	N (male)	2701408
2	RAD-PIG-EF316-N-RSMA	Adapter cable, 50 cm pigtail, 50 Ω impedance	N (female) → RSMA (male)	2701402

Omnidirectional antenna, 6 dBi, without surge protection




Figure A-4 Omnidirectional antenna, 6 dBi, without surge protection

Item	Product	Description	Connection	Order No.
1	RAD-ISM-2400-ANT-OMNI-6-0	Omnidirectional antenna, 2.4 GHz, 6 dBi gain, linear vertical polarization, h/v 360°/30° opening angle, IP67 protection, seawater-resistant	N (female)	2885919
2	RAD-PIG-RSMA/N-0.5	Antenna cable, 0.5 m length, 50 Ω impedance	N (male) → RSMA (male)	2903263
	Alternative: RAD-PIG-RSMA/N-1	Antenna cable, 1 m length		2903264
	RAD-PIG-RSMA/N-2	Antenna cable, 2 m length		2903265
	RAD-PIG-RSMA/N-3	Antenna cable, 3 m length	N (male) → RSMA (male)	2903266
	RAD-PIG-RSMA/N-5	Antenna cable, 5 m length		2702140

Typical combinations of antennas and adapter cables

Omnidirectional antenna, 6 dBi, with surge protection




Figure A-5 Omnidirectional antenna, 6 dBi, with surge protection

Items 2 and 3 are optional.

Item	Product	Description	Connection	Order No.
1	RAD-ISM-2400-ANT-OMNI-6-0	Omnidirectional antenna, 2.4 GHz, 6 dBi gain, linear vertical polarization, h/v 360°/30° opening angle, IP67 protection, seawater-resistant	N (female)	2885919
2 (opt.)	RAD-CAB-EF393- 3M Alternative: RAD-CAB-EF393- 5M RAD-CAB-EF393-10M RAD-CAB-EF393-15M	Antenna cable, 3 m length, 50 Ω impedance Antenna cable, 5 m length Antenna cable, 10 m length Antenna cable, 15 m length	N (male) → N (male) N (male) → N (male)	2867649 2867652 2867665 2885634
3 (opt.)	CN-LAMBDA/4-5.9-BB	Attachment plug with LAMBDA/4 technology as surge protection for coaxial signal interfaces	N (female) → N (female)	2838490
4	RAD-PIG-RSMA/N-0.5 Alternative: RAD-PIG-RSMA/N-1 RAD-PIG-RSMA/N-2 RAD-PIG-RSMA/N-3 RAD-PIG-RSMA/N-5	Antenna cable, 0.5 m length, 50 Ω impedance Antenna cable, 1 m length Antenna cable, 2 m length Antenna cable, 3 m length Antenna cable, 5 m length	N (male) → RSMA (male) N (male) → RSMA (male)	2903263 2903264 2903265 2903266 2702140


RAD-...-IFS**Directional antenna, 9 dBi, with outdoor surge protection**

Figure A-6 Directional antenna, 9 dBi, with outdoor surge protection

Items 2 and 3 are optional.

Item	Product	Description	Connection	Order No.
1	ANT-DIR-2459-01	Directional antenna, 2.4/5 GHz, 9 dBi gain, linear vertical polarization, h/v 75°/55° opening angle for 2.4 GHz, IP67 protection	N (female)	2701186
2 (opt.)	RAD-CAB-EF393- 3M Alternative: RAD-CAB-EF393- 5M RAD-CAB-EF393-10M RAD-CAB-EF393-15M	Antenna cable, 3 m length, 50 Ω impedance Antenna cable, 5 m length Antenna cable, 10 m length Antenna cable, 15 m length	N (male) → N (male) N (male) → N (male)	2867649 2867652 2867665 2885634
3 (opt.)	CN-LAMBDA/4-5.9-BB	Attachment plug with LAMBDA/4 technology as surge protection for coaxial signal interfaces	N (female) → N (female)	2838490
4	RAD-PIG-RSMA/N-0.5 Alternative: RAD-PIG-RSMA/N-1 RAD-PIG-RSMA/N-2 RAD-PIG-RSMA/N-3 RAD-PIG-RSMA/N-5	Antenna cable, 0.5 m length, 50 Ω impedance Antenna cable, 1 m length Antenna cable, 2 m length Antenna cable, 3 m length Antenna cable, 5 m length	N (male) → RSMA (male) N (male) → RSMA (male)	2903263 2903264 2903265 2903266 2702140

Typical combinations of antennas and adapter cables

Parabolic antenna, 19 dBi, with outdoor surge protection




Figure A-7 Parabolic antenna, 19 dBi, with outdoor surge protection

Items 2 and 3 are optional.

Item	Product	Description	Connection	Order No.
1	RAD-ISM-2400-ANT-PAR-19-0	Parabolic antenna, 2.4 GHz, 19 dBi gain, linear vertical polarization, h/v 17°/11° opening angle, IP65 protection	N (female)	2867885
2 (opt.)	RAD-CAB-EF393- 3M Alternative: RAD-CAB-EF393- 5M RAD-CAB-EF393-10M RAD-CAB-EF393-15M	Antenna cable, 3 m length, 50 Ω impedance Antenna cable, 5 m length Antenna cable, 10 m length Antenna cable, 15 m length	N (male) → N (male) N (male) → N (male)	2867649 2867652 2867665 2885634
3 (opt.)	CN-LAMBDA/4-5.9-BB	Attachment plug with LAMBDA/4 technology as surge protection for coaxial signal interfaces	N (female) → N (female)	2838490
4	RAD-PIG-RSMA/N-0.5 Alternative: RAD-PIG-RSMA/N-1 RAD-PIG-RSMA/N-2 RAD-PIG-RSMA/N-3 RAD-PIG-RSMA/N-5	Antenna cable, 0.5 m length, 50 Ω impedance Antenna cable, 1 m length Antenna cable, 2 m length Antenna cable, 3 m length Antenna cable, 5 m length	N (male) → RSMA (male) N (male) → RSMA (male)	2903263 2903264 2903265 2903266 2702140

A 1.2 868 MHz antennas

Omnidirectional antenna, 4 dBi, with surge protection




Figure A-8 Omnidirectional antenna, 4 dBi, with surge protection

Items 2 and 3 are optional.

Item	Product	Description	Connection	Order No.
1	ANT-OMNI-868-01	Omnidirectional antenna, 868 MHz, 4 dBi, linear vertical, h/v 360°/30° opening angle, IP67, seawater-resistant, including mounting bracket and mast clips for 30 mm ... 45 mm diameter, stainless steel, ATEX/IECEX approval	N (female)	2702136
2 (opt.)	RAD-CAB-EF393- 3M Alternative: RAD-CAB-EF393- 5M RAD-CAB-EF393-10M RAD-CAB-EF393-15M	Antenna cable, 3 m length, 50 Ω impedance Antenna cable, 5 m length Antenna cable, 10 m length Antenna cable, 15 m length	N (male) → N (male) N (male) → N (male)	2867649 2867652 2867665 2885634
3 (opt.)	CN-LAMBDA/4-2.2-BB	Attachment plug with LAMBDA/4 technology as surge protection for coaxial signal interfaces	N (female) → N (female)	2800024

Typical combinations of antennas and adapter cables

Item	Product	Description	Connection	Order No.
4	RAD-PIG-RSMA/N-0.5	Antenna cable, 0.5 m length, 50 Ω impedance	N (male) → RSMA (male)	2903263
	Alternative:			
	RAD-PIG-RSMA/N-1	Antenna cable, 1 m length		2903264
	RAD-PIG-RSMA/N-2	Antenna cable, 2 m length	N (male) → RSMA (male)	2903265
	RAD-PIG-RSMA/N-3	Antenna cable, 3 m length		2903266
	RAD-PIG-RSMA/N-5	Antenna cable, 5 m length		2702140

Directional antennas, with surge protection




Figure A-9 Directional antenna, with surge protection

Items 2 and 3 are optional.

Item	Product	Description	Connection	Order No.
1	ANT-DIR-868-01	Directional antenna, 868 MHz, 3.5 dBi, circular polarized, IP67, including mounting bracket and mast clips for 25 mm ... 85 mm diameter, stainless steel, ATEX and IECEx approval	N (female)	2702137
	Alternative:			
	RAD-ISM-900-ANT-YAGI-6.5-N	Yagi antenna, IP65, 8.5 dBi gain, 0.6 m cable length		2867814
	RAD-ISM-900-ANT-YAGI-10-N	Yagi antenna, IP65, 12 dBi gain, 0.6 m RG-213 cable	N (female)	5606614

RAD-...-IFS

Item	Product	Description	Connection	Order No.
2 (opt.)	RAD-CAB-EF393- 3M	Antenna cable, 3 m length, 50 Ω impedance	N (male) → N (male)	2867649
	Alternative:			
	RAD-CAB-EF393- 5M	Antenna cable, 5 m length		2867652
	RAD-CAB-EF393-10M	Antenna cable, 10 m length	N (male) → N (male)	2867665
	RAD-CAB-EF393-15M	Antenna cable, 15 m length		2885634
3 (opt.)	CN-LAMBDA/4-5.9-BB	Attachment plug with LAMBDA/4 technology as surge protection for coaxial signal interfaces	N (female) → N (female)	2838490
4	RAD-PIG-RSMA/N-0.5	Antenna cable, 0.5 m length, 50 Ω impedance	N (male) → RSMA (male)	2903263
	Alternative:			
	RAD-PIG-RSMA/N-1	Antenna cable, 1 m length		2903264
	RAD-PIG-RSMA/N-2	Antenna cable, 2 m length	N (male) → RSMA (male)	2903265
	RAD-PIG-RSMA/N-3	Antenna cable, 3 m length		2903266
	RAD-PIG-RSMA/N-5	Antenna cable, 5 m length		2702140

Typical combinations of antennas and adapter cables

A 1.3 Antenna splitter

Directional antennas, 8 dBi, with 2-way outdoor antenna splitter




Figure A-10 Directional antennas, 8 dBi, with 2-way outdoor antenna splitter

Items 4 and 5 are optional.

Item	Product	Description	Connection	Order No.
1	ANT-DIR-2459-01	Directional antenna, 2.4 GHz/5 GHz, 9 dBi gain, linear vertical polarization, h/v 75°/55° opening angle for 2.4 GHz, IP67 protection	N (female)	2701186
	Alternative: ANT-DIR-868-01	Directional antenna, 868 MHz, 3.5 dBi, circular polarized, IP67, including mounting bracket and mast clips for 25 mm ... 85 mm diameter, stainless steel, ATEX and IECEx approval	N (female)	2702137
	Or other directional antennas from Phoenix Contact			
2	FL LCX PIG-EF142-N-N	Antenna cable, 50 cm length, 50 Ω impedance	N (male) → N (male)	2700677
3	RAD-SPL-2-N/N	2-way distributor for antenna signals (antenna splitter)	3 x N (male)	2702293

RAD-...-IFS

Item	Product	Description	Connection	Order No.
4 (opt.)	RAD-CAB-EF393- 3M	Antenna cable, 3 m length, 50 Ω impedance	N (male) → N (male)	2867649
	Alternative:			
	RAD-CAB-EF393- 5M	Antenna cable, 5 m length	N (male) →	2867652
	RAD-CAB-EF393-10M	Antenna cable, 10 m length	N (male)	2867665
	RAD-CAB-EF393-15M	Antenna cable, 15 m length		2885634
5 (opt.)	CN-LAMBDA/4-5.9-BB	Attachment plug with LAMBDA/4 technology as surge protection for coaxial signal interfaces	N (female) → N (female)	2838490
6	RAD-PIG-RSMA/N-0.5	Antenna cable, 0.5 m length, 50 Ω impedance	N (male) → RSMA (male)	2903263
	Alternative:			
	RAD-PIG-RSMA/N-1	Antenna cable, 1 m length		2903264
	RAD-PIG-RSMA/N-2	Antenna cable, 2 m length	N (male) → RSMA (male)	2903265
	RAD-PIG-RSMA/N-3	Antenna cable, 3 m length		2903266
	RAD-PIG-RSMA/N-5	Antenna cable, 5 m length		2702140

A 1.4 Installation example: antennas in potentially explosive areas


WARNING: Explosion hazard when used in potentially explosive areas

Observe the installation instructions for the antenna and the Section "For your safety" on page 7.




Figure A-11 Antenna installation in Zone 2

Typical combinations of antennas and adapter cables

Item	Product	Description	Connection	Order No.
1	IP54 stainless steel housing		-	-
2	Power supply		-	-
3	RAD-2400-IFS or RAD-868-IFS wireless module and I/O extension modules		-	-
4	RAD-PIG-RSMA/N-0.5	Antenna cable, 0.5 m length, 50 Ω impedance	N (male) → RSMA (male)	2903263
	Alternative:			
	RAD-PIG-RSMA/N-1	Antenna cable, 1 m length		2903264
	RAD-PIG-RSMA/N-2	Antenna cable, 2 m length	N (male) → RSMA (male)	2903265
	RAD-PIG-RSMA/N-3	Antenna cable, 3 m length		2903266
5	RAD-PIG-RSMA/N-5	Antenna cable, 5 m length		2702140
	BAR-ANT-N-N-EX	Antenna barrier for control cabinet feed-through, type of protection: Ex i, degree of protection: IP65, barrier installation: Zone 2, antenna installation: Zone 0, 1 or 2, frequency range: 0.3 GHz ... 6 GHz, ATEX and IECEx approval	N (female) → N (female)	2702198
6	RAD-CAB-EF393- 3M	Antenna cable, 3 m length, 50 Ω impedance	N (male) → N (male)	2867649
	Alternative:			
	RAD-CAB-EF393- 5M	Antenna cable, 5 m length		2867652
	RAD-CAB-EF393-10M	Antenna cable, 10 m length	N (male) → N (male)	2867665
	RAD-CAB-EF393-15M	Antenna cable, 15 m length		2885634
7	ANT-DIR-2459-01	Directional antenna, 2.4 GHz/5 GHz, gain: 9 dBi, polarization: linear, opening angle: h/v 75°/55°, degree of protection: IP67, seawater-resistant, including mounting bracket and mast clips, ATEX and IECEx approval	N (female)	2701186
	Alternative:			
	RAD-ISM-2400-ANT-OMNI-6-0	Omnidirectional antenna, 2.4 GHz, gain: 6 dBi, polarization: linear, opening angle: h/v 360°/30°, degree of protection: IP67, seawater-resistant, including mounting bracket and mast clips, ATEX and IECEx approval		2885919
	ANT-DIR-868-01	Directional antenna, 868 MHz, gain: 3.5 dBi, polarization: circular, opening angle: h/v 135°/90°, degree of protection: IP67, seawater-resistant, including mounting bracket and mast clips, ATEX and IECEx approval	N (female)	2702137
	ANT-OMNI-868-01	Omnidirectional antenna, 868 MHz, gain: 4 dBi, polarization: linear, opening angle: h/v 360°/30°, degree of protection: IP67, seawater-resistant, including mounting bracket and mast clips, ATEX and IECEx approval		2702136

A 2 Control box for wireless systems

The FL RUGGED BOX control box (Order No. 2701204) is suitable for use in industrial applications. The control box offers space for the power supply, the wireless module, and the I/O extension modules.

Features:

- IP66 protection class
- Mounting suitable for industrial applications
- Bore holes already available, screw connections are included as standard

A set for mast mounting including screw clamps is available as an accessory (FL RUGGED BOX POLE SET, Order No. 2701205). The screw clamps can be used for masts up to 89 mm in diameter.




Figure A-12 Control box with wireless system

Mounting example with a 35 mm power supply and five 17.5 mm devices and terminal blocks

Power supply	MINI-SYS-PS-100-240AC/24DC/1.5	1500 mA
Load	Wireless module	65 mA
	RAD-DAIO6-IFS	95 mA
	RAD-DI4-IFS	11 mA
	RAD-DOR4-IFS	55 mA
	RAD-DI8-IFS	18 mA
	RAD-DO8-IFS	22 mA
	RAD-AI4-IFS	120 mA
	RAD-AO4-IFS	115 mA

B Appendixes

B 1 List of figures

Figure 3-1:	Wireless module structure	19
Figure 3-2:	Basic circuit diagram for the wireless module	20
Figure 3-3:	Radioline connection station with up to 32 I/O extension modules	20
Figure 3-4:	Mounting and removal	21
Figure 3-5:	Connecting cables	22
Figure 3-6:	Connecting the power supply	23
Figure 3-7:	Supply via system power supply	23
Figure 3-8:	DIP switch	25
Figure 3-9:	RS-485 interface pin assignment	25
Figure 3-10:	RS-232 interface pin assignment (DTE - DCE)	26
Figure 3-11:	RS-232 interface pin assignment (DTE - DTE)	26
Figure 3-12:	Connecting the antenna	27
Figure 4-1:	I/O data mode	31
Figure 4-2:	I/O-to-I/O, wireless, and RS-485	32
Figure 4-3:	Serial data mode	33
Figure 4-4:	PLC / Modbus/RTU mode	33
Figure 4-5:	PLC / Modbus/RTU dual mode	34
Figure 4-6:	Configuration using the configuration stick	36
Figure 4-7:	PSI-CONF software: "Network Settings"	39
Figure 4-8:	PSI-CONF software: "Wizard, Step 3"	41
Figure 4-9:	PSI-CONF software: setting the data transmission rate	41
Figure 4-10:	PSI-CONF software: "Individual Settings, Overview"	42
Figure 4-11:	PSI-CONF software: "Individual Settings, Serial Port"	43
Figure 4-12:	PSI-CONF software: "Individual Settings, Allowed Parents"	43
Figure 4-13:	Diagnostic LEDs on the wireless module	44
Figure 4-14:	Bar graph for point-to-point connection	48
Figure 4-15:	Bar graph for point-to-multipoint connection	48
Figure 4-16:	PSI-CONF software: "Diagnostic, Overview"	49
Figure 4-17:	PSI-CONF software: "Diagnostic, I/O Status"	50
Figure 4-18:	PSI-CONF software: "Diagnostic, Serial Port"	50
Figure 4-19:	PSI-CONF software: "Diagnostic, Network settings"	51
Figure 4-20:	PSI-CONF software: "Record diagnostic data, Network diagnose"	51
Figure 4-21:	Assignment of digital inputs and digital outputs	52

RAD-...-IFS

Figure 4-22:	RAD-DAIO6-IFS assignment: analog/digital inputs and outputs	52
Figure 4-23:	Input module and output module with the same address	54
Figure 5-1:	Serial data mode	55
Figure 5-2:	PSI-CONF software: "Wizard, Step 3"	56
Figure 5-3:	PSI-CONF software: "Wizard, Step 4"	56
Figure 5-4:	Frame-based data transmission: $T_{IdleMin}$ parameter	57
Figure 5-5:	Frame-based data transmission: $T_{FrameEnd}$ parameter	57
Figure 5-6:	PSI-CONF software: "Individual Settings"	58
Figure 6-1:	Configuration example: PLC / Modbus/RTU mode	59
Figure 6-2:	PSI-CONF software: "Wizard, Step 3"	60
Figure 6-3:	Monitoring of oil pumps	61
Figure 6-4:	Configuration example: PLC / Modbus/RTU dual mode	62
Figure 6-5:	Flow meter	64
Figure 6-6:	Access control with door opener	64
Figure 6-7:	PSI-CONF software: "Individual Settings, Network Settings"	65
Figure 6-8:	Function blocks for Radioline	84
Figure 6-9:	I/O integration in PC Worx	85
Figure 6-10:	I/O integration in TIA Portal or STEP 7	86
Figure 7-1:	RAD-AI4-IFS structure	87
Figure 7-2:	Basic circuit diagram for the RAD-AI4-IFS	88
Figure 7-3:	DIP switches of the RAD-AI4-IFS	88
Figure 7-4:	Diagnostic LEDs of the RAD-AI4-IFS	89
Figure 7-5:	2-wire connection technology	92
Figure 7-6:	3-wire connection technology	92
Figure 7-7:	4-wire connection technology	93
Figure 7-8:	Systematic temperature measuring error ΔT depending on cable length l 93	
Figure 7-9:	Systematic temperature measuring error ΔT depending on cable cross section A	94
Figure 7-10:	Systematic temperature measuring error ΔT depending on cable temperature T_A	94
Figure 7-11:	RAD-PT100-4-IFS structure	95
Figure 7-12:	Basic circuit diagram for the RAD-PT100-4-IFS	96
Figure 7-13:	Diagnostic LEDs of the RAD-PT100-4-IFS	97
Figure 7-14:	RAD-AO4-IFS structure	99
Figure 7-15:	Basic circuit diagram for the RAD-AO4-IFS	99
Figure 7-16:	DIP switches of the RAD-AO4-IFS	100
Figure 7-17:	Diagnostic LEDs of the RAD-AO4-IFS	101

List of figures

Figure 7-18:	RAD-DI4-IFS structure	103
Figure 7-19:	Basic circuit diagram for the RAD-DI4-IFS	103
Figure 7-20:	Diagnostic LEDs of the RAD-DI4-IFS	104
Figure 7-21:	RAD-DI8-IFS structure	106
Figure 7-22:	Basic circuit diagram for the RAD-DI8-IFS	107
Figure 7-23:	DIP switches of the RAD-DI8-IFS	107
Figure 7-24:	Diagnostic LEDs of the RAD-DI8-IFS	109
Figure 7-25:	RAD-DOR4-IFS structure	111
Figure 7-26:	Basic circuit diagram for the RAD-DOR4-IFS	112
Figure 7-27:	DIP switches of the RAD-DOR4-IFS	112
Figure 7-28:	Diagnostic LEDs of the RAD-DOR4-IFS	113
Figure 7-29:	RAD-DO8-IFS structure	116
Figure 7-30:	Basic circuit diagram for the RAD-DO8-IFS	117
Figure 7-31:	DIP switches of the RAD-DO8-IFS	117
Figure 7-32:	Diagnostics LEDs of the RAD-DO8-IFS	118
Figure 7-33:	RAD-DAIO6-IFS structure	121
Figure 7-34:	Basic circuit diagram for the RAD-DAIO6-IFS	122
Figure 7-35:	DIP switches of the RAD-DAIO6-IFS	122
Figure 7-36:	Diagnostics LEDs of the RAD-DAIO6-IFS	123
Figure 8-1:	Penetration of obstacles at different frequencies	129
Figure 8-2:	Point-to-point connection, star network, self-healing mesh network ..	130
Figure 8-3:	Distributed network management with parent-child zones	130
Figure 8-4:	RF bands in the 2.4 GHz wireless system	131
Figure 8-5:	RF bands in the 868 MHz wireless system	131
Figure 8-6:	Antenna polarization	134
Figure 8-7:	Decoupling of wireless paths due to directivity and different polarization levels	135
Figure 8-8:	Outdoor installation of antennas	136
Figure 8-9:	Dispersion on a rough surface	141
Figure 8-10:	Diffraction on an edge	141
Figure 8-11:	Reflection on a metal surface	141
Figure 8-12:	Reduction of radio waves when penetrating a wall	142
Figure 8-13:	Angle of the transmitter and receiver	143
Figure 8-14:	Radio dead spot	143
Figure 8-15:	Wireless path with strong wind	144
Figure 8-16:	Fresnel zone	145
Figure 8-17:	Free space attenuation	148
Figure 8-18:	Bush with an attenuation of approximately 15 dB	149

RAD-...-IFS

Figure 8-19:	Forest with an attenuation of around 40 dB	149
Figure 9-1:	Loopback test on an RS-232 interface	158
Figure 9-2:	Settings in HyperTerminal	158
Figure A-1:	Omnidirectional antenna, 2 dBi	171
Figure A-2:	Omnidirectional antenna with protection against vandalism, 3 dBi ...	172
Figure A-3:	Omnidirectional antenna, 2.5 dBi	173
Figure A-4:	Omnidirectional antenna, 6 dBi, without surge protection	174
Figure A-5:	Omnidirectional antenna, 6 dBi, with surge protection	175
Figure A-6:	Directional antenna, 9 dBi, with outdoor surge protection	176
Figure A-7:	Parabolic antenna, 19 dBi, with outdoor surge protection	177
Figure A-8:	Omnidirectional antenna, 4 dBi, with surge protection	178
Figure A-9:	Directional antenna, with surge protection	179
Figure A-10:	Directional antennas, 8 dBi, with 2-way outdoor antenna splitter	181
Figure A-11:	Antenna installation in Zone 2	182
Figure A-12:	Control box with wireless system	184

B 2 List of tables

Table 2-1:	Firmware versions	16
Table 2-2:	Overview of I/O extension modules	17
Table 3-1:	DIP switches 1 and 2: termination network	25
Table 4-1:	Default settings of the wireless module.....	29
Table 4-2:	Operating mode.....	31
Table 4-3:	Yellow thumbwheel setting	35
Table 4-4:	Data transmission rate of the wireless interface, 2.4 GHz.....	40
Table 4-5:	Data transmission rate of the wireless interface, 868 MHz	40
Table 4-6:	LED bar graph	45
Table 4-7:	2.4 GHz RSSI voltage.....	46
Table 4-8:	868 MHz RSSI voltage	46
Table 4-9:	Assignment of input modules and output modules	53
Table 4-10:	White thumbwheel setting.....	53
Table 5-1:	Verified parameters for frame-based data transmission	58
Table 6-1:	Configuration via PSI-CONF software	60
Table 6-2:	Configuration via PSI-CONF software	63
Table 6-3:	Supported Modbus function codes.....	66
Table 6-4:	Module type and timeliness of data	67
Table 6-5:	Module type IDs.....	67
Table 6-6:	Setting the white thumbwheel for register 30010 (read).....	68
Table 6-7:	RSSI voltage 2.4 GHz.....	68
Table 6-8:	RSSI voltage, 868 MHz	68
Table 6-9:	RAD-AI4-IFS module type and timeliness of data.....	69
Table 6-10:	RAD-PT100-4-IFS module type and timeliness of data	70
Table 6-11:	RAD-AO4-IFS module type and timeliness of data	71
Table 6-12:	RAD-DI4-IFS module type and timeliness of data.....	72
Table 6-13:	RAD-DI8-IFS module type and timeliness of data.....	73
Table 6-14:	RAD-DOR4-IFS module type and timeliness of data	75
Table 6-15:	RAD-DO8-IFS module type and timeliness of data.....	76
Table 6-16:	RAD-DAIO6-IFS module type and timeliness of data	77
Table 6-17:	RSSI signal and error code registers	82
Table 6-18:	Representation of RAD-AI4-IFS analog values.....	83
Table 6-19:	Representation of RAD-AO4-IFS analog values	83
Table 6-20:	Representation of RAD-DAIO6-IFS analog values	83
Table 6-21:	Representation of RAD-PT100-4-IFS Pt100 values.....	84
Table 7-1:	DIP switches of the RAD-AI4-IFS.....	88

RAD-...-IFS

Table 7-2:	Setting the I/O MAP address for the RAD-AI4-IFS	90
Table 7-3:	Pt100 input	91
Table 7-4:	Setting the I/O MAP address for the RAD-PT100-4-IFS	98
Table 7-5:	DIP switches of the RAD-AO4-IFS.....	100
Table 7-6:	Setting the I/O MAP address for the RAD-AO4-IFS	102
Table 7-7:	Setting the I/O MAP address for the RAD-DI4-IFS.....	105
Table 7-8:	DIP switches of the RAD-DI8-IFS	108
Table 7-9:	Setting the I/O MAP address for the RAD-DI8-IFS.....	110
Table 7-10:	DIP switches of the RAD-DOR4-IFS.....	113
Table 7-11:	Setting the I/O MAP address for the RAD-DOR4-IFS	114
Table 7-12:	DIP switches of the RAD-DO8-IFS	118
Table 7-13:	Setting the I/O MAP address for the RAD-DO8-IFS.....	119
Table 7-14:	DIP switches of the RAD-DAIO6-IFS	123
Table 7-15:	Setting the I/O MAP address for the RAD-DAIO6-IFS	124
Table 8-1:	Typical delay times	126
Table 8-2:	Application of antennas	133
Table 8-3:	Antenna characteristics	134
Table 8-4:	Polarization of transmitter/receiver antennas	135
Table 8-5:	Level and attenuation of the wireless devices and accessories	137
Table 8-6:	Free space attenuation	139
Table 8-7:	Attenuation of different materials	142
Table 8-8:	Radius of the Fresnel zone depending on the distance	145
Table 8-9:	Ranges for different antennas at 2.4 GHz.....	146
Table 8-10:	Ranges for different antennas at 868 MHz.....	146
Table 9-1:	Detecting and removing errors: wireless module	152
Table 9-2:	Detecting and removing errors: I/O extension module	156

B 3 Index

A

Access control with door opener	64
Accessories	171
Ordering data	159
Adapter cable	171
Addressing	
Extension module	53
I/O data mode	54
Modbus register	66
PLC / Modbus/RTU mode	54
Wireless module	35
Analog extension module	87, 91, 98
Analog/digital extension module	120
Antenna	
Accessories	171
Aligning	137
Connecting	27
Installing	134
Selecting	133, 171
Antenna cable	
See Cable	
Antenna socket	27
Application example	18
Application examples, Dual mode	64
Approvals	167
ATEX	167
Attenuation	137, 148

B

Bar graph	45
Point-to-multipoint connection	48
Point-to-point connection	48
Blacklisting	128
Brief description	15

C

Cable	133, 171
Checking the location	132

Circuit diagram

RAD-AI4-IFS	88
RAD-AO4-IFS	99
RAD-DAIO-6-IFS	122
RAD-DI4-IFS	103
RAD-DI8-IFS	107
RAD-DO8-IFS	117
RAD-DOR4-IFS	112
RAD-PT100-4-IFS	92, 96
Wireless module	20
Circular polarization	135
Class A	8
Coexistence management	128
Configuration software	
See PSI-CONF	
Configuration stick	35, 160
CONFSTICK	35, 160
Connecting	
Antenna	27
Cables	22
Power supply	23
Connection assignment	
RS-232	26
RS-485	25
Connection station	20
Control box	184

D

Data Communication Equipment (DCE)	26
Data transmission rate	40
DCE (Data Communication Equipment)	26
Decoupling of wireless paths	135
Default settings	29
Delay time	125
Diagnostics	
On the wireless module	44
Via PSI-CONF software	49

RAD-...-IFS

Diagnostics LED	
RAD-AI4-IFS	89
RAD-AO4-IFS.....	101
RAD-DAIO6-IFS	123
RAD-DI4-IFS	104
RAD-DI8-IFS	109
RAD-DO8-IFS	118
RAD-DOR4-IFS.....	113
RAD-PT100-4-IFS	97
Wireless module.....	44
Diffraction.....	141
Digital extension module	102, 106, 111, 115
DIN rail connector	20
DIP switch	
RAD-AI4-IFS	88
RAD-AO4-IFS.....	100
RAD-DAIO6-IFS	122
RAD-DI8-IFS	107
RAD-DO8-IFS	117
RAD-DOR4-IFS.....	112
Wireless module.....	25
Directional antenna	133
Dispersion	141
Distributed network management	130
Dual mode.....	62
Duty cycle	129

E

EIRP (Equivalent Isotropically Radiated Power)	
Siehe Equivalent isotropically radiated power	
Equivalent isotropically radiated power	39, 147
Error code	83
Extended temperature range	
See Temperature range	
Extension module	
Combinations	52
Product description	87

F

Factory settings.....	29
Fault message contact	47
FCC	13
FHSS (Frequency Hopping Spread Spectrum)	
See Frequency hopping method	
Firmware update	30
Firmware version.....	16

Flow meter	64, 127
Formats	
Analog input and output values	83
Pt100 values.....	84
Frame-based data transmission.....	57
Free space attenuation	139, 148
Frequency hopping method	128
Fresnel zone	144
Front module.....	32
Function block.....	84
Function code	66

G

GPS device	132
------------------	-----

I

I/O extension module	
See Extension module	
I/O integration	
Phoenix Contact controller	85
Siemens controller	86
I/O-MAP address	53
RAD-DAIO6-IFS	52
Industry Canada (IC).....	13
Input and output module	120
Input module	87, 91, 102, 106

L

LED	
See Diagnostics LED	
LED bar graph	
See Bar graph	
Level	137
Location	132
Loopback test	157

M

Master address	35
Measuring error (Pt100)	93
Memory stick.....	37
Modbus.....	59
Modbus function code	
See Function code	
Modbus memory map	68
Complete overview.....	79

Modbus register	66
Modbus telegram watchdog	
See Watchdog	
Monitoring oil pumps	61
Mounting	20
Multipath propagation	47, 141

N

Network key	35
Network management	
See Distributed network management	

O

Oil pump	61
Omnidirectional antenna	133
Output module	98, 111, 115

P

PC Worx	84
Penetration	142
Pin assignment	25
PLC / Modbus/RTU dual mode	62
PLC / Modbus/RTU mode	59
Polarization	134, 135
Potentially explosive area	11, 134, 182
Practical test	132
Process data table	
RAD-AI4-IFS	69
RAD-AO4-IFS	71
RAD-DAIO-6-IFS	77
RAD-DI4-IFS	72
RAD-DI8-IFS	73
RAD-DO8-IFS	76
RAD-DOR4-IFS	75
RAD-PT100-4-IFS	70
PSI-CONF	
Configuring	38
Configuring in PLC / Modbus/RTU mode	60
Diagnostics	49
Pt100 input	91
Pt100 value	84
Pulse counter mode	107
Pulse transmission	127

R

RAD-AI4-IFS	87
RAD-AO4-IFS	98
RAD-DAIO6-IFS	120
RAD-DI4-IFS	102
RAD-DI8-IFS	106
RAD-DO8-IFS	115
RAD-DOR4-IFS	111
Radiated power	
See Equivalent isotropically radiated power	
RAD-ID	35
Radio dead spot	143
Radio waves	141
Radioline function block	84
RAD-PT100-4-IFS	91
RAD-RS485-IFS	32
Range	146
Receiver sensitivity	40
Recording parameters	51
Redundant power supply	23
Reflection	141
Register	66
Relay output	112
Relay, wireless module	
See RF link relay	
Removal	20
Removing errors	
See Troubleshooting	
Repeater chain	43
Repeater/slave address	35
Resetting	
Counter state (Pulse counter mode)	108
To default settings	30
Residential area	8
RF band	35
RAD-2400-IFS	131
RAD-868-IFS	131
RF link relay	47
RS-232 interface	24
RS-485 front module	32
RS-485 interface	24
RS-485 station	32
RSMA antenna socket	27
RSSI signal register	84
RSSI test socket	47
RSSI voltage	46, 151

RAD-...-IFS**S**

Safety notes	7
Saving the configuration.....	37
Serial data mode	55
Serial interface	24
SET button	47
Shield connection	24
Signal strength	
See RSSI voltage	
Slave address	35
Software PSI-CONF	
See PSI-CONF	
Startup time.....	54
STEP 7.....	84
Supply voltage	23
System calculation	148
System power supply	23

T**T-BUS**

See DIN rail connector	
Technical data.....	159
Temperature input.....	91
Temperature measuring error	
See Measuring error	
Temperature range	169
Temperature sensor	
2-wire sensor.....	92
3-wire sensor.....	94
4-wire sensor.....	93
Termination resistor	25
Thumbwheel, white	53
Thumbwheel, yellow	35
TIA Portal	84
Troubleshooting	151

U

UL notes.....	12
USB cable	38

W

Watchdog.....	61
Weather influences	144
Well-pad monitoring system.....	61
Wind.....	144

Wireless module

Configuring.....	31
Installing	20
Product description	19

Z

Zone 2.....	11
-------------	----

RAD-...-IFS

Please observe the following notes

General terms and conditions of use for technical documentation

Phoenix Contact reserves the right to alter, correct, and/or improve the technical documentation and the products described in the technical documentation at its own discretion and without giving prior notice, insofar as this is reasonable for the user. The same applies to any technical changes that serve the purpose of technical progress.

The receipt of technical documentation (in particular user documentation) does not constitute any further duty on the part of Phoenix Contact to furnish information on modifications to products and/or technical documentation. You are responsible to verify the suitability and intended use of the products in your specific application, in particular with regard to observing the applicable standards and regulations. All information made available in the technical data is supplied without any accompanying guarantee, whether expressly mentioned, implied or tacitly assumed.

In general, the provisions of the current standard Terms and Conditions of Phoenix Contact apply exclusively, in particular as concerns any warranty liability.

This manual, including all illustrations contained herein, is copyright protected. Any changes to the contents or the publication of extracts of this document is prohibited.

Phoenix Contact reserves the right to register its own intellectual property rights for the product identifications of Phoenix Contact products that are used here. Registration of such intellectual property rights by third parties is prohibited.

Other product identifications may be afforded legal protection, even where they may not be indicated as such.

How to contact us

Internet

Up-to-date information on Phoenix Contact products and our Terms and Conditions can be found on the Internet at:

phoenixcontact.com

Make sure you always use the latest documentation.

It can be downloaded at:

phoenixcontact.net/products

Subsidiaries

If there are any problems that cannot be solved using the documentation, please contact your Phoenix Contact subsidiary.

Subsidiary contact information is available at phoenixcontact.com.

Published by

PHOENIX CONTACT GmbH & Co. KG

Flachsmarktstraße 8

32825 Blomberg

GERMANY

Should you have any suggestions or recommendations for improvement of the contents and layout of our manuals, please send your comments to:

tecdoc@phoenixcontact.com



SCATTERGOOD & JOHNSON LTD

ELECTRICAL ENGINEERING & FLUID CONTROL DISTRIBUTORS


At Scattergood & Johnson Ltd, we pride ourselves on being a technical distributor to specialist industries.

Working with a range of quality product suppliers across a number of specialist markets, we are not your average 'box shifter' - we are your technical and supply chain partner.

We fully support every product we sell - for free! Our internal team and external sales engineers can answer any product or application question, no matter the complexity.

Backing up this technical ability is a range of 50,000+ products available from stock for nationwide next day delivery (same day if required!), or you can collect what you need from any of our trade counters around the UK.

Select your specialist interest below to learn more about how we can help.



Online, In Branch and On the Road - Scattergood & Johnson Ltd, there when you need us.

www.scatts.co.uk