



Quick start guide

UM QS EN IL EIP BK - M340

Integration of the IL EIP BK DI8 DO4 2TX-PAC
bus coupler into a Modicon M340 controller

Quick start guide

Integration of the IL EIP BK DI8 DO4 2TX-PAC bus coupler into a Modicon M340 controller

2012-09-19

Designation: UM QS EN IL EIP BK - M340

Revision: 00

Order No.: —

This user manual is valid for:

Designation	Revision	Order No.
IL EIP BK DI8 DO4 2TX-PAC	HW 03; FW 103	2897758

Please observe the following notes

User group of this manual

The use of products described in this manual is oriented exclusively to:

- Qualified electricians or persons instructed by them, who are familiar with applicable standards and other regulations regarding electrical engineering and, in particular, the relevant safety concepts.
- Qualified application programmers and software engineers, who are familiar with the safety concepts of automation technology and applicable standards.

Explanation of symbols used and signal words



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety measures that follow this symbol to avoid possible injury or death.

There are three different categories of personal injury that are indicated with a signal word.

DANGER This indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING This indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION This indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



This symbol together with the signal word **NOTE** and the accompanying text alert the reader to a situation which may cause damage or malfunction to the device, hardware/software, or surrounding property.



This symbol and the accompanying text provide the reader with additional information or refer to detailed sources of information.

How to contact us

Internet

Up-to-date information on Phoenix Contact products and our Terms and Conditions can be found on the Internet at:

www.phoenixcontact.com

Make sure you always use the latest documentation.

It can be downloaded at:

www.phoenixcontact.net/catalog

Subsidiaries

If there are any problems that cannot be solved using the documentation, please contact your Phoenix Contact subsidiary.

Subsidiary contact information is available at www.phoenixcontact.com.

Published by

PHOENIX CONTACT GmbH & Co. KG
Flachsmarktstraße 8
32825 Blomberg
GERMANY

Should you have any suggestions or recommendations for improvement of the contents and layout of our manuals, please send your comments to:

tecdoc@phoenixcontact.com

Please observe the following notes

General terms and conditions of use for technical documentation

Phoenix Contact reserves the right to alter, correct, and/or improve the technical documentation and the products described in the technical documentation at its own discretion and without giving prior notice, insofar as this is reasonable for the user. The same applies to any technical changes that serve the purpose of technical progress.

The receipt of technical documentation (in particular user documentation) does not constitute any further duty on the part of Phoenix Contact to furnish information on modifications to products and/or technical documentation. You are responsible to verify the suitability and intended use of the products in your specific application, in particular with regard to observing the applicable standards and regulations. All information made available in the technical data is supplied without any accompanying guarantee, whether expressly mentioned, implied or tacitly assumed.

In general, the provisions of the current standard Terms and Conditions of Phoenix Contact apply exclusively, in particular as concerns any warranty liability.

This manual, including all illustrations contained herein, is copyright protected. Any changes to the contents or the publication of extracts of this document is prohibited.

Phoenix Contact reserves the right to register its own intellectual property rights for the product identifications of Phoenix Contact products that are used here. Registration of such intellectual property rights by third parties is prohibited.

Other product identifications may be afforded legal protection, even where they may not be indicated as such.

Table of contents

1	About this document	1-1
	1.1 Aim of this document	1-1
	1.2 Hardware and software versions	1-1
	1.3 Example	1-2
2	Adding an EIP bus coupler in Unity	1-3
3	Adding a bus coupler in DTM Navigator	1-6
4	Online assignment of the IP address of the Inline I/O station	1-9
	4.1 Open the Ethernet/IP™ Made Easy application	1-9
	4.2 BootP server	1-10
	4.3 Changing to a static IP address	1-11
5	Online setting of the digital and analog I/O reserves	1-13

IL EIP BK D18 DO4 2TX-PAC

1 About this document

1.1 Aim of this document

This quick start guide helps you to start up an Inline station (IP20) in an Ethernet/IP™ network with a Modicon M340 controller using the Unity software.



Please proceed as follows to start up IP67 modules of the Fieldline product range:

Configure the station in such a way that it produces or consumes a preset amount of data. This amount of data is the maximum to be expected depending on the connected configuration. Thus, the controller configuration does not need to be adapted when the configuration connected to the IL EIP BK DI8 DO4 2TX-PAC bus coupler is changed.

1.2 Hardware and software versions

Devices or software with the following version was used for preparation of this quick start:

Table 1 Hardware

Manufacturer	Order No.	Type	Hardware version	Firmware version
Phoenix Contact	2897758	IL EIP DI8 DO4 2TX-PAC	03	103
Schneider Electric		BMXNOC0401	01	1:01

Table 2 Software

Manufacturer		Type	Version
Phoenix Contact		Ethernet/IP™ made easy	1.0.1.68
Schneider Electric		Unity Pro S	V5.0
Phoenix Contact	IL_EIP_BK_DI8_DO4_M340.eds	EDS file for M340	

1.3 Example



Install the required devices according to the information given in the associated documentation. The documentation from Phoenix Contact can be found on the Internet at www.phoenixcontact.net/catalog.

The following explanations are based on this example:

- 32-bit digital inputs (including eight digital bus coupler inputs), this corresponds to 4 bytes.
- 8 words for analog inputs, this corresponds to 16 bytes
- Two bytes for every status word of the station are added to these words.

This results in 22 bytes of data.

- 16-bit digital outputs (including four digital bus coupler outputs), this corresponds to 2 bytes.
- 4 words for analog outputs, this corresponds to 8 bytes.

This results in a data consumption of 10 bytes.




Figure 1 Example structure

Status word structure

Table 3 Byte 0: Local bus status


Bit	Meaning of bit x = 1
0	CRC error during transmission on the local bus
1	I/O error on the local bus (short circuit in the digital output module).
2	U_L, U_S or $U_M < 11$ V.
3	The existing configuration differs from the stored configuration.
4	Communication with the first local bus module not present or no longer present.
5	Communication loss in the local bus detected (see byte 1).
6	Outputs in output position (Fault Mode 2)
7	Reserved

Table 4 Byte 1: Error location (number of the faulty local bus module)


Content	Meaning
1	Module with four integrated digital outputs (bus coupler)
2	Module with eight integrated digital inputs (bus coupler)
3	First active Inline module connected to the bus coupler
4	Second active Inline module connected to the bus coupler

2 Adding an EIP bus coupler in Unity

- Create a Unity project with your controller.




- Add the EIP bus coupler to your controller configuration.




IL EIP BK D18 DO4 2TX-PAC

- Assign a name to the EIP bus coupler.



- Define the I/O area. Please note that 16 I/O words are reserved for the EIP bus coupler.



In addition to the 16 words reserved by the EIP bus coupler, this example provides 34 I/O words at the remote stations (thus 50 I/O words). The inputs of this station can be accessed from %MW16 (Inline status word) and the outputs from %MW66.

Adding an EIP bus coupler in Unity

- Define the IP address of the bus coupler in the DTM navigator.

The screenshot displays the Unity Pro S software interface for configuring an EIP_Scanner device. The main window is titled "Unity Pro S : -No name* - [EIP_Scanner - fdtConfiguration]". The interface includes a menu bar (File, Edit, View, Services, Tools, Build, PLC, Debug, Window, Help) and a toolbar with various icons.

The left sidebar contains two panes: "Project Browser" and "DTM Browser". The "Project Browser" shows a structural view of the project configuration, including a PLC bus, BMX YBP 0800, BMX CPS 2000, BMX P34 20102, and BMX NOC 0401. The "DTM Browser" shows a Host PC connected to the EIP_Scanner at IP address 192.168.0.1.

The main workspace is divided into three sections:

- Channel Properties:** Shows the selected device "M_NOC0401" and its communication type "EIP_Scanner".
- Services:** A tree view showing services like Address Server, SNMP, QoS, and EtherNet/IP Local Slaves (Local Slave 1, 2, 3).
- Configuration:** A table for defining IP address parameters. The configuration is set to "Static".



Group/Parameter	Value	Unit
IP Address		
Scanner IP Address	192.168.0.20	
Sub-Network Mask	255.255.255.0	
Gateway IP Address	0.0.0.0	

A description box below the table states: "Field of 4 bytes entered in pointed decimal notation representing the Internet address or IP address of the scanner." Buttons for "Help", "OK", "Cancel", and "Apply" are located at the bottom of the configuration area.


The bottom status bar shows the system is "Ready", with indicators for "HMI R/W mode", "OFFLINE", "USB:SYS", and "NOT BUILT".

3 Adding a bus coupler in DTM Navigator


- In DTM Navigator, click the EIP bus coupler with the right mouse button and click “Add”.



Adding a bus coupler in DTM Navigator




- Set the IP address of the I/O station.




IL EIP BK DI8 DO4 2TX-PAC

- Specify the provided produced/consumed amount of data and the cycle time (RPI) of the I/O station.

In this example, 22 input bytes (produced by the station) are provided in Multicast or Unicast modes as well as 10 output bytes (consumed by the station) in the Unicast mode (point-to-point).



A connection summary will be shown.




Offline operation is finished now.


4 Online assignment of the IP address of the Inline I/O station

4.1 Open the Ethernet/IP™ Made Easy application

- Select the network card of the computer.




- Option: Filter for available addresses.




4.2 BootP server

- Select the target station.



- Enter the IP address and confirm the input with “Add”.




- Assign the IP address by clicking “Start ...” (“Assigning” and afterwards the address given in the “IP Address” field).

Online assignment of the IP address of the Inline I/O station


- Option: Configure the Managed Switch.

The view shown in the screenshot allows fast configuration of the basic settings of the Managed Switches in the network (IGMP, Snooping, RSTP, etc.).




4.3 Changing to a static IP address

- Select the station to be configured.



IL EIP BK DI8 DO4 2TX-PAC


- Deactivate the BootP server.



The station now has a fixed IP address. You can exit the “EtherNet/IP™ Made Easy” program.

5 Online setting of the digital and analog I/O reserves

- In DTM Navigator right-click IL_EIP_BK_DI8_DO4 and afterwards “Connect”.
- Write the parameters from the EDS file.



Here, you select the digital or analog inputs and outputs in accordance with the produced and consumed amount of data.

In our example:

- Included status word = 2 bytes
- Reserve 32-bit digital input = 4 bytes
- Reserve 8-bit analog output = 16 bytes


This corresponds to the provided produced amount = 22 bytes

- Reserve 16-bit digital output = 2 bytes
- Reserve 4-bit analog output = 8 bytes

This corresponds to the consumed amount = 10 bytes

These parameters become effective as soon as the “Add All IO” is set to TRUE.

IL EIP BK D18 DO4 2TX-PAC



These parameters have now been written to the I/O station. This can also take place with explicit messages.

Activate communication by placing the switch to STOP/RUN or activating the corresponding bit (%MW 50.0).



SCATTERGOOD & JOHNSON LTD

ELECTRICAL ENGINEERING & FLUID CONTROL DISTRIBUTORS

Est.1899

At Scattergood & Johnson Ltd, we pride ourselves on being a technical distributor to specialist industries.

Working with a range of quality product suppliers across a number of specialist markets, we are not your average 'box shifter' - we are your technical and supply chain partner.

We fully support every product we sell - for free! Our internal team and external sales engineers can answer any product or application question, no matter the complexity.

Backing up this technical ability is a range of 50,000+ products available from stock for nationwide next day delivery (same day if required!), or you can collect what you need from any of our trade counters around the UK.

Select your specialist interest below to learn more about how we can help.



Online, In Branch and On the Road - Scattergood & Johnson Ltd, there when you need us.

www.scatts.co.uk