

* Full range of accessories for NZM MCCB

Moeller

NZM MCCB Accessories



Auxiliary Contacts (Screw Contact)



Part Number	Description	For Use With
M22-K10	Internal Fixing, 1 N/O Contact	NZM MCCB PN Isolators
M22-K01	Internal Fixing, 1 N/C Contact	

Shunt Trips (Screw Contact)



Part Number	Voltage	For Use With
NZM1-XA/24ACDC	24 V AC/DC	NZM1 MCCB
NZM1-XA/110ACDC	110-130 V AC/DC	
NZM1-XA/230ACDC	208-250 V AC/DC	
NZM1-XA/415ACDC	380-440 V AC/DC	
NZM2/3-XA/24	24 V AC/DC	NZM2, NZM3 MCCB
NZM2/3-XA/110	110-130 V AC/DC	
NZM2/3-XA/230	208-250 V AC/DC	
NZM2/3-XA/415	380-440 V AC/DC	
NZM4-XA/24ACDC	24 V AC/DC	NZM4 MCCB
NZM4-XA/110ACDC	110-130 V AC/DC	
NZM4-XA/230ACDC	208-250 V AC/DC	
NZM4-XA/415ACDC	380-440 V AC/DC	

Under Voltage Trips (Screw Contact)



Part Number	Voltage	For Use With
NZM1-XU/24AC	24 V AC	NZM1 MCCB
NZM1-XU/110AC	110-130 V AC	
NZM1-XU/230AC	208-250 V AC	
NZM1-XU/415AC	380-440 V AC	
NZM2/3-XU/24AC	24 V AC	NZM2, NZM3 MCCB
NZM2/3-XU/110AC	110-130 V AC	
NZM2/3-XU/230AC	208-250 V AC	
NZM2/3-XU/415AC	380-440 V AC	
NZM4-XU/24AC	24 V AC	NZM4 MCCB
NZM4-XU/110AC	110-130 V AC	
NZM4-XU/230AC	208-250 V AC	
NZM4-XU/415AC	380-440 V AC	

Leeds

Tel: 0113 243 0203

Sheffield

Tel: 0114 243 1841

Gateshead

Tel: 0191 460 2233

Manchester

Tel: 0161 876 4337

Glasgow

Tel: 0141 892 0166

Walsall

Tel: 01922 403426

e-mail: sales@scatts.co.uk

web: www.scatts.co.uk